

啤穿針線2*2

Caution: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This Class B digital apparatus complies with Canadian ICES-003. Cet appareil numérique de la classe Best conforme à la norme NMB-003 du Canada. FCC ID: S09XOX1001 IC: 5768A-XOX1001 FOR DECOGNITIVE USE ONLY © 2010 Hallmark Licensing, Inc. Mid. for Hallmark Cards, Inc. Kansas City, MO 64141 www.hallmark.com XOX1001



Requires three (3) AA batteries (included). CAUTION: DO NOT MIX OLD AND NEW OR DIFFERENT BATTERY TYPES. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Hallmark
Wireless Snowman Band
Saxophone Joe

PLAYS MUSIC AND MOVES!

1 PMS7489C 2 PMS200C 3 Black Die-cut

File Info-

Client: Hallmark
File: 1XOX1001U_US_Card_004129_R2
DCR No: D1004129R3
Handle by: Lan
Location: Job Share
Software & Ver: AI CS 3.0
Date: 30/04/2010

Output Info-

Screen Set: ABS175_LPI_Round
Tone Repro: None
Line Screen: 175lpi
Dot Shape: Composed
Output Media: Plate
Trapping: On app
Newsland Printing Co. Ltd.

Not valid with any other offer or on past purchases. Tax not included.
Offer valid while supplies last.
REGULARLY \$24.95
\$12.95
WITH ANY PURCHASE

Each of the four snowmen in this band moves in time to the two songs that each plays individually. When put together with other members of the band, they communicate wirelessly to move in time and play along with each other's songs. As with other holiday traditions, "The more the merrier!" Put the four band members together, and enjoy all eight songs!

Saxophone Joe plays "Jolly Old St. Nick" and "Up on the Housetop."

This is not your ordinary Snowman Band!

Slide switch to "ON" to turn on. The snowman will begin to play a song. Once he finishes that song, press the play button to hear the next song. If you own more than one Snowman Band member, whichever band member you activate will take the lead and the others will follow. If a band member seems to be playing on his own, simply slide his switch up to "OFF" and then back to "ON" and that should help the band to sync up again. It's best to keep the band members near each other (within a three-foot circle) when they are synchronizing.

To operate in "DISPLAY" mode, press and hold the play button for four seconds. The band will then self-activate on a timed mode (two to three minutes between each song). The band members will signal that they've switched modes. To turn off "DISPLAY" mode, press and hold the play button on any one member for four seconds and the band members will signal that they've switched modes again. "DISPLAY" mode will shorten the battery life. When not in "DISPLAY" mode, if the item is left on at all times, you should expect the batteries to last through a full holiday season with normal use.

1 PMS200C Die-cut

File Info-

Client: Hallmark
File: 1XOX1001U_US_Card_004129_R2
DCR No: D1004129R3
Handle by: Lan
Location: Job Share
Software & Ver: AI CS 3.0
Date: 30/04/2010

Output Info-

Screen Set: ABS175_LPI_Round
Tone Repro: None
Line Screen: 175lpi
Dot Shape: Composed
Output Media: Plate
Trapping: On app
Newsland Printing Co. Ltd.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. these limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause interference to radio communications.

however, there is no guarantee that interference will not occur in a particular installation. if this equipment does cause harmful

interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help.

X.X+-0.1
X.XX+-0.01
X.XXX+-0.001
ANG. +-0.5