

Step 1

Scan the bar code affixed to the bottom of the ROAM™ node ID using handheld PDA.

Scan Node ID



Step 2

Scan fixture attributes using handheld PDA and activation booklet. Fixture attributes may include lamp type, wattage, pole ID etc.

Scan Fixture Attributes



Step 3

Insert photo control node into twist locking receptacle on top of the fixture.

Install Node on Fixture



Step 4

Cover photo control device with hand to shield light. Photo control is functioning properly when fixture illuminates.

Test Node Functionality



ROAM Installation Manual

Specifications

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

FCC ID: SQB-NIVISLM0002

IC: 6546A-NIVISLM0002

IMPORTANT NOTE: To comply with FCC RF exposure compliance requirements, the antenna used for this transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. Under normal operating conditions, the antenna is designed to maintain a separation distance of 20 cm from all persons. The antennas used for this transmitter must be installed to provide a separation distance of at least 20cm from all persons.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Industry Canada Statement per Section 4.0 of RSP-100

The term "IC:" before the certification / registration number only signifies that the Industry Canada technical specifications were met.

Section 7.1.5 of RSS-GEN

Operation is subject to the following two conditions:

- 1) this device may not cause interference, and
- 2) this device must accept any interference, including interference that may cause undesired operation of the device.



ROAM, a Subsidiary of Acuity Brands

ROAM Headquarters, 3825 Columbus Road,
Granville, OH 43023

Contact your local Holophone factory sales representative for application assistance, and computer-aided design and cost studies. For information on other Holophone products and systems, call the Inside Sales Service Department at 740-345-9631. In Canada call 905-707-5830 or fax 905-707-5695.

Changes or modifications to this unit not expressly approved by ROAM could void the user's authority to operate this equipment.

For more information on ROAM, please contact your local representative