

Instructions for Nyko Wireless Headset for Xbox Live™

Thank you for purchasing the Nyko Wireless Headset for use with the Xbox Live™ online gaming service. This device utilizes the latest technologies available to provide unparalleled performance and comfort. Please familiarize yourself with this manual to insure proper use and installation of this device.

FEATURES

- Wireless 2.4 GHz technology for crisp, clear communication up to 20 feet
- Ultra-lightweight, ergonomic design for comfort and stability during long gaming sessions
- Rechargeable lithium-ion battery delivers six hours of continuous use
- Tactile Mute button for convenience
- Two soft silicone ear pieces, in different sizes, and adjustable ear strap provide custom comfort for either ear
- Volume control for independent, one-touch access
- Works with all dual-port controllers and wireless controllers with dual-port adaptors for complete wireless gaming experience.
- Compatible with all voice-supported Xbox Live games
- Easy setup: plug and play
- AC charger included

SYSTEM REQUIREMENTS

- Xbox Communicator module (not included)
- Xbox Live account*
- Xbox game title that supports voice command or online voice communication
- A dual-port Xbox game controller

*Please note that certain games allow the use of voice command without online connection. In this case an Xbox Live account is not required to use this device.

GETTING STARTED - CHARGE YOUR HEADSET

Your Nyko Wireless Headset incorporates a lithium ion rechargeable battery. This power source is designed for heavy use and repeated charging. Never attempt to replace the battery.

- 5) Make sure that your Xbox Live account is still active.
- 6) Make sure that your Wireless Headset is fully charged.

If you keep hearing beeping sounds:

The unit's power is low and needs to be charged.

If the sound is too loud or is distorting:

- 1) Turn down the volume on the headset using the (-) button.
- 2) Turn down the volume of the Xbox Communicator module.
- 3) Make sure that all your connections are sound, and everything is plugged in properly.

NOTE: The sound may distort because of the internet connection, or lag associated with the online game you are playing. If the host of the online game is not capable of fully supporting all participants, you may notice lag with both voice and game play.

If you try to use the Wireless Headset without an Xbox Communicator module:

The Nyko Wireless Headset requires the Xbox Communicator module to interact with the Xbox console.

If you experience considerable lag in online game play:

Check your internet connection speed, or contact your service provider if you are experiencing unsatisfactory performance. The Nyko Wireless Headset has no effect on the speed of the game.

TECHNICAL SUPPORT

We appreciate your support of Nyko products, and endeavor to guarantee your satisfaction with this purchase. If you are experiencing difficulties, please contact us:

Online: www.nyko.com

Email: customersupport@nyko.com

Phone: 1-888-444-6956

Nyko Product Limited Warranty

This Nyko product is warranted to the original purchaser for the normal intended use for a period of ninety (90) days from the date of purchase. If a defect covered under this warranty occurs, Nyko will replace or repair the product or its defective parts, at its option, at no charge. Warranty does not apply to defects resulting from modification or misuse of this product. The product can be returned to the place of purchase with proof of purchase or shipped to: Nyko Technologies, 1990 Westwood Blvd, 3rd Floor, Los Angeles, CA 90025, with freight charges prepaid. Please allow 3-4 weeks for processing.

Only use the AC adaptor supplied with this product. MAKE SURE THE UNIT IS FULLY CHARGED BEFORE USING IT FOR THE FIRST TIME. TO CHARGE:

- 1) Plug the supplied AC adaptor into a power socket.
- 2) Insert the AC adaptor tip into the DC port (2) on the side of the headset.
- 3) A SOLID RED GLOW from the LED (located under the clear Power button (1)) indicates that the unit is charging
- 4) A FLASHING RED from the LED shows the unit is fully charged. A full charge will take approximately 5 hours.
- 5) Once the unit is fully charged, it is ready for use. Unplug the AC adaptor from the headset and follow the instructions below.

NOTE: A beeping sound means the unit needs to be charged.


POWERING UP YOUR HEADSET

Press and hold the clear Power button (1) for a few seconds. You will hear a rising crescendo of tones indicating that the headset is powering up. Press and hold the clear Power button again for a few seconds. You will hear a deepening crescendo of tones to indicate the headset is shutting off.

INSTALLATION:

To begin use of your Nyko Wireless Headset, please follow these steps:

- 1) Charge your Nyko Wireless Headset until the unit's LED flashes red to show a full charge.
- 2) While your Xbox console is turned OFF insert a controller with dual expansion ports into one of the open controller ports of the console.
- 3) Insert the Wireless Headset's transceiver into the lower port of the controller.
- 4) Insert an Xbox Communicator module (not included) into the top port of the controller.
- 5) Insert the small plug attached to the transceiver into the headset jack located on the communicator.
- 6) Select the silicone ear gel that fits your ear most comfortably. Make sure the ear gel is securely in place on the headset's stem. Never force the stem into your ear canal. A large ear gel is already installed on your headset. A spare large ear gel plus a smaller one are also included in the packaging.



- 7) This headset can be worn on either ear. Flip the ear strap as needed.
- 8) Turn the Xbox console ON and check the game's option menu to ensure the voice/headset feature is active.
- 9) A FLASHING GREEN LIGHT on the headset indicates it is attempting to link. Once the headset's LED and the transceiver's LINK light are both SOLID GREEN, a link has been established. Your headset is ready.

NOTE: The transceiver and the headset have been factory matched to each other, and will not operate with other headsets or transceivers. If you have purchased more than one Nyko Wireless Headset, please label each set to avoid confusion. Remember to store your set in a safe place to avoid loss or damage.

ADJUSTING THE HEADSET VOLUME

Set the volume using the (+) and (-) buttons on the headset. The Nyko Wireless Headset provides 9 preconfigured sound levels. You will hear indicator tones each time one of the volume buttons is pressed.

NOTE: We suggest setting the volume of the Xbox Communicator module to the maximum level, and use the volume control of the Wireless Headset to set your desired sound level.

IMPORTANT! The microphone on the headset will not work if the mute function of the Xbox Communicator module is on. Press the Mute button on the Xbox Communicator module to change its LED light from red to green.

USING THE MUTE FEATURE OF THE HEADSET

The Nyko Wireless Headset is equipped with a Mute button. This feature allows you to deactivate the microphone of the headset if you don't want your opponents and/or teammates to hear you.

Press the Mute button (M) on the face of the Wireless Headset until it is in the up position. The microphone is now muted. Press it again to return it to the down position. The microphone is now active again.

NOTE: To avoid confusion, we recommend that you always keep the mute feature of the Xbox Communicator module inactive (green LED), and only use the Mute button located on the Wireless Headset.

FCC Advisory

This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or move the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a different circuit from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

You are cautioned that any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

RF Exposure Statement:

The antenna used for either headset or transceiver must not be co-located or operating in conjunction with any other antenna or transmitter, and the antenna used for the transceiver must be installed to provide a separation distance of at least 20 cm from all persons."

NYKO®

Register this product online:
Coloque este producto en línea:
Enregistrez ce produit sur Internet:

www.nyko.com

Xbox® and Xbox Live™ are trademarks of Microsoft Corporation.
Nyko® is a registered trademark of Nyko Technologies, Inc.
©2005 Nyko Technologies, Inc. All Rights Reserved.

RESETTING YOUR HEADSET

Should your headset fail to operate properly, or fail to link, it may become necessary to reset the unit to the original factory settings. Resetting should only be considered as a last resort after all steps have been taken prior.

On the back of the headset is a small hole labeled "RESET". Insert a pin or open paper clip into the hole and gently press down on the reset button.

INTERFERENCE

Although the Nyko Wireless Headset uses a proprietary 2.4 GHz wireless technology which is certified by the FCC and is resistant to interference, we recommend that you keep the use of other wireless technology in the vicinity of the Wireless Headset to a minimum for optimum performance.

If a connection loss occurs you will notice a blinking green light on the headset. The unit will automatically reconnect once the cause of the interference is eliminated or once you return to within device range.

TROUBLESHOOTING

If other players cannot hear you:

- 1) Make sure that (M) Mute button on the Headset is pressed in ()
- 2) If the LED on the Xbox Communicator module is glowing RED, then the mute function is active. Press the Mute button until the LED glows GREEN.

- 3) Make sure that both the Wireless Headset's transceiver and the Xbox Communicator module are correctly inserted into the controller ports.


If you cannot talk to or hear other players; the LED on the Wireless Headset is flashing green:

- 1) Turn the headset off then on again, allowing it to re-link with its transceiver.
- 2) Unplug then re-plug the transceiver into the lower port of the controller, allowing it to re-link with the headset.
- 3) Make sure that the Xbox Communicator module is correctly inserted into the top port of the controller, and the LED on the device is glowing green, indicating that the microphone is active.
- 4) Check the options menu in the game you are playing to make sure it is voice compatible, and that the voice/headset feature is activated. Refer to the game's instruction manual regarding the use of a headset.

NYKO®

WIRELESS HEADSET

for/pour/para Xbox Live™



INSTRUCTIONS

Item# 81440