


User's Manual

1. Connect the jack of this device to the earphone jack of portable player.
(MP3, MD, CD Player Etc.)
2. Connect the wire (red, black) of this device to the car power line.
(red-VCC, black-GND)
3. You can check a frequency position on/off the Select switch.
(We set the frequency with 106.7Mhz when we produce this device)
4. Turn on the FM radio of vehicles and set the same frequency with the marked on select switch position.
5. Push the play button of portable player.
6. The selected music sounds through car speaker.
7. You can adjust the sound with the Volume up/down button of portable player.
(Also you can adjust the sound with the volume controller of car FM radio)
8. You can select 7 FM channel with this device.



Notice

- * Do not use this device while you are driving.
- * FM frequency could be disturbed at some place or momentary noise due to the feature of FM wave.
- * This device is only for 12 Volt and do not use it with 24 Volt vehicles.
- * Do not locate this device and portable player at the place disturbed for driving.
- * Just change the fuse with new one if it is disconnected. (1A standard)
- * Do not locate this device under a direct ray of light, nearby heater and cooler device. It could make out of order.
- * Do not give strong shock on this device and it could make out of order.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE: THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.