

FOB-4F26

Fob Smart Key

Manual for vehicle manufacturer

OUTLINE

1. How to use FOB-4F26

- FOB-4F26 is a part of Remote Keyless System.
- This unit controls door lock/door unlock/
remote engine start-stop/tailgate open/panic wirelessly.

2. Introduction of Transmitter (FOB-4F26)

- Transmitter has five buttons
- Transmitter use the battery
- Frequency is 433.92MHz

GENERAL DESCRIPTION

PRIMARY FUNCTION

- Remote door lock/unlock/tail gate/remote engine start-stop/tailgate/panic
- Operating voltage : 3V DC
- Center freq.: 433.92MHz

Manual

1) LOCK Button

If the LOCK button is pushed, then TRANSMITTER sends the LOCK Data.

2) UNLOCK Button

If the UNLOCK button is, then TRANSMITTER sends the UNLOCK Data.

3) Remote engine start-stop Button

If the Remote engine start-stop button is pushed,
then TRANSMITTER sends the Remote engine start Data.

4) Panic Button

If the Panic button is, then TRANSMITTER sends the Panic Data.

5) TAILGATE Button

If the TAILGATE button is pushed, then TRANSMITTER sends the TAILGATE OPEN Data.

How to change the battery

1) Pull out the metal key from the fob.

2) Plug the key at the case edge and twist to open.

3) Place a new battery (button cell)

- FCC ID is located in battery compartment and user will be able to see the FCC ID when they change the battery.

FCC Warning

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

IC Warning

"This device complies with Industry Canada licence-exempt RSS standard(s)."

Operation is subject to the following conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas provoquer de brouillage, et (2) l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.