


## Using your Lenntek hookup

### Charging your iPod and downloading.

Your new Lenntek **hookup** adapter allows you to charge and download songs without removing the Adapter from the iPod. Just simply plug your iPod "dock connector to USB" cable directly as shown below and start charging and/or downloading.



## Trouble Shooting

**Q: Why doesn't my hookup and Adapter communicate with each other?**

**A:** In order to communicate with each other, the **hookup** and Adapter for iPod must be paired. Please refer to "Using your Lenntek hookup" in the manual.

**Q: My hookup and Adapter seemed paired, but why will they not communicate with each other?**

**A:**

1. Make sure your **hookup** is fully charged (refer to "Using your Lenntek **hookup**" in the manual).
2. Make sure your **hookup** is powered on and Adapter is in search mode with Blue indicator light flashing.
3. Make sure no other Bluetooth devices are in the vicinity.

**Q: Why does my iPod automatically turn on again after I turn off the iPod by "long pressing" play/pause button?**

**A:** If the iPod charge cable is plugged into Adapter and Adapter is in search mode, please wait until the Adapter goes to idle mode. Then "long press" the play/pause button to turn off the iPod.

**Q: Why doesn't the hookup : last number redial, reject call, and switch between phone/hookup conversation when I "long press" the forward/next button?**

**A:** Your mobile phone may not have connected via "handsfree" profile (or does not have this profile) but instead has connected with **hookup** with it's "headset" profile. Bluetooth Headset profile does not support these functions.

## Trouble Shooting

**Q: Why does the Adapter keep searching for the hookup, although the hookup is on and but not connecting?**

**A:** Once the Adapter is plugged into the iPod and the iPod is Playing, the Adapter will begin to connect with **hookup**. This process will last for up to 10 seconds. If no connection occurs after 10 seconds, Adapter will try to search for a new Bluetooth device. You need to make sure both **hookup** and Adapter are in search mode. To set your **hookup** in search mode, turn off your **hookup**, then turn it back on. To set the Adapter in search mode, you can set the iPod to pause and then back to play, or unplug Adapter from iPod and then re-plug into the iPod.

**Q: I can't hear or answer mobile phone calls through my headset?**

**A:**

1. Ensure your mobile phone has Bluetooth and the Bluetooth function is turned on.
2. Make sure that the **hookup** is paired properly with the mobile phone and to other Bluetooth devices.
3. Check to see if the headset is properly connected with the **hookup**.

**Q: Why can't the hookup be turned off (the indicator light remains on)?**

**A:** Please plug in the USB charger cable to recharge your **hookup** (please refer to Using your Lenntek **hookup** in your manual), unplug, and now turn off your **hookup**.

**Q: Which mobile handsets will work with my hookup?**

**A:** **hookup** supports standard Bluetooth Handsfree and Headset profiles. Most mobile phones with Bluetooth supports either or both of these profiles. But there are specific cases of phones that will not operate. Please check our website ([www.Lenntek.com](http://www.Lenntek.com)) for more details about your specific phone issues.



## Light Codes

### hookup

#### Light Status

Red / Blue (Alternating)

Slow Blue

Fast Blue

#### Mode

In pairing mode.

**hookup** is paired with Adapter.

**hookup** is idle and not paired with Adapter.

### Adapter

#### Light Status

Fast, multiple Blue

Slow Blue

Fast single Blue

#### Mode

In pairing mode.

Adapter is paired with **hookup**.

Adapter is idle and not paired with **hookup**.

# Warranty

THIS WARRANTY IS VALID ONLY FOR SERVICE IN THE COUNTRY OF PURCHASE.

This product, except the case and battery, is warranted by Lenntek and its distributors to the original purchaser to be free from defects in material and workmanship under normal use for a period of one year from the date of purchase. During the warranty period, and upon proof of purchase, the product will be repaired using Lenntek reconditioned/replacement parts or the product will be replaced with the same or a similar reconditioned/replacement model at Lenntek's discretion. To obtain warranty service, please take or send the product postage paid, with a copy of your sales receipt or other proof of purchase that shows the date of purchase, to a Service location listed in the "Lenntek is here to HELP you" page. There will be no parts or labor charge to you. Due to the possibility of damage or loss during shipping, it is recommended when sending the product for service that you package the product securely and send it insured, return receipt requested.

The customer shall NOT have any claim under the warranty to repair or adjustment expenses if:

- 1) The problem is caused by improper, rough or careless treatment.
- 2) The problem is caused by a fire or other natural calamity.
- 3) The problem is caused by improper repair or adjustment made by anyone other than a Lenntek service center.
- 4) The problem is caused by battery leakage, bending of the unit, broken display or key.
- 5) The case or battery is damaged or worn.
- 6) Maintenance requested consists of repair or replacement of options, accessories, or consumables.
- 7) The proof of purchase is not presented when requesting service.
- 8) The warranty period has expired.

NEITHER THIS WARRANTY NOR ANY OTHER WARRANTY OR GUARANTEE, EXPRESS OR IMPLIED STATUTORY OR OTHERWISE, INCLUDING ANY IMPLIED WARRANTY OR CONDITION OF MERCHANTABILITY OR OF FITNESS FOR A PARTICULAR PURPOSE, SHALL EXTEND BEYOND THE WARRANTY PERIOD. NO RESPONSIBILITY IS ASSUMED FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES, INCLUDING, WITHOUT LIMITATION DAMAGES RESULTING FROM INACCURACY OR MATHEMATICAL INACCURACY OF THE PRODUCT OR LOSS OF STORED DATA. SOME STATES OR JURISDICTIONS DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS AND SOME STATES OR JURISDICTIONS DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, OR THE EXCLUSION OR LIMITATION BY A PARTY OF LIABILITY FOR DEATH OR PERSONAL INJURY CAUSED BY THAT PARTY'S NEGLIGENCE, SO THE ABOVE LIMITATIONS OR EXCLUSIONS SHALL NOT IN SUCH CASES APPLY. THIS WARRANTY GIVES YOU SPECIFIC RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE, JURISDICTION TO JURISDICTION, OR COUNTRY TO COUNTRY. NOTHING IN THIS WARRANTY AFFECTS YOUR STATUTORY RIGHTS.

THANK YOU FOR CHOOSING LENNTEK

Lenntek is here to HELP You

If you have any problems with this product, please contact one of the following.

	U.S./CANADA	Other Countries
Customer Support	Lenntek	Please contact the Store/Dealer where purchased.
Service location for product repair	Lenntek	
URL	<a href="http://www.lenntek.com">http://www.lenntek.com</a>	<a href="http://www.lenntek.com">http://www.lenntek.com</a>
If for any reason this product is to be returned to the store where purchased, it <b>MUST</b> be placed in the original carton/package.		
US residents may register their product online at <a href="http://www.lenntek.com/support">www.lenntek.com/support</a> .		

WARRANTY CARD

MODEL \_\_\_\_\_

DATE OF PURCHASE \_\_\_\_\_

CUSTOMER'S NAME \_\_\_\_\_

OFFICIAL DEALER STAMP

LENNTEK  
1610 Lockness Place, Torrance, CA 90501