

MAYFLASH LTD

Wireless Rock Guitar Controller Instructions

How it works

1. Plug the receiver to your PS2 game console first, and power on your console. The LED light will be shining and blinking now, and the receiver starts to search a suited wireless guitar controller.
2. Properly put the batteries into the battery box that is on the back of the guitar controller.
3. The switch of the guitar controller should be pushed to "ON" now.
4. The LED light near the switch will be blinking, and begins to look for a suited receiver.
5. When a pair of receiver and controller is matched, the LED light on the receiver will be always shining, and the LED light on the guitar controller will be shining for only 5 seconds and go out. The wireless guitar controller is ready to use.
6. The guitar controller will go into its sleep mode if without any action for 2 minutes. But you can press the button "SELECT" to make it work again.

Notice

1. If the batteries are NOT placed correctly, and if the batteries are used for a long time or you are using overdue batteries, the LED light on the receiver will keep blinking, and guitar controller LED light will not be shining. It means the wireless guitar controller stop working.
2. When the guitar controller switch is pushed to "ON", and the controller LED light will be shining or blinking for a while, it shows that the batteries are placed rightly and voltage is enough.
3. When the wireless guitar controller is right connected to any receiver, it will lock up this receiver at once. The actions like powering off the game console or unplugging the receiver are not able to change this situation. The only way that you can unlock is to push the guitar controller switch to "OFF".
4. If there are several receivers and wireless guitar controllers work at the same time, they will be matched freely. After a successful match between the particular controller and receiver, it will never change unless you power off the guitar controller.

FCC Compliance and Advisory Statement

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, according to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try correct the interference by one or more of the following measures:

- 1.Reorient the receiving antenna.
- 2.Increase the separation between the equipment and receiver.
- 3.Connect the equipment into and outlet on a circuit different from that to which the receiver is connected.
- 4.Consult the dealer or an experienced radio/TV technician for help.

Any special accessories needed for compliance must be specified in the instruction manual.

Warning: A shielded-type power cord is required in order to meet FCC emission limits and also to prevent interference to the nearby radio and television reception. It is essential that only the supplied power cord be used. Use only shielded cables to connect I/O devices to this equipment.

CAUTION: Any changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.