TX141 Remote Electronic Ignition and Control System



OPERATING INSTRUCTIONS -FOR OEMUSE ONLY



TX141

∆WARNING

Fire or explosion hazard. Attempted disassembly or repair of controls can cause property damage, severe injury or death. Do not disassemble the gas valve; it contains no serviceable components.

Read these instructions carefully. Failure to follow them could result in a fire or explosion causing property damage, personal injury, or loss of life. The product must be installed and operated according to all local regulations.

A. BEFORE OPERATING verify that no gas is in the area around the appliance, including near the floor.

WHAT TO DO IF YOU SMELL GAS:

- Do not light any appliance.
- Do not touch any electrical switch; do not use any phone in your building.
- Immediately call the gas supplier from a neighbor's phone.
 Follow the gas supplier's instructions.
- If you cannot reach the gas supplier, call the fire department.
- B. Use only your hand to push in or turn the gas control knobs. Never use tools. If a knob will not push in or turn by hand, don't try to repair it, call a qualified service technician. Force or attempted repair may result in a fire or explosion.
- C. Do not use this control or any gas appliance if any part has been under water or in contact with water. Immediately call a qualified service technician to replace the control system and any gas control system which has been under water or in contact with water.
- These instructions are to be referenced as a user guide, and do not supersede appliance manufacturer's lighting instructions

APPLICATION

TX141 is a battery-powered electronic remote ignition and control system for gas appliances with pilot burners and ODS systems.

GENERAL NOTES

Radio frequency Remote

434 MHz for Europe, US, Canada;

NOTE: This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- —Increase the separation between the equipment and receiver.
- —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- —Consult the dealer or an experienced radio/TV technician for help.

NOTE: This device complies with CAN ICES-3 (B)/NMB-3(B)

- ◆ This product meets the applicable Innovation, Science and Economic Development Canada technical specifications. Ce produit repond aux specifications techniques applicables a l'innovation, Science et Developpement economique Canada.
- ◆ Canadian Compliance Statement

This device complies with Industry Canada license-exempt RSSs. Operation is subject to the following two conditions:

- 1) This device may not cause interference, and
- This device must accept any interference, including interference that may cause undesired operation of the device

Le present appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisee aux deux conditions suivantes :

- 1) l'appareil ne doit pas produire de brouillage;
- l'utilisateur de l'appareil doit accepter tout brouillage radioelectrique subi, meme si le brouillage est susceptible d'en compromettre le fonctionnement.

Batteries - Remote Handset:


3 x1.5V "AAA" (quality alkaline recommended)


4.5V - - - 100mA


NOTE: These remote handsets, receiver, wall switches, are not interchangeable with previous versions.

For all lighting/ignition instructions please refer to appliance manufacturer's instructions.

TX141 SERIES REMOTE HANDSET FEATURES








Remote Controller Model	434MHz Unidirectional	TX120	TX140	TX141
ON/ OFF		*	*	*
Childproof		*	*	*
Revo Home Compatible		*	*	*
Flame Height Adjustment			*	*
Standing Pilot*			*	
LCD				
Low Battery Indicator				
Second Burner				
Thermostat				
Timer				
Error Code Notification*				
Fan Speed			*	
Light Dimmer				
AUX ON/ OFF				
Fan Delay ON/ OFF				
Clock				
Daily Program Thermostat				
3 Independent Access Keys				

^{*}Disabled for Europe

CHILDPROOF



There's a slide switch can select lock or unlock.

Lock: The handset is rendered inoperable include the off function.

TURN OFF THE FIRE



Press OFF button, the receiver confirms transmission with an acoustic signal.

NOTE: There is a 3 second delay before the next ignition is possible.

MANUAL MODE (HANDSET)

NOTICE

Wiring of valve and receiver must be completed before starting ignition. Failure to do so could damage the electronics.

MISCELLANEOUS

Battery replacement

Battery replacement is recommended at the beginning of each heating season. Do not use metal tools to remove batteries. Using a metal tool could cause a short that may damage the receiver.

∆WARNING


When pilot ignition is confirmed, main flame valve turn on to maximum flame height.

Dexen Industries, Inc

9220 Norwalk Blvd Santa Fe Springs, CA 90670

Tel: +1 5626998490


TURN ON THE FIRE



Press ON button, the receiver confirms transmission with an acoustic signal.

- Main burner and rear burner turn on once pilot ignition is confirmed.
- Main gas goes Max flame height first, and will goes last flame height memory.

FLAME HEIGHT ADJUSTMENT



Handset
During the appliance flame on, briefly
pressing the or button changes the flame height.

NOTE: While pressing either button a Green indicator flashes. The receiver confirms transmission with an acoustic signal.