




Installation the Sensor

1. Install battery into sensor and tighten sensor top cap.
2. Check Sensor ID:
Each sensor should be assigned a unique identification number (ID).
3. Remove original valve cap and screw lock nut first then sensor onto valve stem.




4. Sensor onto valve stem



5. Screw lock nut back and using Wrenches to lock tight. This prevents sensor from

easy removing also in favor of sensor stationary.

Note: User may ignore this fixture, when causing inflation hassle concerns.



6. Continue to install all other sensors with the same procedure.

* **Note** : Clean up the valve stem surface before installation to ensure the conductivity between sensor and valve.

Federal Communication Commission Interference StatementThis equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.
FCC Caution:This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.