

USER MANUL

Table of contents

- **INTROUCTION**
- **SPECIFICATION**
- **INSTALLATION of REPEATER**

CE0678


1. Introduction

TP2-Repeater is device to relay TPM(Tire Pressure Monitoring) information from TPM Sensor, Which is installed in each tires, to Monitor through 433.92MHz of RF

2. Specification

- Frequency : 433.92MHz
- Output Power : EN300 200
- Operating temperature : -20°C ~85°C
- Operating voltage: DC 24V
- SIZE (L × H × W) : 116mm × 41mm × 103mm
- Weight : 137g

3. Installation of REPEATER



- Mounting of tire pressure sensor
- TP2-Repeater install in vehicle back wheel frame middle, so fixed it to NUT
- TP2-Repeater power line is connected to ignition of vehicle
- Plug in the Monitor to cigarette socket and turn on the key to ACC mode

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications (including the antennas) made to this device that are not expressly approved by the manufacturer may void the user's authority to operate the equipment.

Note : This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment under FCC rules.