

HunterDouglas 



PowerView® Hub
QUICK START GUIDE



When prompted, scan or type the
Accessory Setup Code below.



Table of Contents


 Kit Contents	3
 Connections	5
 Home Automation Integration	13
 Troubleshooting	15

KIT CONTENTS



- A. PowerView® Hub USB
- B. PowerView® Repeater
- C. USB Power Supply
- D. USB Power Supply Cable
- E. Ethernet Cable (Optional)

Note: Download the PowerView® App. The App is available for Apple® iOS and Android™ mobile devices. Apple is a trademark of Apple Inc., registered in the U.S. and other countries. Android is a trademark of Google Inc.



The PowerView® Hub interfaces with the PowerView® App to allow control of Hunter Douglas motorized window coverings from mobile devices. The Hub can also integrate with home automation systems via IP or cloud-to-cloud integration.

Note: Do not expose the PowerView Hub to direct sunlight.



Connect Hub to Internet connected wireless router.

Connect using an active Wi-Fi network:
 Open the PowerView® App on your mobile device and follow the on-screen instructions to properly connect to an active Wi-Fi network. The Hub will continue to blink AMBER, once the Hub has been connected to the home network.

Connect using an Ethernet cable (optional)

Connect the Ethernet cable from the Hub to an open LAN port on your router. The Hub will continue to blink AMBER, once it has been connected to the home network.

Note: If connecting the Hub to the home network via Ethernet, connect the Hub to the router, before connecting the Hub to power.



Connect power to Hub.

1. Connect one end of the USB power cable to the USB power supply.
2. Plug the USB power supply into an AC outlet or power strip.
3. Plug the other end of the USB power cable into the power port on the back of the Hub.

Note: During the boot-up process, the Hub's LED may turn off and on again. Once the Hub has completed the boot-up process, it will consistently blink AMBER. Do not interrupt the boot-up process by cutting power or pressing any buttons on the back panel of the Hub.



Pairing your Hub with an existing PowerView® Shade Network.

If you have already established a PowerView® Shade Network between a PowerView® Remote and PowerView shades, you should pair the Hub to the same network. To pair the Hub to the same network, open the PowerView® App and follow the prompts. The Hub LED will turn to solid BLUE, once the Hub has been paired to the PowerView Shade Network.



Distribute Repeater(s) as needed.

Note: Do not expose the PowerView® Repeater to direct sunlight.



Transfer your hub data (if needed).

If you have a Gen 1 Hub (above left) on your PowerView® Shade Network, follow in-app instructions to transfer Hub data to the new PowerView® Hub.



Test signal to Repeater(s).

Press and hold the **P** button on the back of the PowerView® Hub. The light on each Repeater should blink BLUE. If the Repeater does not blink BLUE, move the Repeater closer to the Hub or pair the Repeater to the correct PowerView® Shade Network. Other controls on the back of the Hub include the **R** button which power cycles the Hub and erases all Hub data when pressed and held for 6 seconds.



Configuring multiple Hubs on one PowerView® Network (Optional):

After a primary Hub has been paired to the PowerView® Network, each subsequent Hub paired to the same network will automatically be configured as a network access point. Please follow in-app instructions to install secondary Hubs.

Note: The LED of secondary Hubs will display solid GREEN, once paired to the PowerView Network.



You're ready to use the PowerView® App.

For more information about the setup and use of the PowerView® App, please visit:

hunterdouglas.com/operating-systems/powerview-motorization

PowerView® Motorization integrates with a variety of leading third-party control systems and devices.

To learn more about integration, please contact your local Hunter Douglas dealer or visit:

hunterdouglas.com/operating-systems/powerview-motorization

PowerView® LED Feedback	
Blinking AMBER	Hub is not connected to PowerView® Shade Network.
Solid AMBER	Hub is updating firmware from the Internet.
Solid BLUE	Connected, normal operation.
Flashing BLUE	Hub is Transmitting command(s) to the PowerView Shade Network.
Blank	Hub is not connected to power or Hub LED functionality has been switched off.
Solid GREEN	Hub is configured as a secondary Hub.

Problem: Cannot connect to the Hub with the PowerView® App.

- Check for blinking AMBER or solid BLUE on the front of the Hub. (See LED Feedback chart above.)
- Check the connection between the Hub and wireless router and that the router is operating properly.
- Check that the mobile device is on the same network as wireless router.

U.S. Radio Frequency FCC Compliance
 This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
 (1) This device may not cause harmful interference, and
 (2) This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, which means that it can cause limited interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio communications, you may be required to take one or more of the following measures:

- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/television technician for help.
- The user is authorized to operate the equipment only if it has been approved by the party responsible for compliance with FCC rules.*
- This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment and meets the FCC radio frequency (RF) Exposure Guidelines. This equipment should be installed and operated keeping the radiator at least 20cm or more away from person's body. RF Exposure requirements are met when installed in mobile equipment. This module cannot be installed in portable equipment. For more information, please refer to the following website: www.fcc.gov

Industry Canada

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (EIRP) is not more than that necessary for successful communication.

Le présent équipement radio est soumis aux règlements de l'Industrie Canada. Il ne peut fonctionner qu'avec une antenne du type et d'un gain approuvés par l'Industrie Canada. Afin de réduire les interférences radio, le type d'antenne et son gain doivent être choisis de façon à ce que la puissance isotrope rayonnée équivalente (PIRE) ne dépasse pas l'énergie nécessaire à une communication réussie.

Class B Digital Device Notice

This Class B digital apparatus complies with Canadian ICES-003, RSS-Gen and RSS-210.
 CAN ICES-3 (B)/NMB-3(B)
 This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment and meets RSS-102 of the IC radio frequency (RF) Exposure rules. This equipment should be installed and operated keeping the radiator at least 20cm or more away from person's body.

European Conformity

We, the undersigned,
 Hunter Douglas Window Fashions
 One Duelle Way, Bloomfield, CO 80020, USA
 Hunter Douglas Europe B.V.
 P.O. Box 1000, 3720 BA Zaanen, The Netherlands
 certify and declare under our sole responsibility that the PowerView® Hub conforms with the essential requirements of the EMC directive 2004/108/EC and RoHS directive 1999/5/EC.
 A copy of the original declaration of conformity may be found at www.hunterdouglas.com/RF-Certifications.

