### PowerView Scene Controller QuickStart Guide

Rev. 4



#### **Buttons**



1-press activation of favorite Scene



1-press activation of second favorite Scene



- activates Scene shown on display/Program mode/Program menu selections





- scroll buttons for cycling through Scene name list

#### **Configuring the Scene Controller**

You will need the PowerView Hub to be powered up and connected to a wireless router before configuring the Scene Controller.

- 1. Remove battery tabs to activate controller
- 2. Press and hold the button for 4 seconds until the buttons begin to flash.
- 3. Open the PowerView App on your mobile device.
- 4. Select the Add New Controller menu option in the PowerView App (under Hub Settings)
- 5. Follow the instructions on the app screen to configure the Scene Controller

The Scene Controller is now joined to the same PowerView Shade Network as the PowerView Hub.

• Use the PowerView App to configure which Scene names are displayed on the Scene Controller.

#### **Programming**

- 1. Press and hold Select for 4 seconds to put Scene Controller into Program mode
- 2. Use the buttons and select to navigate programming menu/options:
  - a. "Update?" scene controller communicates with Hub to get updated Scene name list information
  - b. "Join Hub?" used to join scene controller to Hub (initial setup only)
  - c. "Reset?" clears all programming from Scene Controller
  - d. "Exit" exits Program mode

#### Operation

- 1. To wake the Scene Controller, press any button key
- 2. Use the Scroll buttons to cycle through Scene name list that was configured using the PowerView App and stored in the PowerView Hub.
- 3. Press Select to activate the Scene displayed on the screen.
  - a. The Scene name displayed with blink until the command has been confirmed by the Hub.

Note: The last Scene activated is displayed on screen.

### **Battery Replacement:**



#### 1. Remove Cover.

Press notch to move cover slightly clockwise to release and remove cover.



#### 3. Replace Cover.

Position cover over slots. Press notch to move cover slightly counterclockwise to lock into position.



#### 2. Place Batteries.

Use two CR 2032 3V batteries. Slide one battery into each compartment and press into place to fully seat.



#### 4. Battery Removal

To remove batteries use a small screwdriver or fingernail to lift battery and remove from slot.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

#### **Industry Canada**

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Class B Digital Device Notice

This Class B digital apparatus complies with Canadian ICES-003, RSS-Gen and RSS-210.

#### Industrie Canada

Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie Canada. Dans le but de réduire les risques de brouillage radioélectrique à l'intention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotrope rayonnée équivalente (p.i.r.e.) ne dépasse pas l'intensité nécessaire à l'établissement d'une communication satisfaisante.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Appareil Numérique de la Classe B – Avis

Cet appareil numérique de la classe B est conforme à la norme NMB-003, CNR-Gen et CNR-210 du Canada.

CAN ICES-3 (B)/NMB-3(B)

#### **European Conformity**

We, the undersigned,

**Hunter Douglas Window Fashions** 

Address: One Duette Way, Broomfield, CO 80020, USA

Authorized representative in Europe:

Hunter Douglas Europe B.V.

Piekstraat 2, 3071 EL Rotterdam, The Netherlands

certify and declare under our sole responsibility that the PowerView<sup>™</sup> Scene Controller conforms with the essential requirements of the EMC directive 2004/108/EC and R&TTE directive 1999/5/EC.

A copy of the original declaration of conformity may be found at  $\underline{www.hunterdouglas.com/RFcertifications}.$ 



