Tenda

Quick Installation Guide


Outdoor Wi-Fi Camera CT6

Package contents

Appearance



Camera x 1







Power adapter x 1 Installation template x 1








Anchor x 3 (Height: 6.6 mm, Inner diameter:2.4 mm, Length:26.4 mm) (BA3 x 25 m

тenda

Quick installation guide x 1


Waterproof kit x 1



Please read this guide before you start with the quick setup for this camera upon the first use. For product or function details, please go to www.tendacn.com to download the user guide.

Adjust the monitoring angle

Loosen the orientation knob, adjust the orientation of the camera as required, then tighten the knob.



Install waterproof kit

Install the waterproof kit for the Ethernet port if the camera is installed outdoors.



When the Ethernet port of the camera is connected to an Ethernet cable, the waterproof installation steps are as follows. If not, you are also recommended to install the kit and wrap the end with waterproof tape.

1. Put the O-ring on the Ethernet port of the camera.

- 2. Pass the Ethernet cable through the fix nut, the waterproof ring and the waterproof jacket in proper order. Then connect it to the Ethernet port of the camera
- 3. Rotate to fix the waterproof jacket to the Ethernet port of the camera, insert the waterproof ring into the waterproof jacket and fasten the fix nut.



FAQ

Q1. What should I do if I failed to add the camera?

- A1. Try the following solutions:
 - Ensure that the router is connected to the internet successfully - The camera only supports 2.4 GHz Wi-Fi network. When adding the camera, you need to connect the smartphone to a 2.4 GHz Wi-Fi network
 - Do not hide the Wi-Fi network of the router when adding the camera (After adding the camera successfully, you can hide the Wi-Fi network).
 - Confirm whether the LED indicator of the camera blinks blue quickly. If not, please reset the camera and configure it again.
 - Reset method: Hold down the Reset button for about 5 seconds and release it when the LED indicator blinks blue quickly or you hear a prompt tone. The camera is reset successfully.

Screw x 3

- Q2. What should I do when the video preview is not smooth?
- A2. Try the following solutions:
- Check if the internet connection of the router is smooth.
- Place the router closer to the camera and adjust the antenna angle of the camera. - When previewing the video with cellular mobile data, make sure that the internet
- connection of the smartphone is smooth
- Auto, Fluent, and HD are supported for video preview. You can switch the video clarity according to the internet status.

Q3. How to store the video?

- A3. Try the following methods
- Method 1: Install the Micro SD card to the camera. The Micro SD card supports Alarm Recording and All Day Recording. By default, the recording mode is Alarm Recording, you can modify the recording mode according to the actual conditions.
 - Method: Run the TDSEE App, choose the camera on the Home page, then tap Settings $\langle \langle \overline{\bigcirc} \rangle$ in the upper right corner $\rangle \rightarrow$ **SD Card Recording Settings**, and choose the
- Method: Run the TDSEE App, choose the camera on the Home page, then tap Cloud in the lower left corner. You can enjoy free cloud storage service (7-days continuous detection recording) for 3 months upon the first activation.

Q4. How to get full-color monitoring video via the camera no matter in the daytime or at night?

- A4. Set Night Vision Mode of the camera to Full-color Mode.
- Method: Run the TDSEE App, choose the camera on the Home page, then tap Settings (🙆 in the upper right corner) \rightarrow Night Vision Mode, and choose Full-color Mode.

Declaration of Conformity

Hereby, SHENZHEN TENDA TECHNOLOGY CO., LTD. declares that the radio equipment
type CT6 is in compliance with Directive 2014/53/EU.
The full text of the EU declaration of conformity is available at the following internet
address: http://www.tendacn.com/en/service/download-cata-101.html
Operating Frequency:
2.4 GHz: EU/2412-2472MHz (CH1-CH13)
EIRP Power (Max.):
2.4 GHz: 17.5dBm
Software Version: V1.0.X

\bigwedge \square Caution:

Adapter Model: BN073-A12012E, BN073-A12012B Manufacture: SHENZHEN TENDA TECHNOLOGY CO., LTD. Input: 100-240V AC, 50/60Hz 0.4A Output: 12V DC, 1A =: DC Voltage

-10
—с
_C
Op
int
int
Ra
T٢
en
Τŀ
th
C
Ar
СО
Τŀ
or
O

corresponding mode. Method 2: Subscribe the Cloud Storage Service on TDSEE App.

Add the camera to TDSEE App

ν_{1}	Tips	1
	Before adding your camera, please ensure that the router is connected to the internet successfully and the filter function is disabled.	


1. Download the **TDSEE** App onto your mobile device by searching for **TDSEE** in the Google Play or App Store or by scanning the QR code.

Or





- 2. Power on the camera.
- The LED indicator lights solid red after the camera is powered on. When the LED indicator blinks blue guickly, the camera is waiting to connect to a 2.4 GHz Wi-Fi network.




- 3. Run the **TDSEE** App and follow the instructions to complete user registration. Enter the **Home** page, then tap **Add a device** or the upper right corner of the home page 🕂 .
- 4. Scan the QR code on the body of the camera, and follow the instructions in the App.

Install the device

Install the camera

The camera supports ceiling and wall installation.

(1) Please make sure the ceiling is strong enough to withstand three times the weight of the camera. (2) You may need a hammer drill, a drill bit, rubber hammer, a screwdriver, and a ladder for the installation.



Wall installation

Ceiling installation



FCC Statement

- This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules, These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause services, descent to an induce requires the interference to radio or television reception, which can be determined by turning the equipment of and the true to exervice the interference to radio or television reception, which can be determined by turning the equipment of and the true to exervice the interference to radio or television reception, which can be determined by turning the equipment of and the true to exervice the interference to radio or television reception, which can be determined by turning the equipment of and the true to exervice the interference to radio or television reception, which can be determined by turning the equipment of and the true to exervice the interference to radio or television reception, which can be determined by turning the equipment of and the true to exervice the interference to radio or television reception, which can be determined by turning the equipment of and the true to exervice the interference to radio or television reception, which can be determined by turning the equipment of and the true to exervice the interference the interference to exervice the inte on, the user is encouraged to try to correct the interference by one or more of the following measures -Reorient or relocate the receiving antenna.
- ncrease the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.
- peration is subject to the following two conditions: (1) this device may not cause harmful
- terference, and (2) this device must accept any interference received, including terference that may cause undesired operation.

adiation Exposure Statement

his device complies with FCC radiation exposure limits set forth for an uncontrolled vironment and it also complies with Part 15 of the FCC RF Rules. his equipment should be installed and operated with minimum distance 20cm between he device and your body.

aution!

- Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. his transmitter must not be co-located or operating in conjunction with any other antenna r transmitter
- Dperating frequency: 2412-2462MHz
- NOTE: (1) The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. (2) To avoid unnecessary radiation interference, it is recommended to use a shielded RJ45 cable.

·____ R ECYCLING

X

- T his product bears the selective sorting symbol for Waste electrical and electronic equipment (WEEE).
- T his means that this product must be handled pursuant to European directive 2012/19/EU in order to

- h e buys new electrical or electronic equipment.
- O perating Temperature: -30°C 60°C
- O perating Humidity: (10% 95%) RH, non-condensing



Technical Support

Shenzhen Tenda Technology Co., Ltd. 6-8 Floor, Tower E3, NO.1001, Zhongshanyuan Road, Nanshan District, Shenzhen, China. 518052 USA hotline: 1-800-570-5892 Toll Free: 7 x 24 hours Canada hotline: 1-888-998-8966 Toll Free: Mon - Fri 9 am - 6 pm PST Hong Kong hotline: 00852-81931998 Global hotline: +86 755-2765 7180 (China Time Zone) Website: www.tendacn.com E-mail: support@tenda.com.cr

Copyright

© 2021 Shenzhen Tenda Technology Co., Ltd. All rights reserved.

Tenda is a registered trademark legally held by Shenzhen Tenda Technology Co., Ltd. Other brand and product names mentioned herein are trademarks or registered trademarks of their respective holders. Specifications are subject to change without notice.