



DIGITAL IP NETWORK PUBLIC ADDRESS SYSTEM

---

# USER MANUAL

[For V3.0.8]

## Table of Content

Part I : Introduction.....	2
1.1 Product Overview.....	2
1.2 Detailed features and functionalities .....	2
1.3 Diagram of the topology of system.....	4
Part II: Installing The System .....	5
2.1 System Software Installation* .....	5
2.1.1. Server Software Installation .....	5
2.1.2 Workstation Software Installation .....	6
Part III: Server Software Operation .....	7
3.1 Basic Operation .....	7
3.2 Software Configuration* .....	7
3.3 General Operation .....	10
Part IV: Workstation Software Operation.....	15
4.1 Basic Operation .....	15
4.2 Software Configuration* .....	15
4.3 General Operation .....	16
Part V: MP3 Programming Tools .....	176
5.1 General Operation .....	176
Part VI: Hardware Installation and Operation.....	187
6.1 Main control room equipment installation.....	187
6.2 Terminal installation.....	187

**\* Mandatory for installer only, can be skipped by end user.**

# Part I: Introduction

## 1.1 Product Overview

The Digital IP Network Public Address System, powered by Ethernet technology, the world's most widely used networking technology, encapsulates audio signal into TCP/IP datagram and transports it over computer networks. The solution completely resolves the problems of the legacy public address systems such as bad sound quality, difficulty in maintenance, shortage of mutual communication, etc. In addition to the major features it delivers, it is also very easy to install –the system can be set up into fully functioning within one minute by merely plugging the terminals into network jacks.

The system not only carries out basis functions like class bell, multicasting by zones, speech, but also features advanced functions such as AOD (Audio on Demand).

The system supports CD quality playback (44.1k, 16 bit, stereo). The quality is sufficient for listening comprehension exercises in foreign language study or examination. Students can take great advantage of the crystal-clear sound.

## 1.2 Detailed features and functionalities

### - **Covering all the basic functions provided by legacy broadcasting systems.**

Automated class bell, music playback, speech, notification broadcasting and radio program forwarding.

### - **Ethernet infrastructure**

Taking advantage of the ubiquity of the Ethernet, cost-effective and high quality guaranteed.

### - **Online speech**

Sending the speech to the broadcasting system by any online PC (must be on the campus network). The speech can be broadcasted or multicasted to designated zones.

### - **AOD (Audio On Demand)**

The operator can play any programs stored on the audio server by controlling the broadcasting terminal using remote.

**- Multiple media sources**

Cassettes, CD, radio, Microphones... programs from various sources can be input directly into the audio server. With real-time compression and fast forwarding, the programs can be heard from any corner across the campus in no time.


**- Customized playlist**

Each terminal has its uniquely assigned IP address, making it possible that it can individually receive the programs preconfigured on the audio server. Operators can save programs on the server and setup the playlist, then the program can be play back automatically at the preset time and in the order of the playlist.

**- Multicasting**

The system allows for multicasting service, with which programs can be delivered to designated groups manually divided by the operator. The volume and the on-playing program on the terminal can be remotely controlled by the operation platform installed on the server-side.

### 1.3 Diagram of the topology of system



## Part II: Installing The System

### 2.1 System Software Installation\*

The software application of IP Network Public Address System consists of server software and workstation software. The server software will automatically run demo version with three (3) preset users should no softdog is detected; it will become a full version when softdog is plugged in.



Softdog (Drive-free)


#### 2.1.1. Server Software Installation

Caveat: Running firewall software may affect the normal operation of IP Network Public Address System. Please make sure the firewall software is disabled prior to installing/executing the software (including Windows Firewall).

##### 1) Brief installation procedure


- Install the Windows XP (Server or Professional version recommended) on the computer to be installed with the server software.
- Ensure that the soundcard and network card are installed and functional on the computer to be installed with the server software.
- In the TCP/IP properties of the network card setting, assign static IP (e.g., 192.168.0.6), mask 255.255.255.0, and gateway (e.g., 192.168.0.1).

Note: Server must use static IP address, DHCP is not available to the server software.



- Insert the system installation CD-ROM. execute CD:\Setup\Setup...exe.

- Keep clicking “Next” through the installation until it is completed. The shortcut icon will be created on the desktop.



- Go back to CD:\ folder. Copy “MP3 Files(Demo)”, and paste the content in the folder to the local harddisk (e.g., D:\ MP3 Files)
- Take the CD-ROM out. The installation for the server software is now completed. Please refer to Part III for server software configuration procedure.

## 2.1.2 Workstation Software Installation

### 1) Brief installation procedure

- Check whether the workstation computer has Windows2000/XP properly installed. The workstation software does NOT support Windows98/Me.
- Ensure that the workstation computer has sound card and network card properly installed.
- DHCP can be configured for TCP/IP properties in network card setting.




- Insert the system installation CD-ROM. execute CD:\Setup\Setup...exe, then click on “Next” to the next screen. Uncheck “Digital IP Network Public Address System Server” and leave the “Digital IP Network Public Address System Workstation” checked. Keep clicking “Next” until the installation is completed. The shortcut icon will be created on the desktop. Please refer to Part IV for workstation software configuration procedure.

# Part III: Server Software Operation

## 3.1 Basic Operation

System server is the core of the Digital IP Network Public Address System.




Main operation window

## 3.2 Software Configuration\*


Normally the software configuration is only required to be done once after the initial server installation to set the proper parameters and does not need to be reconfigured during the normal operation. The following steps reflect a typical configuration procedure done by the installer. The system administrator can also refer to these steps for reference.

- 1) Select “Program Management” window, which is shown in the figure below. Click on “folder” button to pop out the dialog box. Then specify the path to the folder where all the media are stored (e.g., D:\mp3 files, which has been created in section 2.1).






Then press “Search” button. The system will establish the media list automatically.




2) Select “Terminal Setting” window, as shown in the figure below. Specify the actual number of terminals, then press “update” button. The software will restart.




After the software restarts, go back to the “Terminal Setting”, and double-click any line to pop up the “Edit” dialog box. Name the terminal according to its location or role.

3) In the right area of the “Terminal Setting” window is the “Group” box where groups can be added, renamed or deleted.




To assign certain terminals to specific group, select them from the “default group” and drag them to the desired group (e.g. Office)




4) Select “Basic Setting” window as shown in the following figure.

Sniffers: Assign a terminal as the monitor to monitor the system operation in the “Running Status” window.

Timing automatically switches computer: to automatically turn off the computer at night and turn on in the morning.



Workstation Account is to manage the accounts for the users who will use the workstation. User needs valid account and password to log on to the server with the workstation.



### 3.3 General Operation

The digital IP Network Public Address System performs the following major functionalities in its day-to-day use.

**Timing ring(Managed by Server)**— The most basic functionality. It allows the music or bell to be played automatically at specified time, for instance, playing morning calls every weekday at 6:30 AM.

**Timing program(Managed by workstation)**— Activated and specified by the workstation, automatically and in turn play multiple selected audio files at assigned time. This functionality is similar to the timing school bell, except timing school bell is managed by the server, whereas this is managed by the remote workstation.

**Timing broadcast**— Automatically turn on the machine at scheduled time and capture /stream the audio to the network. Best for broadcasting live programs from external source such as news in the radio.


**Live broadcast**— Stream the audio program or live speech/announcement to specified location.

**Audio On Demand(AOD)**— Select and play audio files stored on the server via the remote control and its LCD. Every terminal can play separate audio file without interfering on another.


**Running Status**— The running status of all the online terminals and ongoing tasks can be displayed in the system and also be modified or adjusted.

#### 1) Timing ring(Manage by Server)


Click on “Timing ring” and a window looks like the figure below is presented. Press “New scheme” to create a new scheme, such as “day light saving time”. To make the scheme current, press “Exec scheme”.



On the right side of the window, press “Add Task” to pop up a dialog as shown in the following figure. Check all the desired target terminals; name the task, set the time, and assign the audio file for the task.




Click on “Time Setting” to pop up the dialog box. The duration can be left unspecified. In this case, the playing length in time will be the length of the audio file per se. Otherwise, if the duration specified is longer than the actual length of the audio file, the file will be replayed over and over until the specified duration is reached. If the duration specified is shorter than the actual audio file, the playing will be stopped once the time is up. The stop date can also be left unspecified.



## 2) Timing program(Manage by workstation)

It is supported to check any Program Timer tasks on the server; however, the major work regarding setting and editing tasks should be performed on the workstation. On the server, click on “Timing program” to open the corresponding window, which can be seen in the following figure. To check the detailed information, double-click on any line. Like the School Bell Timer, the Program Timer can also run automatically at the scheduled time. It can also be manually triggered if needed.




## 3) Timing broadcast

Automatically turn on the machine (or start the task) at scheduled time and capture /stream the audio to the network. Best for broadcasting live programs from external source such as news in the radio. The parameters for the soundcard and recording (such as the source, volume, etc) should be configured under the “Live broadcast” window which will be detailed in the following section. The operation process is similar to that for the School Bell Timer

## 4) Live broadcast

This functionality allows the user to capture the live sound with the soundcard and stream it to the network in real-time. The soundcard performs A/D transferring. A variety of sources are supported, such as the microphone, cassette, CD, etc.




### Procedure of Live broadcast (Support five soundcard broadcast simultaneous)

#### a). Specify the recording device.

The soundcard has the ability to mix audio from multiple channels (MIC, Line-in)

into one output channel; it can also accept only one channel. Specifying the recording device is actually to specify the input (Stereo Mixer or single input channel)

Usually, Stereo Mix is recommended to allow all the input signals to be transmitted to the terminals. Note: Different soundcards have different terms for “Stereo Mix”. For example, while most of the integrated soundcards use “Stereo Mix” denote the function, the Creative’s SB-Live soundcard uses “The sound you can hear” to indicate the same function.




The recording volume shouldn’t be set too loud for recording to prevent the sound distortion. It is recommended to set it to the middle position.

**b). Specify the targeted terminals, and then press “Start broadcast”.**


### 5) Audio On Demand(AOD)

The audio files users can order are stored on the hard drive of the server. The menu that can be seen in the “Program Management” is also the one that will be displayed on the terminals LCD. Users can either manage these audio files on the server with the “Program Management”, or add or delete files from the workstation. Please refer to Part VI for terminal operation.



### 6)Running Status


The “Running Status” window lists all the online terminals and their current states. To see the detail for any specific terminal (except for the terminal with ongoing AOD task, which can not be monitored), double-click the line where it is in. To monitor the sound being played by any specific terminal, single-click the line where it is in and then press “Monitor Terminal”.



# Part IV: Workstation Software Operation

## 4.1 Basic Operation



Users use workstation software to remotely log on the server via IP network (LAN, WAN) and manage the server. Workstation software is mostly used by users to perform real-time capturing, produce the audio files and schedule tasks. The figure below is the screenshot of the workstation software.



## 4.2 Software Configuration\*

The workstation configuration is easier compared to that of the server. Basically, user only needs to configure the server’s IP address on the workstation. Procedure:

After executing the workstation software, user is prompted with a log in window that looks like the left figure below. Click on server address and then input the server’s IP address (e.g., 192.168.0.6) in the textbox preceded by “server IP address” radio button. Also fill out the username and password textboxes (**default username/password is admin/admin**). After all the fields are filled out, press Login button. If all the information is correct, the workstation will now sign in the server.






## 4. 3 General Operation

### 1) Live broadcast

The process of this functionality is similar to that for the server. For details, please refer to Section 3.3 in Part III. Only the different part is detailed hereunder.



Advanced Options: Since workstation can be used on both LAN and WAN, and normally LAN provides much more sufficient bandwidth than WAN does, for the workstation to perform better on the WAN, user can set the Advanced Options according to the specific network environment.

### 2) Timing progame

Program Timer enables automatic playback of multiple selected audio files at assigned time.

First, press “Add Task” button to activate the task wizard. Fill in the basic information at the first step, then click “Next”. In the next window, specify targeted terminals, then click “Next”. In the last window, specify the program playlist for this task. To complete, press “Finish” button.

### 3) Program Management

The Program Management on the workstation is to remotely manage the media stored on the server. As with the server, user can also use workstation to create folder, add, rename or delete audio files. To upload files to the server, click on “Upload” button. To download to the workstation, click “Download”.



# Part VI: Hardware Installation and Operation

## 6.1 Main control room equipment installation

Main control room is the center of the broadcasting system, particularly the system server may need 24-hour continuous operation, the design must conform to the following several principles:

1. In order to minimize the interference system, main control room should choose to stay away from electromagnetic waves;
2. Main control room power supply into line with the standard requirements of a good grounding to earth, grounding resistance should be less than 4 ohms;
3. Main control room should be chosen to the second floor or above floors;
4. Main control room suggested the installation of air-conditioning (temperature of 18-28 ° C, relative humidity of 40% -70%);
5. Recommendations main control room installed anti-static floor;
6. Main control room of decorative materials should use non-burning material or difficult combustion materials;



Control room sample

## 6.2 Terminal installation

According to different applications, digital broadcasting terminals into a variety of models, mixed use in engineering. Please read carefully terminals incidental "Terminal Manual".

Modulation:FM

RF Power: MAX 5.0W

Channel	Frequency
0	461.60
1	461.80
2	462.00
3	463.20
4	463.40
5	463.60
6	463.80
7	464.00
8	464.20
9	464.40
A	464.60
B	464.80
C	466.20
D	466.40
E	466.60
F	466.80

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Note: The device has to be kept a distance of 50cm from human body and its has no ad-hoc function.