



Suga Electronics Limited

802.11b/g/n(1T1R) STA WIFI module

User Manual

Model: SWN80MA-6

Version: 1.1

Date: Apr 20, 2017

Contents

1. FCC & ISEDC Statement	2
1.1. FCC Caution.....	2
1.2. FCC Radiation Exposure Statement	2
1.3. ISEDC Warning	3
2. Hardware Installation	4
2.1. Hardware Installation Procedures	4
3. Software Installation.....	4
3.1. STA Windows driver installation.....	4
4. Example.....	5
4.1. Router setting.....	5
4.2. Associate SWN80MA-6 with the router.....	5
5. Device Labeling	6
6. Disclaimer	7



Suga Electronics Limited

1. FCC & ISEDC Statement

1.1. FCC Caution

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

1.2. FCC Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.



Suga Electronics Limited

1.3. ISEDC Warning

RSS (Category I Equipment):

This device complies with Innovation, Science, and Economic Development Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference, and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence.

L'exploitation est autorisée aux deux conditions suivantes:

- (1) l'appareil n'edoit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada.

To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.

Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie Canada. Dans le but de réduire les risques de brouillage radioélectrique à l'intention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotrope rayonnée équivalente (p.i.r.e.) ne dépasse pas l'intensité nécessaire à l'établissement d'une communication satisfaisante.

ISEDC Radiation Exposure Warning


This equipment complies with ISEDC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Cet appareil est conforme aux limites d'exposition aux rayonnements définies pour un environnement non contrôlé. Cet équipement doit être installé et utilisé à distance minimum de 20cm entre le radiateur et votre corps.

2. Hardware Installation

2.1. Hardware Installation Procedures

- 2.1.1. Plug SWN80MA-6 module into the USB port of the PC, shown as below.



3. Software Installation

3.1. STA Windows driver installation

- 3.1.1. Install SWN80MA-6 STA window's driver and Realtek USB wireless LAN utility into the PC, shown as below:

DATA	2016/9/7 14:03
EAP	2016/9/7 14:03
IM	2016/9/7 14:03
Release notes	2016/9/7 14:03
RTWLANU_Driver	2016/9/7 14:03
_Setup.dll	2008/5/10 13:27
data1.cab	2014/5/29 16:39
data1.hdr	2014/5/29 16:39
data2.cab	2014/5/29 16:39
Install.bat	2011/11/7 11:32
IsConfig.ini	2017/4/12 11:49
ISLangUni.ini	2013/4/26 11:38
ISSetup.dll	2008/9/11 18:26
layout.bin	2014/5/29 16:39
Setup.exe	2013/10/18 16:55
setup.ico	2011/11/7 11:32
Setup.ini	2014/5/29 16:39
setup.inx	2014/5/29 16:39
setup.iss	2014/5/29 16:53
UnInstall.bat	2011/11/7 11:32
Uninstall.iss	2011/11/7 11:32



Suga Electronics Limited

4. Example: Associate SWN80MA-6 module with a router for surfing the internet

4.1. Router setting

Connect the router to internet by WAN

SSID: Buffalo-G-DDC8

Mode: b/g/n mixed mode

Bandwidth: 20/40MHz Auto

Encryption: WPAPSK/AES

Password: odm0123456789

4.2. Associate SWN80MA-6 with the router

Open the “Realtek USB wireless LAN utility” in the desktop, the icon shown as below:





Suga Electronics Limited

Click the option “SSID”, then double click “Buffalo-G-DCD8”, shown as below:

1F MES	1	AES	WPA2 PSK	26%
Chairman's Office	1	AES	WPA PSK/WPA2 PSK	44%
DQA3	1	AES	WPA PSK/WPA2 PSK	64%
Suga 2F	1	TKIP/AES	WPA PSK/WPA2 PSK	48%
Buffalo-G-DCD8	2	AES	WPA2 PSK	100%
ChinaNet-5zQL	6	TKIP/AES	WPA PSK/WPA2 PSK	48%
Suga 2F	6	TKIP/AES	WPA PSK/WPA2 PSK	48%
Suga 2F	11	TKIP/AES	WPA PSK/WPA2 PSK	24%
Suga 2F	11	TKIP/AES	WPA PSK/WPA2 PSK	56%
Suga Customers	11	AES	WPA PSK/WPA2 PSK	26%

Enter the password “odm0123456789”, then click“OK”.

Several seconds later, SWN80MA-6 module will connect to the router Buffalo-G-DCD8 successfully, then you can enjoy your internet surfing.

5. Device Labeling

The host device containing this module must either:

- (1). Make the module label visible so that the FCC/IC ID is visible in the end construction.
- (2). Label the end product with the FCC ID and IC ID of the module. For example: “Contain FCC ID: [VZFSWN80MA6](#)” and “Contain IC: [10609A-SWN80MA6](#)”.



Suga Electronics Limited

6. Disclaimer

Suga Electronics Limited assumes no responsibility for errors or omissions in the materials available on this Document.

THESE MATERIALS AND INFORMATION ARE PROVIDED “AS IS” WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED , INCLUDING BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR NON-INFRINGEMENT.

SugaE uses reasonable efforts to include accurate and up-to-date information on this Document; it does not, however, make any representations as to its accuracy or completeness of the information, text, graphics, links or other items contained within these materials. Your use of this Document is at your own responsibility. SugaE, its suppliers, and other parties involved in creating and delivering this Document’s contents shall not be liable for any special, indirect, incidental, or consequential damages, including without limitation, lost revenues or lost profits.