

verykool I117

User Manual



Table of Contents

Legal Information	1
Important Notice	3
Safety Precaution / Measures	3
Getting Started	5
Packing Contents	5
Installing SIM, Battery and Attaching other Accessories	5
SIM Card, Memory Card & Battery Installation	5
Connecting Hands-free Kit (Ref Figure 2)	6
Connecting the charger/Charging the Battery (Ref Figure 3)	7
Phone Keypad Layout (Figure 4)	8
Left Soft Key	9
Right Soft Key	9
Dial Key	9
End Key.....	9
OK Key.....	9
Up and Down Direction Keys	9
Left and Right Direction Keys	9
0-9 Keys.....	10

* & # Key	10
Important Phone Icons	10
Signal Strength Icon	10
Battery Meter Icon	11
Keypad Lock Icon	11
Basic Functions	12
Make a Call	12
Making a Call Using Call history	12
Answering a Call	13
Call Option.....	13
Menu Layout.....	15
Messages	16
SMS	16
MMS	18
Chat.....	18
Voicemail server	18
Broadcast message	19
Fun & Games.....	19
Games	19
STK.....	19
Call history.....	19

Call history	20
Call setup	20
Services.....	22
WAP.....	22
Data account.....	23
Organizer.....	23
Calendar.....	24
To do list	24
Alarm.....	25
World clock.....	25
Calculator	25
Stopwatch	25
Unit converter	25
Currency converter	26
Phonebook	26
Quick search	26
Search contact	27
Add new contact.....	28
Copy all.....	28
Delete	28
Caller groups	28

Extra numbers	28
Phonebook settings.....	29
Speed dial	30
Multimedia	30
Image viewer	30
Audio player.....	31
Sound recorder	32
FM radio	32
Schedule FM record.....	33
File manager	34
Settings.....	34
User profiles	35
Phone setup.....	36
Display setup	37
Call setup	38
Network setup.....	38
Security setup.....	38
Restore factory settings.....	40

Legal Information

All rights reserved. Reproduction, transfer, distribution or storage of part or all of the contents in this document in any form without the prior written permission of verykool is prohibited.

verykool operates on a policy of continuous development. verykool reserves the right to make changes and improvements to any of the products described in this document without prior notice.

Under no circumstances shall verykool be responsible for any loss of data or income or any special, incidental, consequential or indirect damages howsoever caused.

The contents of this document are provided "as it is". Except as required by applicable law, no warranties of any kind, either expressed or implied, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose, are made in relation to the accuracy, reliability or contents of this document. verykool reserves the right to revise this document or withdraw it at any time without prior notice.

The availability of particular products may vary by region. Please check with verykool Executive.

Important Notice

Safety Precaution / Measures

Road safety

The use of a mobile phone while driving is illegal and should be avoided at all costs. If you need to make or receive an urgent call, move your vehicle to the side of the road and allow it to come to a complete stop before using your phone.

Switch off in potentially hazardous environments

Wireless phones can interfere with the smooth functioning of the aircrafts, petrol pumps, medical equipment in hospitals, and near blasting sites. It is extremely important that you do not use your mobile phones whilst in any of the above environments.

Additionally, do remember to deactivate any alarms that you may have set before you turn off the I117 before an aircraft takeoff.

Emergency Calls

In case of an accident or an emergency, dial 911 (Police) from your phone. Being emergency numbers, these are toll free and can be reached even from areas where the network signal strength is very poor.

Battery Use

First time charging must be done using the regular charger and not using the USB cable.

During the first 3-4 charge sessions, charge the battery until it has been fully charged according to the battery level indicator. This ensures higher battery backup and extends the battery life.

Avoid partial charging. Wait for the battery to discharge completely before charging it again.

Charging through the USB cable should be reserved during an emergency.

Use the device in vibrating mode only on rare occasions.

Getting Started

Packing Contents

Before using verykool I117 mobile phone, carefully remove the contents from the shipping carton and check for any damages or missing contents. In case you find any, contact your Authorized Distributor or shipping agent immediately. The standard packing contents are as follows:

- Battery
- Charger
- Hands free Kit
- User Manual
- Service Guide

Installing SIM, Battery and Attaching other Accessories

SIM Card, Memory Card & Battery Installation

Always turn off the phone and detach the charger when you insert or remove a SIM card or battery from the phone.

1. Remove the battery cover by pulling it.
2. Slide the SIM Card into its holder. Make sure that metal contacts of the SIM Card are facing down, and the cut off corner is correctly aligned.

3. Place the battery in the back of the phone with the label side up and the connectors facing each other.
4. Place the battery cover and push it into place.

Connecting Hands-free Kit (Ref Figure 2)

You are provided with a hands-free earpiece set with your phone. The same can be used to listen to your mp3 songs and listen and speak while on a call. To connect the hands-free earpiece, simply connect the connector into the connecting socket as shown in the figure. When properly connected, the phone will display a message 'Earphone plugged in' with an icon displayed on top of the screen.

NOTE: Only use verykool specified accessories.



Figure-2

Connecting the charger/Charging the Battery (Ref Figure 3)

1. Plug the charger's transformer into a standard AC outlet.
2. Insert the charger's output plug into the phone's connecting socket as shown in figure-3.

NOTE: The battery icon/charging icon would appear on the screen while charging.




Figure-3

Phone Keypad Layout (Figure 4)




Figure-4

Left Soft Key

Performs functions in lower left display.

Right Soft Key

Performs functions in lower right display.

Dial Key

- Make calls
- Answer calls
- Press when idle to see the call history.

End Key

- End or reject calls
- Press and hold this key to turn phone on/off.

OK Key

In standby mode, press OK key to open main menu.

Up and Down Direction Keys

- Scroll to select options
- In standby mode press to open shortcut applications.
- In edit message status, press to select the required word.
- In function menu, scroll to open desired function.

Left and Right Direction Keys

- Scroll to select options
- In standby mode press to open shortcut applications

- In edit message status, press to select the required word.

0-9 Keys

In standby mode, press number keys to input dialing number. In standby mode, press and hold 1 key to set Voicemail number at the first time. Once you have set, press and hold 1 key to call the number. Press and hold 2-9 key to directly call the number set before in the speed dial list. In edit status, press to input numbers, characters. In edit mode, except input number, press 0 key to input space. In functional menu, press numbers to speed select submenu items.

*** & # Key**

Functions vary in different situations or function menus: On Input Screen, press "*" for symbols. In standby and dial mode, press and hold "*" to input + for an international call. On Input Screen, press "#" to switch between different inputting methods. In standby mode, press and hold # key to switch between silent mode and previous mode. Press Left soft key and hold * key to lock/unlock the keypad.


Important Phone Icons

Signal Strength Icon

The Signal Strength Icon is seen on the top leftmost corner of the screen. The icon helps you to identify the strength of the network; the

phone has latched on to, at that particular instance. It has a maximum of 4 bars with a minimum as no bar. 4 bars signify strongest network strength and subsequently minimizes with each diminishing bar. No bar signifies least or no network strength.

Battery Meter Icon

The Battery Meter Icon  is seen on top rightmost corner of the screen. The icon signifies the battery strength available at that instance.

NOTE: At very low battery levels, the phone will prompt 'Low Battery' message on the screen.

Keypad Lock Icon

The Keypad Lock Icon is seen on top of the screen at various positions depending on the number of icons displayed. A closed lock signifies that the keypad is locked. You can unlock the keypad by pressing Left soft key and holding * key on the phone. Similarly for locking the keypad, press Left soft key and hold * key.

Basic Functions

Make a Call

To make a call, unlock the keypad if locked, enter the desired phone number and press the Dial key.

NOTE: Your service provider programs one or more emergency phone numbers, such as 911, that you can call under any circumstance, even when your phone is locked or the SIM card is not inserted. Check with your service provider, as emergency numbers vary by country. Your phone may not work in all locations, and sometimes an emergency call cannot be placed due to network, environmental or interference issues.

Making a Call Using Call history

All dialled and incoming numbers are saved in call history and categorized into Missed Calls, Received Calls and Dialed Calls. To check the history, please follow these steps:

In standby mode, press OK key and select Call history to view. Use the scroll keys to scroll among Missed Calls, Received Calls and Dialed Calls.

Answering a Call

- To receive an incoming call, select 'Answer' or receive it directly by pressing the Dial key.
- If headset is available, user can choose headset keys to answer the call.

Call Option

The verykool I117 phone offers multiple functions during a call. During a call, the following functions can be actualized if you operate according to the instructions on the screen. Press up and down direction keys to choose the function you want and press select key to enter.

- Hold single call: To hold an active call.
- End single call: End the present active call only.
- New call: To make a new call.
- Phonebook: To explore the Phonebook for phone numbers.
- Messages: To explore Messages menu.
- Sound recorder: To record a conversation between the active members of the conversation.
- Mute: Turn on/off the Microphone during an active call.

- DTMF (Dual-tone Multi-frequency): You can choose on/off; which is to send dual-tone multi-frequency sound. This can offer dialing to the telephone numbers with extensions or IVR systems installed for menu driven options.

NOTE: This feature is network dependent.

Menu Layout

Messages

- SMS
- MMS
- Chat
- Voicemail server
- Broadcast message

Fun & Games

- Games

STK

Call history

- Call history
- Call setup

Services

- WAP
- Data account

Organizer

- Calendar
- To do list
- Alarm
- World clock
- Calculator
- Stopwatch
- Unit converter
- Currency converter

Phonebook

- Quick search
- Search contact
- Add new contact

- Copy all
- Delete
- Caller groups
- Extra numbers
- Phonebook settings
- Speed dial

Multimedia

- Image viewer
- Audio player
- Sound recorder
- FM radio
- Schedule FM record
- File manager

Settings

- User profiles
- Phone setup
- Display setup
- Call setup
- Network setup
- Security setup
- Restore factory settings

Messages

Your phone supports various messaging services. You can create, send, receive, edit and organize text messages.

SMS

Under SMS, the phone has the following folders listed.

- **Write message:** Input content by selecting preferred input method.
- **Inbox:** This folder stores all the received messages.
- **Outbox:** This folder contains all the messages sent from your phone.
- **Templates:** Templates stores 10 preloaded/pre-written text messages for ready usage. You can edit the templates according to your wish and also store the messages that you send frequently.
- **SMS settings:** SMS settings store all the different settings responsible for sending and receiving messages.
 - **Profile settings:** It contains modes which include Profile name, Service Centre address, Validity period and Message type.
 - **Common settings:** These settings include the following - Delivery report, Reply path.
 - **Memory status:** Memory status gives you the information about the storage status of the phone memory as well as the SIM memory.
 - **Preferred storage:** Let you select the default storage

location of the messages between Phone and SIM.

MMS

The phone has the capability to support Multimedia Services. You can send and receive multimedia files by using this feature, provided, you have this service activated on your SIM card. It has the following folders listed:

- **Write Message**
- **Inbox**
- **Outbox**
- **Drafts**
- **Templates**
- **MMS settings**

Chat

Chat enables you to enter 2 different user's default settings (Chat room 1 and Chat room 2) to enable sending and receiving the messages. Chat option enables you to see the complete conversation on a single window.

Voicemail server

The Voicemail server is an interactive system for storing, processing and reproducing verbal messages through a voicemail server. The service is operator dependant and the settings are provided by the operator upon activating the service on the SIM card.

Broadcast message

Your phone is capable to receive and store broadcast messages. You can set the receive mode to ON/OFF. 'Read message' folder stores the received messages.

Fun & Games

Games

- **Copter**
- **Games settings:** These settings enable you to vary from settings in background music and sound effect to ON/OFF, allow you to put the vibration mode to ON/OFF and allows you to increase/decrease the volume levels.

STK

STK stands for SIM Tool Kit. This service is provided by the network provider and is used to initiate various Value Added Services, provided the SIM and the operator support this feature.

Call history

Call history

You can check all Calls/SMS related information under Call history menu. Call history menu has details for:

- **Missed calls**
- **Dialled calls**
- **Received calls**
- **Delete call logs**
- **Call timers**
- **Call cost**
- **SMS counter**
- **GPRS counter**

You can also delete call lists by selecting "Delete call logs" option.

Call setup

- **Caller ID** – You can select to hide, send ID or set by network.
- **Call waiting** - You can activate this function or deactivate it, and can also view the current settings via query.
- **Call divert** - You can set to divert the incoming calls in different conditions.
- **Call barring** - In order to activate this service, it requires the services provided by the network service provider. When you change barring password, you need to input the old password.

- **Line switching** – To switch between line1 and line2.
- **Closed user group** - Several numbers can be listed to form a user group. Use this option to specify restrictions to the communication of a user group.
- **Advance settings**
 - **Black list** - Set whether to activate the incoming call filter, and edit the blacklist numbers.
 - **White list** - Set whether to activate the incoming call filter, and edit the white list numbers.
 - **Auto redial** - You can select to redial the number automatically when a call is not connected.
 - **Call time display** - After setting this function on, you can view the call time displayed on the screen.
 - **Call time reminder** - After setting this function to 'on', it will offer a warning tone towards the single or periodic setting as your own during the call process, so you will be reminded of the call time at periodic intervals during a call.

- **Auto quick end** - Can be set to open or close the function, duration of time 1-9999 seconds.

Services

WAP

WAP or Wireless Application Protocol browser provides all the basic services of a computer based web browser but is simplified to operate within the restrictions of a mobile phone. The WAP Browser has the following options:

- **Homepage:** Homepage allows you to enter the default URL on the phone. This will enable you to go to the same page every time you access the homepage.
- **Bookmarks:** Bookmarks enables you to mark a place in an electronic document or a pointer (primarily to an internet URL) in an Internet web browser.
- **Recent pages:** Recent pages stores the list of URLs which have been recently visited by you on the WAP browser.
- **Offline pages:** Offline pages stores the list of URLs which you have saved.

- **Input address:** Enter the desired address (URL) of the website or webpage in this column.
- **Service inbox:** Service inbox receives and stores URLs through text messages from the operator. You can read them and accept to go to the web page and browse.
- **Settings:** You can vary the following settings:
 - **Select SIM**
 - **Edit profile**
 - **Browser options**
 - **Service message settings**
 - **Clear cache**
 - **Clear cookies**
 - **Trusted certificates**

Data account

Data account contains two types of accounts used to establish GSM/GPRS connections for WAP, MMS and www browsing.

- **GSM data**
- **GPRS**

NOTE: Select the appropriate setting from the list for using a particular feature depending on the availability of the operator services.

Organizer

Calendar

You can use the calendar to keep track of important meetings. After entering the calendar function menu you can select year, month and date using direction keys. On a selected date you can select to view:

- **View:** If there is a special background color on a date it means there is some event on that day. You can also view any Note/Remark mentioned by you for an event stored by you previously.
- **View all:** View all the events.
- **Add event:** When you add a new event, you can do the following:
 - Input event duration time.
 - Add a description for that event.
 - Set alarms on/off.
- **Delete event**
- **Jump to date:** Input a date, and then press OK to go to a specific date for entry/edit/viewing of task for that date.
- **Go to weekly/monthly view:** Select this option to view events in weekly/monthly format.

To do list

You can add tasks like events.

Alarm

The Alarm can be set to ring at a specific time on several days. There are five different default alarms. You can set these alarms to wake you up at different time on specific day(s) of a week. The alarm can use radio as an alarm tone also.

World clock

World clock can be used to know the time in various cities across the world. You can see a world map and immediate time in those cities using world clock. Enter world clock to view a particular city's time using the direction keys.

Calculator

Keep your calculations on your finger tips with the calculator.

Stopwatch

The phone comes with 2 types of Stopwatch.

- **Typical stopwatch**
- **nWay stopwatch**

Now, burn the track while you keep every move traced and counted.

Unit converter

Use this feature for the converted units of weight, length, volume, temperature, velocity and surface.

Currency converter

Use this feature for the exchange rate conversion.

Phonebook

Quick search

Quick search allows you to quickly search an entry in the Phonebook by entering the key letters or words of the name. After finding the desired number the user gets the following options:

- **Dial:** Selecting the option will dial the number found by quick search.
- **Send SMS:** Selecting this option will enable the user to send an SMS on the number selected.
- **Send MMS:** Send Number allows the user to send the selected entry's details to another recipient as a multimedia message.
- **View:** View option gives you the details of the number selected.
- **Edit:** Edit option gives you the option to edit the details of the selected number. The details include Name, number, Home number etc.

- **Delete:** The option allows you to delete the selected entry.
- **Copy:** The option allows you to copy the entry selected entry to the phone or to the SIM card depending on where the entry was stored before.
- **Move:** The option allows you to move the entry from Phone to SIM or from SIM to phone depending on where the entry was selected from. The moving entry will be automatically deleted from the last storage device.
- **Send vCard:** This option is same as 'Send Business Card'. It will enable you to send a business card of the selected entry as an SMS or MMS.
- **Send to Blacklist:** This option is used to blacklist the selected entry. Once blacklisted, your phone will reject all calls from those numbers that before they reach the phone.
- **Send to Whitelist:** This option is used to whitelist the selected entry.

Search contact

Unlike 'Quick search', 'Search contact' option enables the user to search an entry by its complete name.

Add new contact

Select this option in order to add a new entry into the SIM memory or to the phone memory.

Copy all

You can copy all the contacts from the Phone memory to SIM memory and vice-versa.

Delete

You can delete all contacts from the Phone memory and SIM memory or delete one by one.

Caller groups

Caller groups contains five default groups:

- Friends
- Family
- VIP
- Business
- Others

Selecting any group allows you to edit the options available with it. For example:

- Setting the ring tone associated with the group.
- Picture associated with the group.

Extra numbers

It has the following options to edit:

- **Service dialing number**

Service dial numbers are special numbers mapped with particular services given by

the network operator. These numbers are pre-fed inside the SIM card by the network provider.

NOTE: Not all SIM cards support these services.

- **SOS number**

The phone gives you five numbers to edit for contacting in case of any emergency.

Phonebook settings

The following fields are listed under settings:

- **Memory status:** This option enables you to check the memory status of the phone and the SIM card.
- **Preferred storage:** Select your preferred storage for contacts.
- **Fields:** Giving you an option to select the fields to be edited at the time of adding a new entry in the Phonebook. The fields include:
 - Home number
 - Company name
 - Email address
 - Office number
 - Fax number
 - Birthday
 - Caller picture
 - Caller ringtone
 - Caller group
- **My vCard:** Edit vCard contacts.

- **vCard version:** You can select your vCard version.

Speed dial

Set speed dial on/off, and edit the speed dial list number.

Multimedia

The verykool I117 comes with a host of multimedia applications to provide you with unlimited entertainment.

Image viewer

Image viewer stores all your pictures which are preloaded. It gives you the following options.

- **View** – To view the selected file.
- **Browse style** – You can select to view the pictures in list style or matrix style.
- **Set as** – Set as wallpaper.
- **Send** – The images selected can be sent via MMS.
- **Rename** – You can rename the image according to your own choice.
- **Delete** – To delete the selected file.
- **Delete all files**
- **Sort by**– The images stored can be sorted by Name, Type, Time and Size.

- **Storage** – You can set the photos default storage path to memory card.

Audio player

The verykool I117 comes with an inbuilt music player that plays all your favorite songs stored in the micro SD card. It gives you a host of setting options to make your listening experience interesting.

The player gives you an option to select from a list of songs already stored in the micro SD card, to be played, added to your ringtones.

The player has the following setting options:

- **List auto gen.:** It also offers to generate the play list automatically.
- **Repeat:** You can also select to repeat the song or complete play list (Off/One/All).
- **Shuffle:** You can shuffle the order of your songs to play. If you put this mode to 'ON', then the songs will be played in a random fashion otherwise, a sequential pattern will be followed.
- **Background play:** Background play option allows you to enjoy

your music even if the player is minimized to use other functions of the phone.

Sound recorder

You can record sound/voice on your verykool I117 phone. Just select sound recorder, go to options and press record. Select 'Stop' to save it. Select 'Pause' to pause the recording and 'Continue' to resume the recording.

FM radio

The verykool I117 comes with an in-built FM radio receiver/recorder player. Press 'Options' to find:

- **Channel list:** Store all the channels that the FM radio can receive. You get options to play or edit them.
- **Manual input:** You can store and register your channel frequency and play it by pressing OK.
- **Preset auto search:** On selecting this, the FM tries to scan all the available channels provided by the network. To start the search, make sure that the radio is power ON.
- **Settings:** Under settings, you have options for Background play (ON/OFF), Loud speaker (ON/OFF), Record format

(AMR/WAV), Audio quality (Low/High) and Record storage (Memory card).

- **Record:** You can record your favorite music or program.
- **Append:** Append recording enables you to append records, if any.
- **File list:** Select File list to check your previously stored recording files.

The FM radio also gives you an option to change the settings through shortcut keys available on the main window. Such as to 'Skip to next channel' and to 'skip to previous channel' using the direction keys on the keypad.

Schedule FM record

verykool I117 comes with a unique feature of FM scheduling. This feature enables you to schedule the radio to power ON itself and record your favorite program. You can set the time, date, and channel and record functions to record the desired program. It can record 4 programs for you to enjoy them anytime later at your own wish. On pressing Edit, you will have the following functions to set:

- ON/OFF
- Date and Time
- Repeat
- Channel settings
- Record settings

File manager

As the name suggests, File manager allows you to manage all the files stored in the memory card (up to 2GB).

1. You can view the remaining memory and available memory in micro-SD card.
2. You can open and navigate the directories and files in the storage.
3. You can View, Play and Setup files in the storage disks.

The options available are:

- **Open**
 - Images
 - Audio
 - My music
- **New folder**

You can create a new folder to store files.
- **Format**

NOTE: Formatting the Memory card will erase all existing data from them.
- **Rename**
- **Details**

Settings

Under settings, the phone gives you the option

to change the settings for various features of the phone.

The following list is available in Settings:

User profiles

All the different profiles are listed under this menu:

- **General:** The profile gives you an option to activate and customize the settings. You can customize the following features:
 - **Tone setup:** Tone setup enables you to set up different music tones to different functionalities of the phone like Incoming call, Message tone and Keypad tone.
 - **Volume:** You can vary the volume levels for Ring tone and Key tone.
 - **Alert type:** Alert type lets you choose the way you want to be alerted. You can choose from Ring only, Vib. only, Vib. and ring, Vib. then ring.
 - **Ring type:** Ring type lets you select the type of ring to alert you. You can choose from Single, Repeat and Ascending.

- **Extra tone:** Extra tone is added to a number of incidences such as Warning, Error, Camp on and Connect.
 - **Answer mode:** Answer mode gives you the choice to select any key to answer a call. Any key enables you to receive a call using any key of the phone except the End key.
- **Meeting**
 - **Outdoor**
 - **Indoor**
 - **Headset**

Phone setup

You have following options listed under phone setup:

- **Time and date:** Let you set the Home city, Time and date on the phone.
- **Schedule power on/off:** Let you set a particular time on the phone when the phone should Power on/off itself.
- **Language:** The verykool I117 currently supports English and Espanol.
- **Pref. input methods:** This enables you to select the text input method: They

are – Multitap ABC/abc, Multitap ES/es and Numeric input.

- **Greeting text:** Let you set your own greeting message when you power ON the phone.
- **Shortcuts:** Assign shortcuts as per your requirements to specific keys.
- **Auto update of date and time:** This feature automatically updates the date and time on the phone, receiving it from the network.

NOTE: This feature is network dependant.

- **Flight mode**
- **Vibrate on**

Display setup

Under Display setup, you can set a host of different characteristics of the phone. Like

- **Wallpaper:** Set your favorite wallpaper on the phone.
- **Screen saver:** Let you set an image as a screen saver.
- **Show date and time:** Enable you to see the date and time on the idle screen.
- **LCD backlight:** Enable you to set the brightness and waiting time.

- **Contrast**

Call setup

Network setup

Network setup gives the user the option to select a desired network and addition of a new network to the network list. The network setup gives you the following options:

- **Network selection**(Automatic/Manual)
- **Preferences** – Will list down the entire network IDs (depending on the SIM card used).
- **GPRS connection**

Security setup

Under Security setup, we have the following options available:

- **SIM lock:** press OK key to enable PIN lock, which will require you to input a password when the mobile phone is switched on. Otherwise, the SIM card is unavailable.

During setup, it requires to enter the correct PIN code. If a wrong code is entered for three times, the PUK (Personal Unlock code) will be required, PUK is used to unlock and change the locked PIN code. If PUK code is not provided, please contact your local network service provider.

- **Phone lock:** Phone lock protects your phone from any unauthorized usage or unauthorized access to information stored in the phone. When phone lock is activated, the phone would ask for the phone lock code every time you power-on the phone. Enter the lock code (default as 0000) to use the phone. You can simply unlock the phone by going into Security setup > Phone lock > enter the lock code and put it off.
- **Auto keypad lock:** Auto keypad lock automatically locks the keypad after a preset time interval. You can set the time from 5 seconds to 5 minutes.
- **Fixed dial:** Outgoing calls from your phone can be restricted by making a fixed dialing list that allows only numbers on that list to be dialled from the phone.
- **Barred dial:** Barred dial is a SIM card/Network dependant feature. If your operator supports it, then you can use the facility in the phone.
- **Change password:** Change password option gives you the options to change PIN, PIN2 password, phone password.

- **Mobile tracker:** If you lose your phone, this function may probably help you to get back your phone.
 1. First you should insert SIM card.
 2. Enter Settings → Security setup → Mobile tracker.
 3. Enter the password (The password is 0000, same as Phone lock password).
 4. Status is ON.
 5. Enter "Receipient number". You can add two numbers. For example, add number 8613764205302 and 8613564952956 ("86" is the country code).
 6. Finish.
 7. Power off. Pull off the SIM card, and insert other SIM card.
 8. Power on. The handset will send a message to the numbers (You enter the numbers in "Receipient number"). You will know which number is using your handset. If you insert former SIM card, the handset will not send the message.

Restore factory settings

Selecting this option will ask you to enter the password to restore the phone to factory settings. The default password is set as 0000.

FCC statement : Section 15.105 (b)

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Section 15.21 Information to the user

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Section 15.19 Labelling requirements

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- 1.This device may not cause harmful interference, and
- 2.This device must accept any interference received, including interference that may cause undesired operation.

SAR INFORMATION

The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue.

Device types (FCC ID: WA6117) has also been tested against this SAR limit.

The highest SAR value reported under this standard during product certification

for use at the ear is 1.49 W/kg and when properly worn on the body is 1.32

W/kg. This device was tested for typical body-worn operations with the back of the handset kept 1.5cm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 1.5cm separation distance between the user's body and the back of the handset. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.