

User Manual


Model:SW05

ENGLISH

Includes

Sport Tone, charge cable, 2 sets of silicone tips (S/L), removable cable management clip, and user guide

Please read and follow this user guide thoroughly before using the Sport Tone.



1. Power/Phone/Pause
2. Volume up
3. Volume down
4. Charge port

Specifications

Frequency response: 20 Hz – 20 kHz

Driver size: 11mm

Impedance: 16Ω

Sensitivity: 110±5dB

Bluetooth v4.0, up to a 30 foot transmission range

Battery capacity: 100mAh

Play time: Up to 4.5 hours based on usage

Charge time: 2 hours

Button functions

NOTE: Button functions may vary per device.

Power/phone/pause button

- Press and hold for at least 4 seconds to power on the Sport Tone; press and hold for at least 4 seconds to power off the Sport Tone.
- When playing music, press and release to pause music; press and release again to play music.
- When receiving an incoming call, press and release to answer; press and release again to end the call.
- Press twice quickly to call last number dialed.

NOTES:

- During the first time set-up, you must hold the power/phone button down for at least 8 seconds until the LED indicator flashes red and blue in order to pair your device to Bluetooth. After the initial pairing, you can let go of the power/phone button when the LED indicator flashes blue.
- When playing music and a call comes in, the music will pause and you will hear a ringtone. The music will resume when the call is ended. Device's ringtone may vary.

Volume up/track forward button

- Press and release to raise the volume.
- Press and hold to go to the next track.

NOTE: The volume up/down buttons may control the volume on your device. Device's results may vary.

Volume down/track back button

- Press and release to lower the volume.
- Press and hold to go to the beginning of the current track.

NOTE: The volume up/down buttons may control the volume on your device. Device's results may vary.

Charging your Sport Tone

NOTE: Make sure your Sport Tone is fully charged before using it the first time.

1. Gently plug the Micro-USB end of the included charge cable into the charge port.
2. Plug the USB A end of the cable into a powered USB port, such as a computer, laptop, or USB AC adapter (not included).
3. The LED power indicator located next to the volume up/track forward button will light up solid red. Once the headset is fully charged, the LED power indicator will turn blue.

NOTE: The LED power indicator will light up red while charging even if the Sport Tone is off.

Connecting via Bluetooth® (first time set-up)

1. Press and hold the power/phone button for at least 4 seconds to turn the headset on.

NOTE: During the first time set-up, you must hold the power/phone button down for at least 8 seconds until the LED indicator flashes red and blue in order to pair your device to Bluetooth. After the initial pairing, you can let go of the power/phone button when the LED indicator flashes blue.

2. Open the settings on your Bluetooth device (Bluetooth

must be enabled).

3. Select "Sport Tone" from the list of Bluetooth devices.

4. Once paired, the LED power indicator light will flash blue slowly.


5. To turn off the Sport Tone, press and hold the power/phone button for at least 4 seconds.

NOTES:

- Upon use of your Sport Tone the volume must be adjusted to your desired level.
- Your device will automatically find and pair with the Sport Tone after the initial pairing. If your device does not automatically pair, turn off the headset and repeat steps 1-4.
- The Sport Tone will automatically pair to the last device connected.
- The volume up/down buttons on the Sport Tone may control the volume on your device. Device's results may vary.

Cable management

To loosen the removable cable management clip.



To tighten the removable cable management clip.

Troubleshooting

Issue: My Sport Tone doesn't turn on.

Solution: Try the following:

- Make sure the Sport Tone is charged.
- Make sure the volume is turned up on your device and the Sport Tone.
- Make sure you press and hold the power/phone button for at least 5 seconds.

Issue: My Sport Tone is not charging.

Solution: Try the following:

- Make sure the charge cable is fully inserted in the Sport Tone.
- Make sure that the charge port on the headset is free from dust and debris.
- Make sure that you are using the charge cable that came with your Sport Tone.
- Make sure there is power coming from the power source.

Issue: My Sport Tone isn't syncing to Bluetooth.

Solution: Try the following:

- Make sure you hold the power/phone button down until red and blue light flash.
- Make sure that the Bluetooth setting is turned "on" on your device.
- Check to see if another user is connected to the Sport Tone.
- Refer to the user guide of your device for Bluetooth syncing instructions.

Issue: My Sport Tone volume is turned all the way up, but the volume is still very low.

Solution: Try the following:

- Make sure your Sport Tone and audio device are charged.
- Make sure the volume is turned up on your device and the Sport Tone.

Issue: The person on the other line cannot hear me very well.

Solution: Try the following:

- Make sure your Sport Tone and phone are charged.
- Make sure there is nothing covering the microphone on the control box.
- Make sure you have service with your phone provider.

Safety warning

- Do not listen at a high volume level. Extended high volume levels can lead to permanent hearing loss.
- Start with setting the volume level at the lowest volume and adjust until you reach a comfortable volume level.
- Tampering or removing the battery can result in damage to your product, void of warranty, and could cause injuries.
- Do not use when a failure to hear your surroundings could be dangerous, such as while driving, or when biking, walking or jogging where traffic is present and accidents may occur.
- Do not use while sleeping, as accidents may occur.
- If you experience any ringing in your ears, try lowering the volume. If the ringing persists, visit your physician.

Important safety precautions

- Incorrect use or incompatibility with your device may result in reduced battery performance or damage to your device.
- Do not attempt to disassemble product.

- Tampering or removing the battery can result in damage to your product, void of warranty, and could cause injuries.
- Do not allow this product to have contact with liquids.
- Store and operate between 32°F – 113°F.
- Do not place this product near a heat source or flame.
- Do not throw or shake.
- Do not operate if it has been subjected to shock or damage.
- Do not crush or puncture the battery.
- Recharge the battery every 3 months when not in use to keep battery in best condition.
- Use soft cloth to clean the exterior. Do not use harsh chemicals or strong cleaning solvents.
- The internal battery must be recycled or disposed of properly. Contact your local waste management office for information on the proper disposal or recycling.

FCC information

This equipment has been tested and found to comply with the limits for a Class B Digital Device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- 1.** This equipment may not cause harmful interference.
- 2.** This equipment must accept any interference received, including interference that may cause undesired operation.

Modifications not authorized by the manufacturer may void the user's authority to operate this device. This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Warranty information

All i.Sound products come with a limited warranty and have been subjected to a thorough series of tests to ensure the highest level of dependability and compatibility. It is unlikely that you will experience any problem, but if a defect should become apparent during the use of this product, i.Sound warrants to the original consumer purchaser that this product will be free from defects in material and workmanship for a period of 120 days from the date of your original purchase. If a defect covered by this warranty occurs, i.Sound, at its option, will repair or replace the product purchased at no charge or

refund the original purchase price. If a replacement is necessary and your product is no longer available, a comparable product may be substituted at the sole discretion of i.Sound.

This warranty does not cover normal wear and tear, abusive use or misuse, modification, tampering or by any other cause not related to either materials or workmanship. This warranty does not apply to products used for any industrial, professional or commercial purposes.

Service information

For service on any defective product under the 120-day warranty policy, please contact Consumer Support to obtain a Return Authorization Number. i.Sound reserves the right to require the return of the defective product and proof of purchase.

NOTE: i.Sound will not process any defective claims without a Return Authorization Number.

Consumer support hotline

877-999-3732 (U.S. and Canada only)
or 310-222-1045 (International)

Consumer support email

support@isound.com

Website

www.isound.com

Save a tree, register online

i.Sound is making the eco-friendly choice to have all products registered online. This saves the printing of

physical paper registration cards. All the information you need to register your recent i.Sound purchase is available at: **www.isound.com/product-registration**