

**CSC600ER; XL-2055ER**  
**USER'S MANUAL**

## TABLE OF CONTENTS

FEATURE LIST. . . . .	1
SAFETY INSTRUCTIONS. . . . .	2
SETTING UP . . . . .	3
LOCATION OF CONTROLS. . . . .	5
BASIC FUNCTION . . . . .	8
FUNCTION OPERATION . . . . .	11
PHONE BOOK. . . . .	11
SET TIME . . . . .	13
SET PHONE. . . . .	13
SET SOS. . . . .	15
RECEIVING CALL RECORDS . . . . .	18
REVIEWING DISPLAY MESSAGES . . . . .	18
CALLER ID SYSTEM OPERATION . . . . .	20
CALL ID ON CALL WAITING. . . . .	22
TROUBLESHOOTING . . . . .	23
AMPLIFY FEATURE . . . . .	24

2. The  $\curvearrowright$  switch will be set to the **OFF** position and the volume will be set to middle at factory.

3. Please adjust the volume to your necessary. Too loud volume may hurt your ear. We recommend you first move the  $\curvearrowright$  switch to the **OFF** position.

### Using your Amplified Phone with hearing aids


Your phone can be used with hearing aids equipped with a telecoil (T-coil). Adjust your hearing aid "T-switch" to the "T" position. Make sure to hold the handset close to your hearing aid.

**CAUTION:** This telephone can produce very high (loud) sound levels. Repeated incremental exposure to amplification levels greater than 18 dB may be harmful to people without hearing loss. Always adjust the volume control to the minimum setting after using the phone.


## AMPLIFY FEATURE

### Receiver Voice Tone


The unit provides extra amplification in the tone frequency range you need to boost. You can identify the range follow these steps:

First, move the  switch on the rear of the unit to **ON** or **OFF** position to turn the function on or off. See Figure1.

Then:

1. If you move the  switch to **ON** position, each time you use the phone, the amplifier turns on automatically, then you can adjust the tone frequency range while on a call by moving the **TONE** control. See Figure2.

But if necessary, you can press the **AMP** button to temporarily turn on or off the amplifier during a call. See Figure3.

2. If you move the  switch to **OFF** position, each time you use the phone, the amplifier turns off automatically.

But if necessary, you can press the **AMP** button to temporarily turn on or off the amplifier during a call. See Figure3.




Figure1




Figure2




Figure3

### NOTES:

1. When the amplifier turns on, the red indicator lamp near the **AMP** button will be bright.

## FEATURE LIST

1. FSK+DTMF dual system caller ID
2. Stores up to 99 incoming calls name & number, date & time
3. Stores up to 30 outgoing calls number
4. Stores up to 99 names & numbers in phone book
5. LCD display calling name & number
6. Call back function
7. Delete individual or all records
8. Real time clock (Set time)
9. NEW call/ Message waiting LED indicator
10. Languages selection
11. 6 one-touch memories
12. 6 SOS numbers auto-dialing
13. SOS message recording
14. Battery low indicator
15. Last number redial
16. Flash time setting
17. Dialing mode setting
18. Speakerphone
19. Caller ID on call waiting
20. LCD blue back light
21. Timer

## SAFETY INSTRUCTIONS

To reduce the risk of fire, electrical shock, and injury, please follow these basic safety precautions before you use this equipment.

1. Carefully read the instructions in this manual.
2. Follow all warnings and instructions marked on the unit.
3. When cleaning, unplug the telephone jack from the wall outlet. Use a damp cloth. **DO NOT** use liquid or aerosol cleaners.
4. Do not use this equipment near water eg, near a kitchen sink, bathtub, washbowl, laundry tub, swimming pool or in a wet basement.
5. Install in a protected location. Ensure all lines and cords are away from foot traffic. **DO NOT** place objects on the line cord that may cause damage or abrasion.
6. Avoid spilling any liquid on the unit. This may cause internal shorting, fire or shock and is not covered under your warranty.
7. Do not overload wall outlets and extension cords as this can result in the risk of fire or electrical shock.
8. Never push objects of any kind into this telephone as they can touch dangerous voltage points or short out parts that could result in a risk of fire or electrical shock.
9. Take the phone to a qualified technician when it requires repair work or service. To reduce the risk of electrical shock, do not disassemble the telephone. Opening or removing covers can expose you to dangerous voltages or other risks. Incorrect re-assembly can cause electrical shock during subsequent use.
10. Avoid using the telephone during an electrical storm. There can be a slight risk of electrical shock from lightning.
11. **DO NOT** use the telephone to report a gas leak, if in the vicinity of the leak.
12. Unplug this telephone from the wall outlet and refer servicing to qualified service personnel under the following conditions:
  - If liquid is spilled into the unit.
  - If the unit is exposed to rain or water.
  - If the unit does not operate normally by following the Operating Instructions.
  - If the unit is dropped or the casing is damaged.
  - If the unit exhibits a distinct change in performance.

## TROUBLESHOOTING

If you have problems with your phone, please check below for helpful hints:

BLANK OR  
FAINT  
SCREEN

- Check the line cord. Connect Telephone Cord. Check batteries

CALLER ID  
WILL NOT  
WORK  
PROPERLY

- Call your telephone company to verify that your Caller ID services are active.

PHONE  
WILL NOT  
RING

- You may have too many communication devices hooked to a single line. A communication device can be a phone, modem, or facsimile (FAX) machine. Contact your telephone company for help in calculating the limit for your residence or business line.

NO DIAL  
TONE

- Verify that the Line Cord is plugged in correctly.

- Verify that the Line Cord connection is correct and tightly secured.

NO DATA  
SENT

- Call your telephone company to verify that your caller ID services are active.

- If you have an answering machine connected to this Phone, ensure that your answering machine is set to answer after at least two rings.

- You answer the call before two rings.

- Contact your telephone company if the problem continues for more than 24 hours. The telephone company may be experiencing temporary line

NO RE-  
SPONSE ON  
LCD DISPLAY

- If you have experienced a power failure when using optional AC adapter, the batteries for memory back up could become weak or dead. If the power is restored and the display screen does not respond then you must replace the batteries with new.

## CALLER ID ON CALL WAITING

When you subscribe to Caller ID/Call Waiting service from your local telephone company and you activate the call waiting function, the telephone will display the name and number of the second caller while you are having a conversation.

Caller ID info displayed

Caller 1  
436-1234

Caller two's information  
is displayed

Caller 1  
436-1234  
Caller 2  
291-5678

1. When you are on the line, the telephone will display the name and number of the second caller.
2. Press the **CALL WAITING** button to answer the second caller.
3. When you have finished, press the **CALL WAITING** button to continue with your conversation with the first caller.

## SETTING UP

### CHECK THE CONTENTS OF THE BOX

Box should contain:

- Handset with handset cord and phone base
- Telephone line cord
- 4 AAA size 1.5V batteries
- User's manual
- Adapter

### BATTERY AND ADAPTER INSTALLATION

A. The Caller ID phone requires four 1.5V AAA size batteries for LCD display.



1. Remove the battery cover from the back of your Caller ID phone.
2. Insert four 1.5V AAA size batteries by observing the +/- polarity marked on the compartment.
3. Replace battery compartment cover.

#### NOTES:

1. Do not recharge the batteries or dispose them in fire.
2. Do not throw the battery everywhere, in case cause the pollution.

B. You can also insert the adapter for the LCD display, and you must insert the adapter for LCD back light and other special functions, please refer to the concrete requirement in the manual.

### CONNECTING LINE CORDS

1. Plug one end of the supplied modular cord into the line jack. Then plug the other end into telephone line jack.
2. Insert the earphone plug into the 2.5mm standard  socket or the 3.5mm standard **NECKLOOP** socket.
3. Insert the end of the shaker line into the  socket.

## WALL INSTALLATION

The phone can be mounted to any wall surface using two self-tapping screws (not supplied). Follow the instructions.

1. Install the two self-tapping screws at a distance of 80mm from each other and located on a vertical centre line (See Figure 1).




Figure 1




Figure 2

2. Slide the handset hanger tab out and reverse its position (rotate it 180 degrees). Slide it back into place so that the hook points up. This will keep the handset from falling out of the cradle when it is mounted on the wall (See Figure 2).
3. Holding the phone slightly above the mounting screws on the wall jack, push the phone against the mounting screws so they are hooked into upper and lower key hole slots on the bottom of the phone.
4. Slowly slide the phone down until it snaps into place (See Figure 3).




Figure 3  
Wall Mounting View

If the incoming call number is of 10 or 11 digits, when you press ▲ or ▼ button to review it, you can press # button to switch this number between 10 digits and 11 digits. For example, if the number is 1234567890, press # button to change it to 11234567890. Or if the number is 11234567890, press # button to change it to 1234567890.

## CALLER ID SYSTEM OPERATION

**Subscription to Caller ID service from your local phone company is required.**

● **New calls / Messages waiting indicator** - The red indicator light will flash to indicate that you have new calls/messages and it will flash until all the new calls / messages have been reviewed.

● **Review Your Caller ID Records** - Use the ▲ or ▼ button to scroll through the caller ID list. At the end of the caller ID record list, you will see the "END OF LIST" message on the LCD. Press the ▲ or ▼ button to continue.

● **Save Call Records** - Save specific calls by deleting old or unnecessary Call Records.

**NOTE:** Your phone stores up to 99 call records before the memory becomes full. When the next call comes in, the oldest record automatically drops off to make room for new call records.

● **Using the CALL BACK feature**

**A. Call back a previously dialed number: The unit can store up to 30 previously dialed numbers.**

1. In the on-hook mode, press the **DIAL** button once, then use the ▲ or ▼ button to select the number you want to call back.
2. Pick up the handset or press **SPEAKER** button to dial the number.

**B. Call back a number from your Caller ID list: The unit can store up to 99 call records in the Caller ID list.**

1. Lift the handset or press the **SPEAKER** button, wait for a dial tone.
2. Select the incoming number that you want to call back by pressing the ▲ or ▼ button.
3. When the number you want to call appears on the LCD, press the **DIAL** button.



**Or**

You can select the desired number by using the ▲ or ▼ button, then pick up the handset or press the **SPEAKER** button to dial it out.

## LOCATION OF CONTROLS




- |                            |                                      |
|----------------------------|--------------------------------------|
| 1. Hook switch             | 12. SOS button                       |
| 2. Caller ID Screen        | 13. Amplify button                   |
| 3. DELETE button           | 14. Headset button                   |
| 4. Up and Down button      | 15. SPEAKER button                   |
| 5. DIAL button             | 16. Flashing incoming call indicator |
| 6. Phonebook button        | 17. REDIAL button                    |
| 7. Handset Tone control    | 18. One-touch memory buttons (M1~M5) |
| 8. Handset Volume control  | 19. Speakerphone                     |
| 9. One-touch memory button | 20. Microphone                       |
| 10. CALL WAITING button    |                                      |
| 11. STOP button            |                                      |




**PRIVATE** - If the caller has exercised the option to prevent his name and number from being sent, "PRIVATE" will be shown on the screen.




**NO CALLS** - When all calls have been deleted, the display will show **NO CALL**.




**END OF LIST** - This message is displayed when you use the ▲ or ▼ button to reach the top (end) of the caller ID list. If there are no calls, then LCD shows **NO CALL**.



**OUT OF AREA** - Will display when someone calls from an area where the telephone company is not offering Caller ID Service or an area that is not yet providing name and number delivery to your area via the long distance network.





**LOW BATTERY INDICATOR:** If the battery is low, the low battery icon  will appear.





## RECEIVING CALL RECORDS

A caller ID record consists of the following information:





\*This function should be supported by your local telephone company.

## REVIEWING DISPLAY MESSAGES


**MESSAGE WAITING\*** - If you have voice mail service from your telephone company and a recorded message is left, the screen will display "**MESSAGE WAITING**" and the MESSAGE WAITING will be saved as a call. The message waiting indicator lamp will flash until the message has been reviewed.

**\*You must subscribe to Voice Mail from your local phone company.**

**TOTAL & NEW CALLS** - This display shows you the total and new calls to be reviewed. In this example, you have 15 calls in total which includes 5 new calls .



## Remote Control



You can conveniently carry the remote-control unit and make a emergency call if necessary. Please refer to section " SET SOS " for details.

## BASIC FUNCTION

### 1. Redial function

This feature allows you to redial the last number you have called by one-touch operation.

- a. Lift handset or press the **SPEAKER** button to get a dial tone.
- b. Press the **REDIAL** button to redial the last number called.

### 2. Flash function

Press the **CALL WAITING** button to terminate a call and institute a dialling tone for another call or to get another call from "Call Waiting" (a special telephone service).

**NOTE:** If you do not have any special telephone service, such as Call Waiting, press the **CALL WAITING** button during a call may disconnect your current conversation.

### 3. Speaker function

To switch your call to speakerphone, press the **SPEAKER** button and replace the handset in the cradle. To switch back, simply pick up the handset. In the speaker state, you can make or answer a call.

### 4. Speaker volume adjustment

To adjust the speaker volume, move the **VOLUME** switch located on the right side of the unit to the desired position.

### 5. Receiver volume and tone select switch

You can adjust the receiver volume by sliding the **VOLUME** control. Also you can amplify the receiver volume and tone frequency according to your own hearing requirements. **Please see the "Amplify Feature" part of the manual for details.**

**NOTE:** The unit must be connected to adapter for the receiver volume and tone adjustment.

### B. To take attention to everything happens at home by remote control whenever

To have the function, you need to turn on the "Auto turn on " and remember the Pin code.

#### 1. To turn on "Auto turn on"

When the LCD shows the **SET SOS** menu, press the **DIAL** button to confirm. Then select the **Auto turn on** menu and press the **DIAL** button to enter. The LCD shows **ON/OFF**. Then select **ON** to turn on the "Auto turn on " function.

#### 2. To set Pin code

When the LCD shows the **SET SOS** menu, press the **DIAL** button to confirm. Then select the **Pin code** menu and press the **DIAL** button to enter. Enter the Pin code (up to 4 digits, and the default Pin code is 1234), then press **DIAL** button to confirm.

After turn on " Auto turn on " and set the Pin code, you can use the function as follows.

After 10 times ringing is detected, the phone will be auto off-hook the line (In this state, the user can hear the caller but cannot answer the caller), and then generates two "bip-bip" tones to remind the caller to enter Pin code to enter full speaker state. The caller enters the Pin code, and then starts the conversation. Every about 2 minutes later, the caller will hear two "bip-bip" tones. Press special buttons (0~9,\*,#) to continue the conversation. Otherwise, the line will be disconnect automatically.

**NOTE:** When the phone is auto off-hook the line, the receiver can press the **SPEAKER** button to enter full speaker state with caller. In this way, there is no need for caller to enter Pin code.

#### NOTES:

1. In the message, you should tell the helper to press one of the special buttons (0~9,\*,#) to confirm that your SOS message has been received.
2. If you want to record a message for less than 10 seconds, you can press the **DIAL** button to confirm and exit.

#### b. To play the SOS message

Press the ▲ or ▼ button to select **PLAY SOUND** menu and press the **DIAL** button to play the SOS message.

After setting the SOS number and message, you can use the function conveniently whenever.

Press the **SOS** button on the remote control unit or base unit. Then the telephone will dial the first SOS number.

If there is no response in 30 seconds or the line is busy, the telephone will dial the second SOS number. If there is still no response in 30 seconds or the line is still busy, the telephone will dial the next number in turn until all the numbers you set are dialled twice.

If someone on the other end lift the handset, the telephone will play the SOS message you recorded to ask for help. You can press the **STOP** button on the remote control unit or the base unit to cancel the SOS calling.


#### NOTES:

1. After lifting the handset, the helper should press one of the special buttons (0~9,\*,#) to confirm. Otherwise, the telephone will dial the next SOS number automatically.
2. In the tone dialling mode, if the helper press one of the special buttons (0~9,\*,#) to confirm, the caller's telephone will enter speakerphone state automatically to receive the confirmation.
3. After pressing the **SOS** button to ask for help, you can enter the speakerphone state to have a word with the helper. Then you can press the **STOP** button on the remote control unit or the base unit to cancel the SOS calling if necessary.




#### 6. Receiver and sending volume adjustment button

The button is located on the handset. To decrease sending and increase receiving volume, press and hold the button while making a call by handset. To return to the normal, just release the button.

#### 7. Ringer volume control


To adjust the ringer volume, move the **RING** switch located on the right side of the unit to the desired position (  ).


#### 8. Ringer, Strobe, Shaker switch


Your phone provides several options to alert you that you have a new incoming call. The loud, adjustable ringer as well as the bright strobe and optional bed shaker or any combination of these allow you to customize the phone to fit your needs. If you want to activate strobe light, set the switch to  . If you want to activate the shaker, set the switch to  . If you want activate the strobe light and shaker, set the switch to  .

**NOTE:** You must insert the adapter to support the strobe light and shaker.

#### 9. One-touch memory

The unit can store 6 one-touch memory numbers including a priority number (  ), 30 digits maximum for each button.

**To store the number** - In on-hook state, enter the desired number by keypad, then press and hold the location button (M1~M5,  ) to store it, and the LCD will show **SAVE OK**.

**To dial the number** - Pick up the handset or press the **SPEAKER** button. Just press the location button (M1~M5,  ) to dial out the matching number.

## 10. Delete a single or all record number(s)

Find out the number which you want to remove, press **DELETE** button, the LCD will show **DEL ?** and then press **DELETE** button again to remove this number. If you press and hold **DELETE** button for about 6 seconds, the LCD will show **ALL DEL ?** then press the **DELETE** button to remove all numbers and the LCD will show **NO CALL**.




In the state of on-hook,

\* Press the **▲** or **▼** button to select the Caller ID numbers.

\* Press the **DIAL** button then press the **▲** or **▼** button to select the last dialled numbers.

## 11. Earphone using

**Using the AUDIO NECKLOOP socket** - Plug the earphone into the socket, then earphone will be activated. In the state, the phone still works meanwhile you can hear the caller through the earphone.

**Using the  socket**- During a call, to activate the earphone, press the  button then replace the handset in the cradle or press the **SPEAKER** button. In the state, you can hear the caller, also you can answer the caller through the earphone. To switch back, just press the  button or pick up the handset or press the **SPEAKER** button.

**NOTE:** You must insert the adapter for the earphone using.

## 12. Speech volume control

You can adjust the sending volume by using the Speech volume control located on the right side of your phone. If your voice is faint or weak, adjust the volume to "HI". You can also decrease the volume as well. There are 3 levels available LO (●), NORMAL (●) and HI (●).

**NOTE:** If you adjust the sending volume to "HI" when an adapter is connected, the receiver volume will decrease 12 dB compared to the receiver volume you acquire by adjusting the control to "LO" position.

## ● SET SOS

Accessing the SOS function, you can ask for help by one-touch operation when you are in emergency or pay attention to everything happens at home by remote control whenever.

**NOTE:** You need to connect the adapter for the SOS function.

### A. To ask for help by one-touch operation

To use the function of asking for help by one-touch operation, you need to preset the SOS number and you'd better record the message you want to tell the helper.

#### 1. To register the remote control

The remote control unit is already registered to the base. When you cannot use the remote control to dial SOS numbers, do the following operations.

Press the Remote register button located on the bottom of the base, then press the **SOS** button on the remote control unit.

#### 2. To preset the SOS number

When the LCD shows the **SET SOS** menu, press the **DIAL** button to confirm. Then select the **SOS NUMBER** menu and press the **DIAL** button to enter. There are 6 SOS number available for setting.

a. Press the **▲** or **▼** button to select one location and enter the telephone number by keypad (18 digits maximum for each memory).

You can press the **DELETE** button to delete the previous digit.

b. After setting the numbers, press the **DIAL** button to store it and return to the previous menu.

#### 3. To set the SOS message

When the LCD shows the **SET SOS** menu, press the **DIAL** button to confirm. Then select the **SOS SOUND** menu and press the **DIAL** button to enter.

##### a. To record the SOS message

Press the **▲** or **▼** button to select **RECORD SOUND** menu and press the **DIAL** button to confirm. You can record a message in 10 seconds.

Use the ▲ or ▼ button to select the language you want and press the **DIAL** button to confirm. Press the **DELETE** button to return to the previous menu.

LCD contrast -- Use the ▲ or ▼ button to select the LCD contrast level you want. Press the **DIAL** button to confirm and exit.

Set Area & LDS -- When you use this phone for the first time, or move to an area that has different area code, you must enter your area code. This is necessary because the phone must distinguish local or long distance calls to properly dial calls from the Caller ID list.

When you enter the area & LDS code setting, the LCD displays "AREA CODE". Use the ▲ or ▼ button to select the desired number and press the **DIAL** button to confirm and enter the next item. After the area code setting (up to 6 digits), press the **DIAL** button once to enter the long distance code setting (up to 6 digits). Set it with the same method and press the **DELETE** button to enter to the standby mode.

Set Flash-- Use the ▲ or ▼ button to select the flash time (100ms/300ms/600ms). Press the **DIAL** button to confirm and exit.

DIM:X--->x -- Use the ▲ or ▼ button to select **ON/OFF** to activate/deactivate the DIM:X->x function\* and press the **DIAL** button to confirm and exit.

(\*If this function is activated, the maximum digits of number can be shown on the LCD is 18, or the maximum digits is 8.

Hour format -- Use the ▲ or ▼ button to select the hour Format (12 HOUR/24 HOUR). Press the **DIAL** button to confirm.

Date format -- Use the ▲ or ▼ button to select the date format (DD-MM/MM-DD). Press the **DIAL** button to confirm and exit. In the DD-MM mode, the date display sequence is day-month while in the MM-DD mode, the sequence is month-day.

Tone/Pulse -- Use the ▲ or ▼ button to select the dialing mode (TONE/PULSE). Press the **DIAL** button to confirm and exit.

## FUNCTION OPERATION

The main menu includes **PHONE BOOK**, **SET TIME**, **SET PHONE** and **SET SOS**.

In the standby mode, you can enter the **MAIN MENU** by the following 2 ways:

1. Press and hold the **CALL WAITING** button.
2. Press and hold the **DIAL** button less than 2 seconds, then press the ▼ button.

Then use the ▲ or ▼ button to select one. Press the **DIAL** button to enter or press the **DELETE** button to return to the previous menu.

### ● PHONE BOOK

When entering the phonebook, the LCD shows two menus: **ADD** and **REVIEW**, use the ▲ or ▼ button to select one, then press the **DIAL** button to enter or press the **DELETE** button to exit to the previous menu.

#### 1.To add name and numbers to the Phone book

Select the **ADD** menu and press the **DIAL** button to confirm.

a. Enter the telephone number by keypad (30 digits maximum for each entry). Press the **DELETE** button to delete any digits entered in error.

b. After setting the number, press the **DIAL** button to enter the name. Use the appropriate keypad to get the following characters:

Key	Characters	Key	Characters
1	1 . , ? ! - " ' (	6	M N O m n o 6 Ö Ø
2	A B C a b c 2 Æ Ø	7	P Q R S p q r s 7
3	D E F d e f 3	8	T U V t u v 8 Ü
4	G H I g h i 4	9	W X Y Z w x y z 9
5	J K L j k l 5	0	0 + & @ / \$ %

If the next character to be entered is on the same button as the previous one, you will first need to press the **DIAL** button. Press the **DELETE** button to delete the previous digit or character if necessary.

c. When the number and name setting is completed, press and hold the **DIAL** button to store it. Meanwhile enter the next number's presetting. Then you can press the **DELETE** button to return to standby mode.

## 2. To review/delete/speed dial/modify the phone book number

Select the **REVIEW** menu and press the **DIAL** button to confirm.

a. *To review the phone book number:*

Use the **▲** or **▼** button to review the phone book entries. Also you can quickly review the call by pressing sequence of the number+# or the **☰** button in the on-hook state.

e.g.: If you want to review the seventh entry, just press 7#, the matching number and name will display on the LCD.

b. *To delete a single phone book number:*

Use the **▲** or **▼** button to select the phone book number which you want to delete, press the **DELETE** button once and the LCD shows **DEL ?**. Press the **DELETE** button once more to confirm.

c. *To speed dial a phone book number:*

Use the **▲** or **▼** button to select the phone book number which you want to call, just pick up the handset or press the **SPEAKER** button to dial it out.

d. *To modify the number & name in phone book:*

Use the **▲** or **▼** button to select the number you want to modify, press and hold the **DIAL** button until the last digit of the number flashes to indicate you enter the modification. Press the **DIAL** button once more, you can then modify the name. After the modification press and hold the **DIAL** button to confirm and enter the next number's addition. You can also press the **DELETE** button to exit.

e. *Copy the CID numbers or last dialled numbers to phonebook:*

When the desired number shows on the LCD, you can press and hold the **DIAL** button until the last digit of the number flashes to indicate you enter the modification (Refer the section 1. a, b).

\* In the on-hook state, press the **▲** or **▼** button to review the CID list.

\* In the on-hook state, press the **DIAL** button once, the LCD will show the last dialled number, you can press the **▲** or **▼** button to review other outgoing numbers.

## ● SET TIME

After entering the **SET TIME** menu, use the **▲** or **▼** button to select the correct number. Press the **DIAL** button to confirm and move to the next item. When you finish the setting, press the **DIAL** button to confirm and press the **DELETE** button to exit.

### NOTES:

1. If you subscribe to Caller ID service from your local phone company, the time and date will be set automatically. (FSK standard)
2. The setting sequence is HOUR-MINUTE-MONTH-DAY.

## ● SET PHONE

This menu includes 11 submenus: **SET RING**, **CALL WAITING**, **AUTO ON HOOK**, **SET LANGUAGE**, **LCD CONTRAST**, **SET AREA&LDS**, **SET FLASH**, **DIM:X→>x**, **HOOR FORMAT**, **DATE FORMAT** and **TONE/PULSE**. Use the **▲** or **▼** button to select one. Press the **DIAL** button to enter or press the **DELETE** button to exit.

Set ring – There are 4 different ringer melodies, use the **▲** or **▼** button to select one you desire and press the **DIAL** button to confirm. Press the **DELETE** button to return to the previous menu.

Call waiting – Use the **▲** or **▼** button to select **ON/OFF** to activate/deactivate the call waiting function and press the **DIAL** button to confirm.

Auto on hook – Use the **▲** or **▼** button to select **ON/OFF** to activate/deactivate the auto on hook feature\* and press the **DIAL** button to confirm.

\* When the auto on hook feature is on, your phone will automatically disconnect the line after about 13 seconds if the phone is left off the hook. This will restore the line to be able to receive another call even if you leave the handset off the base.

Set language – The unit supports multiple languages, including Chinese/Korean/Greece/Australian/Turkish/English3/Spanish/Ned erland/French/German/Polish/Swedish/Danish/Finlish/Norwegian and English1.

## Customer Information

1. This equipment complies with Part 68 of the FCC rules and the requirements adopted by the ACTA. On bottom of this equipment is a label that contains, among other information, a product identifier of [US: [CLSTE12BCSC600ER](#)]. If requested, this number must be provided to the telephone company.

2. If this equipment [[AMPLIFIED EMERGENCY RESPONSE PHONE](#)] causes harm to the telephone network, the telephone company will notify you in advance that temporary discontinuance of service may be required. But if advance notice isn't practical, the telephone company will notify the customer as soon as possible. Also, you will be advised of your right to file a complaint with the FCC if you believe it is necessary.

3. The telephone company may make changes in this facilities, equipment, operations or procedures that could affect the operation of the equipment. If this happens the telephone company will provide advance notice in order for you to make necessary modification to maintain uninterrupted service.

4. If you experience trouble with this equipment, you disconnect it from the network until the problem has been corrected or until you are sure that the equipment is not malfunctioning.

5. Please follow instructions for repairing if any (e.g. battery replacement section); otherwise do not alternate or repair any parts of device except specified.

6. Connection to party line service is subject to state tariffs. Contact the state public utility commission public service commission or corporation commission for information.

7. If the telephone company requests information on what equipment is connected to their lines, inform them of:

- a) The telephone number that this unit is connected to,
- b) The ringer equivalence number [[1.2B](#)]
- c) The USOC jack required [RJ11C], and
- d) The FCC Registration Number [US: [CLSTE12BCSC600ER](#)]

Items (b) and (d) are indicated on the label. The ringer equivalence number (REN) is used to determine how many devices can be connected to your telephone line. In most areas, the sum of the RENs of all devices on any one line should not exceed five (5.0). If too many devices are attached, they may not ring properly.

## Service Requirements

In the event of equipment malfunction, all repairs should be performed by our Company or an authorized agent. It is the responsibility of users requiring service to report the need for service to our Company or to one of our authorized agents. Service can be facilitated through our office at:

[ClearSounds Communications, Inc.](#)

[1743 Quincy Avenue #155 Naperville, IL 60540 U.S.A](#)

[Phone: +630-654-9200](#)

**FCC Caution:**

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.