

User manual

Specification:



Operating Voltage	DC6V
Operating Current(Max.)	15mA max
Static Current	0mA
Operating Frequency	433.92MHz
Modulation Mode	ASK
Read Range	10m
Number of button	1
Operating Temperature	-20~60℃
Operating Humidity	10 ~ 90%
Size	63*32*10.35mm

Paired with Remote Control Module:

1. Remote Control Module Installation:

When extra remote control is available, the remote control module shall be inserted into the holes. Insert the 6 pins of the module(Figure 4) into the correct holes of board (Figure 3).




Figure 4




Figure 3




Figure 5

2. Reapply power to the Exit Button.

3. Press and hold the button on the module until the red LED comes on, then release.

4. While the LED is illuminated, press the button on the remote control, then LED will blink indicating the code is being stored.

5. The red led will go out to indicate the successful programming. Up to 5 remotes can be paired with the one receive by following the above procedure.

6. To delete all units, press and hold the button on the back of the board until the red LED comes on. Continue to hold the button until the LED goes out.

FCC Statement:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.