


成品尺寸:630X128MM 105克铜版纸黑白正反面印刷


折叠成品尺寸: 105X128MM

VIVITAR wemakefun Quick Start Guide IPC112N



© 2009-2017 Sakar International, Inc. All rights reserved. EN


1 What's Included



- IP Camera
- Micro USB cable
- AC Charger
- Screws
- Setup tool

Micro SD memory card not included


2 Parts of the Camera



- Micro SD card slot
- LED indicator (red/blue)
- Lens
- Microphone
- Column spinner
- Ventilation holes
- Speaker
- Reset Button
- Micro USB Port
- Magnet Base

3 Initial Setup


Turning On the Camera



Connect the power supply with the IP Camera and the RED indicator light will turn on.


If the camera indicator is **blinking blue**, the camera needs to be reset. To reset the IP Camera, use the Setup Tool to press the RESET button on the back of the camera. Press and hold until the indicator turns red. Release the RESET button and wait for the system to reboot. This will take about 15 seconds.

Installing the Memory Card



Class 4 or higher Micro SD memory card required (up to 32GB) for normal use.

Indicator Light




When the red indicator light flashes quickly, it is in setting mode and means you can setup the camera via your mobile device.

When the blue indicator light is steady, it indicates that the camera is connected to Wi-Fi.

Camera Operation


Preparations Before Use

Mobile Device System Requirements:
 Android Phones and Tablets with OS 4.4 or higher
 iPhones and iPads with IOS 9.0 or Higher




How to Install the App

Use your mobile phone or tablet to search for 'Vivitar Smart Home Security' in Google Play (for Android OS) or in the Apple App Store (for iOS), or scan the below QR Code to find the app and install it according to the instructions.



4 Connecting Your IP Camera with the App


Note: Your IPC Camera is supported only on a 2.4GHz Wi-Fi network. For setup, make sure your mobile device is connected to a 2.4GHz Wi-Fi network.



- After installing the 'Vivitar Smart Home Security' app, launch the app and tap = **Add device** from the 'Devices' screen to add your IP Camera.


- Tap **IP Cameras** on the 'Add new device' screen.
- Select your IP Camera from the list of devices. You will be prompted to sign in to your IP Cameras Account. If you have an account, enter your email and password and tap **Sign In**. If you do not have an account, tap **Create account** to create one.
- Plug in your camera and wait a few moments until the red LED light blinks then tap **Continue**. Note: If you do not see a red blinking light, then follow the instructions on the screen to reset your camera.

- The 'Configure Network' screen appears with your connected Wi-Fi automatically displayed. Enter the Wi-Fi network password and then tap **Continue** to view the 'Connecting' screen.
- Once successfully connected, the 'Add to Account' screen appears. Enter a name for your camera in the 'Set Name' field and a name for your room in the 'Set room' field for select a room from the list provided. Tap **Done** to complete the camera setup and enter the 'Devices' home screen.



5 Using the Smart Home Security App

- After initial setup is complete and your camera is connected to the App, the 'Devices' home screen displays the devices. Tap **IP Cameras** to open your camera's Live Camera view with streaming video. If you have multiple cameras connected, first select your camera from the list and then the Live Camera view appears.
- The selected camera's capture settings can be changed by tapping the Settings button.
- You can capture your data by taking snapshots and recording videos.



App Menu Away / Home Modes

For more information about the 'Vivitar Smart Home Security' app features, please refer to the User Manual. The User Manual can be accessed from the 'Help' in the app's menu option.

Troubleshooting

In the mode of local accessing, there is no way to connect the smartphone or tablet to the camera.

- >Make sure that the power plug is properly plugged in.
- >Make sure that the camera is enabled, and that the indicator of power/status light is red and flashing quickly.
- >Make sure that the camera and smartphone/tablet are located within an effective receiving distance.
- >Reset may be needed for the camera. Please use the Setup tool to press the reset button, then the camera will change to setting mode. The red indicator will flash quickly, and you can then configure the network to connect the camera.

In Internet accessing mode, the smartphone/tablet fails to connect to the camera by Wi-Fi.

- >Make sure that the power plug is properly plugged in.
- >Make sure that camera is enabled, and that the indicator of power/status light is red.
- >Make sure during setup of the camera's Wi-Fi network, the correct password is entered for the Wi-Fi router.
- >Make sure that the camera and Wi-Fi router are located within an effective receiving distance.
- >Make sure that your smartphone/tablet has successfully connected to Internet by Wi-Fi.

Technical Support and Warranty Information

For technical support issues please visit our website at www.vivitar.com. You can find manuals, software and FAQs on the website. Can't find what you are looking for? E-mail us at support@vivitar.com and one of our technical support team members will answer your questions. For phone support in the US please call 1-800-592-9541, in the UK call 0800 917 4831 in Australia call 1800-006-014. If you are calling from anywhere else, please visit www.vivitar.com for your local toll free number.

Warranty Information:

This warranty covers the original consumer purchaser only and is not transferable. Products that fail to function properly UNDER NORMAL USAGE, due to defects in material or workmanship will be repaired at no charge for parts or labor for a period of one year from the time of purchase.

What Is Not Covered by Warranty:

Damages or malfunctions not resulting from defects in material or workmanship and damages or malfunctions from other than normal use, including but not limited to, repair by unauthorized parties, tampering, modification or accident.

What To Do When Service Is Required:

When returning your defective product (postage pre-paid) for service, your package should include:

- Copy of original bill of sale
- A detailed written description of the problem.
- Your return address and telephone number (Daytime)

MAIL TO THE APPROPRIATE ADDRESS BELOW:

Sakar / Vivitar International
 Attention: Service Department
 195 Carter Drive
 Edison, NJ 08817

Sakar / Vivitar UK
 2D, Siskin Parkway East
 4020 Middlemarch Business Park
 Coventry, CV3 4SU

For Australia Customers Only
 Return faulty camera to the Refund Counter at the store where purchased.

This device complies with the part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with instructions may cause harmful interference to radio or television reception, which can be corrected by turning the equipment off and on. The user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into a circuit different from that to which the receiver is connected.
- Consult the dealer or experienced radio/TV technician for help.

