





User's Manual

LAUNCH TECH. CO., LTD.
Launch Industrial Park, North of Wuhe
Avenue, Banxuegang, Longgang,
Shenzhen, Guangdong,
P.R.China, 518129
Tel: +86-755-84528767
http://www.cnlaunch.com

1. Product Components

1.1. Ports & Indicators



Fig.1-1 Product illustration

No.	Name & Functions
0	OBD-16 diagnostic connector: t connect vehicle's OBD2 diagnosti socket.
2	Power indicator(Red) and workin indicator(Blue)

1.2. Accessories

- DBScar II x 1:
- Quick start guide x 1
- Upgrade tool installation CD x 1
- Connector Extension Cable x 1

2. Technical Specifications

- Working voltage: 9~18V
- · Working current(average): 35mA
- Working temp: -20 to 65°C (-4 to 149 °F)
- Storage temp: -40 to 85°C (-40 to 185 °F)
- · Storage humidity: <80%
- Working humidity: <60%
- Size(L*W*H): 53*30*24mm

3. Connected to vehicle

- Locate vehicle's DLC socket: it provides standard 16 pins and is generally located on driver's side, under the dash, for the detail position, please refer to automobile repair manual.
- Plug the DBScar II into DLC socket and the power indicator on DBScar II will light up about 3c.




Fig. 3-1

4. Installing Software

DBScar II APP is free to download.

- 1) Turn on your mobile smart device and link the network well:
- 2) Go into "App Store" (for iOS) or "Google Play" (for Android), search the key word "DBScar", click DBScar II software client to download and install (for details, please refer to the corresponding user's manual).

5. Bluetooth Setting

Enter bluetooth setting interface, set bluetooth ON and scan for devices, the system will list out the search result. click the desired one to pair(the default name is DBS XXXXXXX, where XXXXXXX is the last 7 digits of product SN.

NOTE: Before operating, bluetooth must

be paired. Meanwhile, please make sure the communication distance between your phone and connector is kept within 2 meters to get better results.

6. Using DBScar II

To perform this function, please confirm the following work has completed.

- 1) Bluetooth has been connected;
- 2) Connector has been connected to vehicle;
- Mobile client software has been downloaded and installed.

FCC STATEMENT

- This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
- This device may not cause harmful interference.
- (2) Theis device must accept any interference received, including interference that may cause undesired operation.
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be

determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receivingantenna.
- Increase the separation between theequipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

-1- -2- -3- -4- -5- -6- -7-