

OUTDOOR MACHINE Instruction manual

Prepare by :Wilson

Date : 20, SEP, 2009

Technical Index :

Operation Power : 3V Dc battery

Maximum transmitting power : less than 20mW

Working temperature : -20 to 60 degree

RF frequency : 912.45MHz

RF Modulation : FSK Modulation

Instruction :

1 : Function

1.1 : Connect the 3V battery to battery socket in the OUTDOOR MACHINE

1.2 : When the OUTDOOR MACHINE sensor detects human moving and it will transmit RF signal to Detector

2 : ID code select

Set matching 8 pole House Data Code on OUTDOOR MACHINE emitter via Dip switches, ID code setting must be the same as the receiver unit

Battery installation :

The power of the OUTDOOR MACHINE emitter is use 3V Dc battery, method of replacing battery: open the housing cover then you can see the position of battery. When replace the new battery, ensure correct polarity is respected . After replace the new battery and then recover the housing, the OUTDOOR MACHINE emitter will back to operation status.

FCC Warning Statement

FCC NOTE :

THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER AUTHORITY TO OPERATE THE EQUIPMENT.

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions :

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.