

FRONT


**SHARPER
IMAGE®**



User Guide

STBT13
FCC ID: YGKSTBT13

In the Box




Wireless Earbuds

Micro USB Charging Cable


Charging the Earbuds

1. Insert the micro USB charging cable into the micro USB charging port on the earbuds.
2. Insert the larger end of the micro USB charging cable to an available USB port on your computer or AC Adaptor (not included).
3. The LED indicator remains RED when the earbuds are charging and will turn BLUE when they are fully charged.
4. When the earbuds have fully charged, carefully remove the micro USB charging cables from the earbuds.



NOTE: A low battery alert will announce that the earbuds must be charged. The LED indicator will flash red and a voice prompt "Low battery. Please charge" is heard.

Location of Controls




Location of controls:

1. Left earbud
2. Right earbud
3. MFB (Multi Function Button)
4. LED indicator
5. Microphone
6. Micro USB charging port
7. Left ear hook
8. Right ear hook

Pairing the Earbuds

NOTE: For easy pairing with your mobile device, Make sure that both earbuds are fully charged.


1. Press and hold the Multi Function Button on both earbuds for approximately 6 seconds. A tone is heard, indicating that the earbuds are in pairing mode. The LED indicators on both earbuds will quickly flash RED and BLUE.



Multi-Function Button

2. Open the Bluetooth Settings menu on your mobile device.
3. Locate the earbud's model (STBT13) from the list of discovered devices.
4. Press the earbud's model number (STBT13) to pair your speaker to your mobile device.
5. Another tone is heard, indicating that both devices have successfully paired.

On an iOS or Android Device
• Go to **SETTINGS > BLUETOOTH**
(Make sure Bluetooth is turned ON)



i If a previously paired device is in range when the earbuds are turned on, the headset will connect to it automatically.

BACK

Troubleshooting

Problem Description	Cause	Solution
Earbuds fail to Power On.	Battery life is depleted. Releasing the Multi-Function Button too early.	Use the charger to fully charge the battery. Long press the Multi-Function Button.
Charging function is failed.	The charging cable is not properly connected.	Reconnect the charging cable to the charging port.
Power off function is failed.	The earphone program is in error due to an incorrect operation.	Use the charger to charge and reset the earphone.
The earbuds cannot be searched or pairing fails.	The earbuds are unable to enter pairing mode. The bluetooth application cannot locate the earbuds.	Make sure that the earbuds are fully charged. Close the Bluetooth settings menu on your phone and start again.

i Make sure you charge your earbuds for at least 2 to 3 hours before using them for the first time.

Legal Information

READ CAREFULLY AND KEEP THIS MANUAL

Caution: Any changes or modifications not expressly approved could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undersired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Limited Warranty

90 Days Limited Warranty
In the unlikely event that this product is defective, or does not perform properly, you may within ninety (90) days from your original date of purchase return it to the authorized service center for repair or exchange.

TO OBTAIN WARRANTY SERVICE:

- Call the Customer Support number located below, or go to our website portal to receive a SRO number.
- Provide proof of the date of purchase within the package (dated bill of sale).
- Prepay all shipping costs to the authorized service center, and remember to insure your return.
- Include a return shipping address (no P.O. Boxes), a telephone contact number, and the defective unit within the package.
- Describe the defect or reason you are returning the product.

Your product will be repaired or replaced, at our option, for the same or similar model of equal value if examination by the service center determines this product is defective. Products received damaged as a result of shipping will require you to file a claim with the carrier.

The shipping address of the authorized service center is:
Customer Service Dept. 36
c/o Southern Telecom
400 Kennedy Drive
Sayreville, NJ 08872

Should you have any questions or problems concerning this product, please contact our customer service department at:
Customer Support:
Phone: 1-877-768-8481
Monday-Friday 8AM-10PM(EST)

www.southern telecom.com
Click on "Product Support"

Warranty service not provided
This warranty does not cover damage resulting from accident, misuse, abuse, improper installation or operation, lack of reasonable care, and unauthorized modification. This warranty is voided in the event any unauthorized person opens, alters or repairs this product. All products being returned to the authorized service center for repair must be suitably packaged.

Limitation of Warranty:

- THE WARRANTY STATED ABOVE IS THE ONLY WARRANTY APPLICABLE TO THIS PRODUCT. ALL OTHER WARRANTIES, EXPRESS OR IMPLIED (INCLUDING ALL IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE) ARE HEREBY DISCLAIMED. NO VERBAL OR WRITTEN INFORMATION GIVEN BY AIT, INC. ITS AGENTS, OR EMPLOYEES SHALL CREATE A GUARANTY OR IN ANY WAY INCREASE THE SCOPE OF THIS WARRANTY.

- REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER. AIT, INC. SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT OR ARISING OUT OF ANY BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT. THIS DISCLAIMER OF WARRANTIES AND LIMITED WARRANTY ARE GOVERNED BY THE LAWS OF THE STATE OF NEW YORK. EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED TO THE APPLICABLE WARRANTY PERIOD SET FORTH ABOVE.

Some states do not allow the exclusion nor limitation of incidental or consequential damages, or limitations on how long an implied warranty lasts so the above limitations on exclusions may not apply to you. This warranty gives you specific legal rights, and you also may have other rights that vary from state to state.

Sharper Image® name and logo are registered trademarks. Manufactured and marketed by Southern Telecom under license. © Sharper Image. All Rights Reserved.

SHARPER IMAGE®



Questions and Customer Support

For further assistance or troubleshooting, please call our customer support line:

Phone: 1-877-768-8481
Monday-Friday 8AM-10PM (EST)

www.southern telecom.com
Click on "Product Support"