

Please read this guide before using.

Welcome:

Thank you for choosing this product from **Skyworth**. By reading this manual, you can not only appreciate its perfect functions & brief operation introduction, but also have a comprehensive understanding of how to use this machine.

Statement:

This manual is provided just to guide you about the functionality of the product, and it does not make any explanation for its hardware/software configurations. Products and fittings may vary depending on where you purchase them.

The product is available for network environment GSM/GPRS/EDGE/WCDMA/HSDPA. Certain functions may require the support of network operator or service provider, please refer to the user guide for related details.

No part of this document can be reproduced without permission.

The machine recommends you to use the preinstalled Android operating system. Install non-preinstalled operating systems or other operating systems which are not covered in this user guide are not forbidden, however, we can neither ensure their stability,

reliability or safety when running in this machine owing to lack of strict testing, nor guarantee to provide drivers of other operating systems. The mentioned non-preinstalled operating systems include upgrade version or prior version of the preinstalled operating system and other different operating systems. For this machine, preinstalled operating system or any internet application functions are separable to the functions of the machine itself. Interpret any preinstalled software functions as the functions of the machine itself are incorrect. For any hardware or software provided by third party, **Skyworth** does not make any promise or service for its usability or reliability.

For your safety, please read "Safety Precautions" carefully.

Icon illustration:



Indicating warning information which you need to pay special attention to.



Caution.



Indicates special illustration or prompt about usage of the product.

[] Indicates operation of a key

Boldface Indicates an interface menu or icon operation.

Content

Safety Precautions

Disobey these rules may bring danger or violate law.



Driving:Do not use the machine while you are driving. Please use earphone or pull over and stop your automobile to dial or

listen to a call.



Medical devices:Follow any special regulations in force in any area such as hospitals and always switch off your machine

whenever it is forbidden to use it.



Airplane:Wireless devices can cause interference in aircraft. Please strictly obey the relevant regulations.



Oil station: Turn off your machine before entering a place susceptible to explosion, such as an oil station, oil tank or

chemical plant



Avoid interfering blasting: Turn off your machine in a place where a blasting process is under way, and obey any relevant

rules.



Interference: All wireless phones may be subject to interference, which could affect their performance.



Accessories: To ensure best performance, please use approved accessories and battery & do not connect your machine to

an incompatible product.



Waterproof: The machine does not possess waterproof function, please keep it dry and get it stay away from water.



Environmental recycling: Dispose used batteries in accordance with local regulations. Always recycle. Do not dispose

used batteries in a fire.



Connection: When connecting to other devices, please read user manual of target device to ensure safety.



Children's safety: Keep the machine and all its fittings beyond children's reach to avoid potential danger.



Data backup: Please backup important information stored in your device in case of unexpected losing. Not all video files are supported by the machine.



SOS: With the device, you can dial an emergency call under power on status when you are in service zone. Dial the emergency number and tell your location.

1. Get to know PAD

	Power key: Press it for about 3sec can power on/off the machine; under power on status, press it can turn off screen backlight.
	Home key: In any interfaces, press it can exit the current function and return to the home screen; in any interfaces, long press it can open the most recently used applications screen.
	Menu key: Press it to obtain more options.
	Return key: Press it to return to last menu.

Getting started

Install UIM/SIM card



Please make sure the machine is powered off before installing or taking out UIM/SIM card.

Insert or withdraw UIM/SIM card while it is in using, the machine would automatically power off for protecting UIM/SIM card!

UIM/SIM card is provided by service provider, it can store some basic data, e.g. contact name and phone number. Note: Some

UIM/SIM cards may not be compatible with this machine, under these circumstances, please consult service provider to replace

them.

The machine has an internal rechargeable battery. The battery isn't user accessible and should only be replaced by an Authorized Service Provider. The performance of a battery is subject to multiple factors: radio network configuration, signal strength, ambient temperature, and the voice, data or other application mode you choose to use.



To avoid self-ignition and burning:

- **Do not unpack or maintain battery on your own.**
- **Do not disassemble, extrude or perforate battery; do not short-circuit the battery;**
- **do not dispose used batteries in a fire or water.**
- **Do not place your device in temperatures above 60 C (140 F).**
- **Use only approved batteries.**
- **Please dispose battery correctly & do not discard it casually.**

Install UIM/SIM card

Insert UIM/SIM card into card slot as the image indicates. (Note: please pay attention to the notch of UIM/SIM card and do not

install it in a wrong direction.)

Install storage card

Install storage card to expand its storage space. (This machine use MicroSD storage card).

1. Install storage card:

Place its golden contactor side downward and insert it into card slot as the image indicates, then press it downward gently till you hear a click sound.

2. Take out storage card:

Gently press the MicroSD inward, the MicroSD will automatically pop out, and now you can take storage card out.



You are recommended to use the original standard MicroSD card or some famous mainstream brand MicroSD card such as SanDisk and Kingston. Some MicroSD cards may not be compatible with this machine, please confirm its compatibility before purchasing.

The T-Flash card is a miniature object. Keep it out of the reach of children for fear that children may swallow it!

Charging the battery

Using a travel adapter to charge the battery:

1. Connect USB cable with travel adapter.
2. Connect the USB cable interface with the Mini USB interface of the machine, and connect travel adaptor to standard power supply jack.
3. The battery symbol indicates the charging status. While charging, the charge indicators will scroll. When all the scroll bars are steady, the battery is fully charged.
4. After charging, please disconnect charger from AC power supply jack in time, and then disconnect other connections.

Please charge an exhausted battery in time, excessive discharge may damage battery.

During the course of charging, it is normal to find the battery and the device slightly heat-up.

This product only supports designated charger, other chargers can't fully charge it.

If the machine is very low in power and powered off, it may require you to charge for five to ten minutes before you can use it.

Press (Power key) for about 3sec can power on/off the device.

Password

PIN code

The PIN (Personal identification number, 4 to 8 digits) code prevents your SIM card from being used by unauthorized people. In general, the PIN is supplied with SIM card by the network operator. If PIN check is enabled, you need to input the PIN each time when you power on your machine. The SIM card will be locked if you input wrong PIN code for three consecutive times. For details, please contact the network operator.

PIN2 code

The PIN2 code, supplied with SIM card, is required to access certain functions. If you input wrong PIN2 for three consecutive times, the PIN2 will be locked, and you need to input correct PUK2 to unlock the PIN2. For details, please contact the network operator.

PUK and PUK2 code

PUK and PUK2 code are supplied with SIM card. If not, contact your network operator. If you input wrong PIN/PIN2 code for three consecutive times, you would be required to input PUK/PUK2 code.

If you input wrong PIN code for three consecutive times, your SIM card would be locked. Please contact network operator in search

of help to unlocking code immediately. Trying to unlock the code by user self may result in an invalid SIM card.

2. Quick Start Guide

Read this Quick start guide to learn about Pad features on how to use the controls, and more.

Turn on/off screen

1. Turn off screen

You can turn off screen by pressing (Power key) .Once turned off, nothing happens if you touch the screen & this also benefit for saving battery capacity.

2. Turn on screen

To turn on screen, press power key to light screen.

Lock and unlock

You can lock your device and screen to prevent casual operations.

1. Lock device

Short press (power key) . Note: if you don't touch the screen within system default time period or a set time period, the device would lock automatically.

2. Unlock device

Short press (power key) , then drag slider rightward to unlock.

Home screen

By using touch screen you can realize each function of the device. The device provides you with five home screens, slide your finger leftward or rightward on touch screen can switch between them. Press Home key at any time can go to Home screen. You can tap any icon to open its corresponding application.

You can click Application Tray to view all applications.

You can increase or decrease screen icons as per your requirement. For details, please refer to basic settings.

Status bar icons

Icon	Description
	Network Signal
	3G Data Connection
	Airplane Mode
	Battery Capacity
	WLAN Signal
	Without SIM Card
	Without T-Card
	Notification
	Bluetooth Activated

	GPS Activated
	Missed Calls
	New Message
	New Mail
	Silent
	Vibrate
	Alarm
	USB Connection

If there are missed calls or new messages, prompt message would display on notification indication bar at the top of the screen.

Gently drag notification indication bar down to show all prompt messages. By clicking each prompt message you can view new messages or missed calls.

Application menu

By clicking Application tray on home screen can you visit all applications & set system related parameters.

Click **Home screen tray** to return to Home screen.



Set time and date

You can set date, time, time zone and format.

In application interface, click **Settings> Date & time**.

Date and time settings include: **Automatic, Set Date, Select Time Zone, Set Time, Use 24-hour Format and Select Date**


Format.

Automatic can be checked only after insert an UIM/SIM card.

Make a call

Dial from dialpad

1 Tap **Application tray>Dial** application to open dialpadscreen



2 Input target phone numbers by tapping onscreen keyboard, tap  to dial.

While inputting phone number, you can tap  to delete wrong character.

Dial from contacts

1. Tap Application tray >Dial>Contacts or tap Contacts directly.
2. Select & tap a contact to open contact menu.

3. Click  to make a call.

Dial from call log

1. Click Application tray>Dial>Call log.
2. Slide to a target phone number or contact, tap  to make a call.

Dial from Favourites

You can dial a most contacted phone number through Favourites.

Click Application tray >Dial >Favourites.

Select a target contact, tap  to make a call.

Create a Favourite contact

1. Tap Application tray>Dial>Contacts.
2. Select & tap a contact to open contact menu, then tap  to add contact to Favourites.

To delete a contact from Favourites, please tap  in the contact menu again.

Answer incoming calls & View missed calls

Answer incoming calls

To answer an incoming call, please drag rightward the green answer key; To reject an incoming call, please drag leftward the red end key.

View missed calls

When there is a missed call, in the status bar, a missed call icon will display. Slide downward the status bar can you view the missed calls.

Or you can click Application tray>Dial>Call log to view missed calls.

You can send and receive short messages and multimedia messages which contain multimedia files.

Tap **Application tray>Message** to enter message function.

Text Input and Smart Phone Settings

Text Input

When editing text, you can use Android keypad or Google Pinyin input method to edit Chinese, English, Number, Symbol, etc. e.g.

Add contact information, compose messages, etc.

Switch Input method:

1. Open text edit interface.
2. Hold and press text edit region to pop out an Edit text menu.
3. Tap input method, check a target input method in the input method menu.



Smart Phone Settings

Sound setting

You can set your favourite ringtone as incoming call ringtone.

Ringtone settings

1. In the **Application menu**, tap **Settings> Sound and Display> Pad ringtone**.
2. Drag upward/downward the ringtone list, tap ringtone name can audition, select & tap your favorite ringtone then click OK can you save ringtone settings.

Set song as ringtone

You can also set songs which are stored in SD card as incoming call ringtone.

In **Application menu**, tap **Music> Songs**.

Drag upward/downward the song list, press & hold your favorite song to pop out an option box, tap **Use as Pad ringtone** to save the song as incoming call ringtone.

Before this operation, please make sure a SD card which is loaded with song(s) has already inserted.

Set ringtone volume

1. In Application Menu, tap Settings > Sound and display > Ringtone volume.
2. Drag incoming call volume indicator to adjust ringtone volume, tap OK to save settings.
3. Under home screen interface, you can press side volume key to tune ringer volume; you can set ringer to vibrate and silent mode by pressing decrease volume key till the ringer volume indicator turns empty.

You can long press Power key to pop out Device options. Here, you can select silent mode to set device to silent mode directly.

Screen settings

Set wallpaper

1. In Home screen interface, press (Menu key) to open Menu options.
2. Tap Wallpaper>Wallpaper gallery, Current wallpaper or Gallery.
3. Drag wallpaper thumbnails, then select your favourite image and tap Set wallpaper.

Dynamic wallpaper

You can also set screen as dynamic wallpaper.

1. In Home screen, press (menu key) to open menu options.
2. Tap Wallpaper>Current wallpaper.
3. Select your favourite dynamic image, tap Set wallpaper.

Set screen brightness

1. In Application menu: Tap Settings> Sound and display> Brightness.
2. Slide to adjust brightness, tap OK to save settings.

Set screen timeout

You can adjust the delay before the screen automatically turns off.

1. In Application menu, tap Settings> Sound and display> Screen timeout.
2. Select a time as per your need.

Security settings

Factory data reset

1. In Application menu, tap Settings> Privacy > factory data reset.
2. Tap reset Pad.
3. Tap Erase all data, the device will reboot and restore factory settings.

Home screen settings

The device provides you with five Home screens, slide your finger leftward or rightward on touch screen can switch between them.

Press Home key at any time can go to Home screen.

You can add Shortcuts, Widgets, Folders and Wallpaper to home screen as per your need.

Add Shortcuts to home screen

1. In Home screen interface, press (Menu key) to open Menu options.
2. Tap Add>Shortcuts.
3. Tap target shortcuts to save them to home screen.

Add widgets to home screen

1. In Home screen interface, press Menu key) to open Menu options.
2. Tap Add>Widgets.
3. Tap target widgets to save them to home screen.

Delete icons on home screen

1. In Home screen interface, press & hold a target icon until the icon  display on the bottom of home screen, drag the target icon



to delete the icon.

4. Internet

Browser

You can use the Browser to visit web pages and applications which are based on network. Please consult network service supplier, if necessary, about how to connect.



CAUTION
Network connection type depends on your network service supplier, and network connection fees may vary according to connection types. Please consult your network service supplier for specific fees.

In **Application menu**, tap Browser.

After opening browser, an address field will occur, tap & input a target web address, then tap **start** to visit web page.

Press (menu key) and the following options will pop out.

New window: To add a new window;

Exit: To exit the browser;

Bookmarks: To save your favourite webpage;

Windows: Tap this key can switch and manage all opening windows; and you can tap new window to create a new one. Tap the key again can close switch window interface.

Refresh: To refresh current webpage;

More: To pop out more option menus which include Forward, Back, Add bookmark, Select text, Find on page, etc.

Bluetooth connection

The device supports Bluetooth Wireless Connection. You can build wireless connection between the device and Bluetooth earphone accessories, hands-free kits for card, computer or other devices to achieve data exchange.



Some region may forbid or restrict the usage of Bluetooth device and its accessories. Please abide by local laws and regulations. To ensure maximum Bluetooth security, please use your Bluetooth device in safe and non-public places.

Turn on/off Bluetooth

1. In **Application menu**, tap **Settings>Wireless & networks**.

2. Tap Bluetooth, when Bluetooth status indicator  is highlighted it means Bluetooth already turned on. In the meantime, the status bar at the top of the screen will display a Bluetooth  indicator.

To save battery capacity & ensure maximum Bluetooth security, please turn off Bluetooth when you don't want to connect other devices. You need to turn on Bluetooth again to allow other devices to connect to your pad.

Bluetooth settings

In **Application menu**, tap **Settings> Wireless & networks > Bluetooth settings**.

Bluetooth settings include the following operations:

Connect to new devices

1. Please ensure Bluetooth already turned on & visible & within suitable distance (about 10m).
2. In **Application menu**, tap **Settings> Wireless & networks > Bluetooth settings**.
3. Tap **Scan for devices**, and the pad will display all available devices.

4. Tap the target device, then tap pair with the device or input device password (the default password is 0000) to connect with it.

Relevant Bluetooth devices have specific functions. For detailed connection and usage, please refer to relevant user guide.

WLAN

You are able to connect to WLAN to surf internet or download with wireless network.

Connect to WLAN

1. In **Application menu**, Tap **Settings>Wireless & network**.
2. Tap **WLAN**, when **WLAN** status indicator is highlighted, it means **WLAN** already turned on. In the meantime, the status bar at the top of the screen will display a **WLAN**indicator.

To maximum battery life span, please turn off WLAN when you don't need to use it.

WLAN Search and Connection

1. In **Application menu**, Tap **Settings> Wireless & network > WLAN settings**.
2. Tap **WLAN** to turn it on & scan available network. If **WLAN** already turned on, press menu key to open Menu options>Scan.

The device will list all available networks.

3. Tap a target network, and then tap Connect.
5. If you try to access a secured connection, you will be prompted to enter a password. When the device is connected to a network, a wireless indicator will display on status bar.

5. Contacts

This function enables you to save contact name, phone number, email address, etc.

View contacts

In **Application menu**, Tap **Contacts** to open **contacts list**.

Drag contacts list upward or downward to view more contact.

Press (menu key) to open **Menu options** to perform further operations: **Search, New contact, Accounts, Import/Export**, etc.

Create New contact

1. In Application menu, Tap Contacts to open contacts list.

2. Press (menu key) to open **Menu options** tap **New contact**.

3. Tap corresponding item to input relevant contact information.

After finishing inputting, tap **Done** to save contact.



Edit contact

1. In **Application menu**, Tap **Contacts** to open contacts list.

2. Select & tap a target contact to open contact menu, the press(Menu key)to open **Menu options> Edit contact**.

3. After finishing inputting relevant information, tap **Done** to save contact.

Delete contact

1. In **Application menu**, Tap **Contacts** to open **contacts list**.
2. Select & tap a target contact to open contact menu, the press(Menu key)to open **Menu options> Delete contact**.

Import/Export contact

1. In **Application menu**, Tap **Contacts** to open **contacts list**.
2. Press(Menu key)to open **Menu options> Import/Export**. You can select Import from **SD card**, **Export to SD card**, etc.
3. After selecting import/export type, select contacts and tap **Done**.

6. Messaging and Email

Messaging

You can send and receive short messages and multimedia messages which contain multimedia files.

Create short messages

1. In **Application menu**, tap **Messaging> New message**.
2. Select & tap relevant message type, then tap **Type to compose** textbox.

Input content, then tap **SEND** key to send message.

Messages will display in thread style instead of inbox and outbox to facilitate your reference.

Reply to a message

When you received a new message, a prompt will display on the notification indication bar. You can reply to it after reading.

1. In **Application menu**, tap **Messaging> New message**.
2. Tap Recipient to edit message receiver, or tap  to add from contacts.
3. Tap **Type to compose** to input message content.
4. Tap **SEND** to send the message.

Create multimedia message

1. In **Application menu**, tap **Messaging> New message**.
2. Tap Recipient to edit message receiver, or tap to add from contacts.
3. Press (Menu key) to open **Menu options>Add subject**, tap Subject to input multimedia Message subject.
4. Tap **Type to compose** to input message content, then press key to send message.

You can press (Menu key) to open **Menu options** to Add **Attach, insert smiley, etc.**

Manage messages

Delete messages

Open a thread, hold and press a message to pop out a dialog where you can select **Delete message** to delete the target message.

Delete thread

Press and hold a thread to pop out a dialog where you can select Delete thread to delete a target thread.

Forward messages

Open a thread, press & hold a message to pop out a dialog where you can select **Forward** to forward the message.

Email

You can use the Email application to read and send email.

You should configure Email box before sending and receiving Email.

Email application sends and receives email by internet connection mode. Please consult service supplier for specific setup parameters.

Configure Email

1. In **Application menu**, tap **Email**.
2. After inputting Email address and password, tap **Next**. Setup account name, your name and signature, then tap **Done**.

You can also configure Email account manually:

1. Input Email address and password
2. Tap **Setup manually**, and then select Email account type.
3. Set specific information of server.
4. Tap **Next** or **Done** to complete setup.

Send Email

You can send Email to one or multiple recipient.

Before sending, you can add recipient email address manually or from Contacts.

1. In Application menu, tap Email.
2. Press (Menu key) to open **Menu options**, tap **Compose** to open Email edit screen.
3. To enter recipient, please tap recipient to input recipient email address. If necessary, tap (**Menu key**) to open **Menu options>Add Cc/Bcc** to address a copy or blind copy of the message.
4. Tap Subject to enter subject.
5. Tap text input region to input email content.

6. Press (Menu key) to open Menu options, tap Add attach to insert attachment.
7. Tap Send to send the Email.

Receive Email

1. In Application **menu**, tap Email.
2. Press (Menu key) to open **Menu options**, tap Refresh.
3. The device will connect to server and download emails automatically. New Emails will be saved in inbox.
4. Tap an email to read it.

While reading Email, press (Menu key) to open Menu options, and now you can tap **Forward** to forward the Email to others. Or you can tap Reply to edit and send an Email to the sender.

7. Multimedia

Audio player

It's convenient for you to use Audio player to play your favourite Music files.

Before playing music, please ensure a SD card which is loaded with music files has already inserted.


In Application menu, tap Music to open Audio player interface.

Music files will be categorized by Artists, Albums, Songs or Playlists. You can tap a category and select music file to play.

Play music

Select & tap a song to play it.

While playing music, you can press side key to tune volume.



Video player

It's convenient for you to use video player to play your favourite video files.

Before playing video, please ensure a SD card which is loaded with video files is inserted.

In **Application menu**, tap **Gallery**.



Play video

Select & tap a video to play it.

While playing video, you can pause playing or drag progress bar to forward/rewind playing process. Side key can be used to tune volume.

Sound recorder

In **Application menu**, tap **Sound recorder**.



Please ensure a **SD card** is inserted before using the sound recorder.

8. Other applications

Alarm

In Application menu, tap **Alarm**.

Add alarm

Press (Menu key) to open **Menu options**> Add **alarm**. Then you can edit Alarm and tap **Done** to finishing setting.

In Alarm screen, select & tap a status indicator which situates at the right side of the alarm to turn the alarm on. When the status indicator is highlighted, it means the alarm is turned on.

When the preset alert time is up, it gives off an alert tone. Select Stop to stop the ring or Snooze to temporarily stop the ring. If you select Snooze, the alarm clock will ring later.

Calendar

In Application menu, tap Calendar to open calendar application where you can arrange and manage to-do events.

You can view the calendar by day, week or month.

To use calendar, you need to set correct time and date beforehand.

Create new event

Press (Menu key) to open **Menu options> New event** to add new event.

1. Enter a name and optional additional details about the event, set begin and end time and its urgency degree.
2. After finishing inputting, tap **Done** to save the event.

Manage agenda

Before viewing or editing **agenda**, you should create one.

Tap an **agenda** and all existed agendas will display.

Add reminder

Tap and agenda to enter **View event interface**, open **Menu options> Add reminders**.

Edit event

Press & hold an agenda to pop out a dialog where you can select Edit event.

Delete event

Press & hold an agenda to pop out a dialog where you can select Delete event.

Calculator

In Application menu, tap **Calculator**.

The device supports simple arithmetic problems +, -, ×, ÷.

This calculator provides limited precision and is only applicable to simple arithmetic calculation.

Navigation

In Application menu, tap Navigation.

You can press (Menu key) to open **Menu options** to perform corresponding operations.

This function only limits to outdoor usage, specific details depend on **UIM/SIM** card and the data service type that you applied to, and it may produce corresponding fees, please consult service supplier for specific charge standard.

9. Battery and Device Maintenance

Battery maintenance

1. The device has an internal rechargeable battery. Please charge battery in time when battery level is low.
2. When it is not in using, please disconnect charger and power supply. Please do not connect battery and charger for over a week, excessive charging will shorten battery lifespan.
3. During charging, ensure the battery is placed in a room temperature environment or in an environment close to room temperature.

4. Short-circuits of the battery may cause explosion, fire, personal injury or other severe consequences!
5. Do not use a damaged battery.
6. Put battery in excessive cold or heat place will shorten battery lifespan, and may degrade device performance.
7. Dispose used batteries in accordance with local regulations. Always recycle. Do not dispose batteries in a fire.

Device maintenance

The following suggestions will help you take care of your device:

1. Keep the device and all its fittings beyond children's reach.
2. Keep the device dry. Keep away from rain, moisture, liquid or other substances that may corrode electronic circuits.
3. Do not store the device in a high-temperature place. High temperature will shorten the life of electronic circuits and damage

the battery and some plastic parts.

4. Please do not try to open up or disassemble the device, unprofessional operation may leads to device damage.
5. Don't use strong acid or alkali cleaners to clean the device
6. Use only approved accessories and batteries. Violate these rules will result in ineffective warranty.

10. Tips and Troubleshooting

Fault	Probable cause
Cannot be powered on	The battery energy is exhausted; The battery is not in position.
(U)SIM card error	The metal face of the (U) SIM card is polluted. Clean the (U)SIM card with a clean cloth; Reinstall the (U)SIM card; (U)SIM card is damaged, please replace it.
Poor quality of calling	Check signal strength on display screen, 4-grid signal means strong signal; less than 2-grid signal means weak signal.
	Signals are obstructed. For instance, radio waves cannot be effectively transmitted

	<p>nearby a high building or in a basement.</p> <p>Line congestions occur when you use the device in high-traffic hours;</p>
	<p>Related to the distance of network-build base station. You may ask your network service Operator to inform you of the network coverage.</p>
Echo or noise	<p>Hang up the call, and dial again. Your network service operator may provide you with a better link when you retry.</p>
Calls cannot be dialled	<p>You might have set Hide ID, however, network operator do not provide this service; Strong interfering signal existed. Call barring is activated; It might have been because Line 2 is activated. However, network operator do not provide this service;</p>
The battery cannot be charged	<p>It might have been because the battery is excessively discharged, and it would take a few minutes before it begin to charge after connecting to charger; Battery performance deteriorated.</p>

Cannot connect the network	<p>The signal is weak; Or affected by radio interference; Check whether (U) SIM card is installed correctly, damaged or poor contacted. If damaged, please consult</p>
----------------------------	--

	network supplier.
Standby duration shortened	Standby duration is related to system settings of network. It is recommended that you turn off your device in area with no signal reception to save battery.
	Replace battery.
	In a weak signal region, the device will continuously search for a base station, thereby consume great amount of power and shorten standby time. Please move to a strong signal place or power off your device temporarily.
PIN error	Input incorrect PIN code for three consecutive times. Contact the network supplier.
	Contacts storage space not enough.

Cannot add records to Contacts

Delete some records.

Environmental protection illustration

Parts	Hazardous Substance					
	Plumbum (Pb)	hydrargyrum (Hg)	cadmium (Cd)	hexavalent chromium (Cr6+)	Polybrominate d biphenyls (PBB)	Polybrominated diphenyl ether (PBDE)
Phone	X	O	O	O	O	O
Battery	X	O	O	O	O	O
Accessories	X	O	O	O	O	O

O: Means content of the hazardous substance in all homogeneous material of the parts is under the limit of SJ/T 11363-2006 standard.

X: Means content of the hazardous substance in at least one homogeneous material of the parts surpassed the limit of SJ/T 11363-2006 standard.

Note: The reason for “X” is that there isn’t any alternative technique or parts at present.

Specifications

Display/Pantalla	7-inch 1024*600 LCD
------------------	---------------------

Platform/OS	Qualcomm Cortex A5 MSM8225 Dual-core 1.2Ghz
Internal memory (User Memory)	ROM 4G / RAM 512MB
External memory (Max. Support)	32G
Music Player	support MP1, MP2, MP3, WMA, WAV, OGG, OGA, APE, FLAC, AAC, M4A, 3GPP etc.
VDO Playback	support up to HD 2160P; support AVI, MPG, MKV, RM, RMVB, MP4, MOV, VOB, DAT, FLV, TS, 3GP, WEBM VP8), etc. 1080p decoder
Photo	support JPG, JPEG, BMP, GIF, PNG, JFIF etc., up to 8000 x 8000
Battery	4,000mAh Li-polymer
Camera Back (Pixel)	5.0M pixels
Camera Front (Pixel)	5.0M pixels
USB Port	5PIN MICRO

11. Battery Information

Type	Capacity
Li-polymer	4,000 mAh

- The battery life depends on many factors, including the SIM card, network conditions, settings, usage and environment.
- Making calls, turning on the backlight and music player will consume more battery power.
- The standby time is shorter when the network is not available than in the standard status.
- For power saving, the backlight turns off automatically if your phone stands idle for an assigned time.
- The performance of battery varies with the charging status, temperature, local radio wave and backlight status.

12. Warranty Condition for Product

1. Tablet and mobile charger are in-warranty of 12 months after the date of purchase.

2. Battery is in-warranty of 6 months after the date of purchase.
3. This warranty shall apply to Tablet and accessory under "Skyworth" brands that are purchased from Shop namely, Skyworth by Smart and Authorized Distributor or Authorized Service Center as appointed in Thailand only.
4. The condition of the warranty for Tablet and accessory that are purchased in other countries, except Thailand. It shall be applied in accordance with the applicable law. For Thailand, the purchaser acknowledges the end of warranty period as stated in the warranty sticker or purchase's record of Skyworth system.
5. Within the warranty period, maintenance or parts replacement is free of charge. Should be noted that Skyworth reserves the rights no return the damaged part.
6. Skyworth provides warranty for Tablet and accessory with the terms and conditions that are stated in the law excluding the commerce, product satisfaction, lost of benefit or expected profit, loss or damages from the violation of personal rights in conversation, and working discontinuance or loss of information arising of the use or inability to use.
7. In cellular network / signal and sounds that are used with Tablet and accessory is the service of independent operators, not Skyworth. Therefore, Skyworth will not be responsible for the working process, the readiness of the service, and the area covered.
8. Any Tablet and accessories that are already repaired or had parts replacement, the warranty period will continue from the

remaining

warranty onward or 60 days from the repaired date whichever is longer.

9. Customer has to pay for the repair cost and cost of replacement parts provided that the said repair are not in the warranty conditions.
10. 10. The warranty sticker on the Tablet must not be torn, tattered, scraped or crossed out.

The warranty shall not cover the following conditions:

1. Tablet and accessory are damaged due to the abnormal use, improper use, being stored in the damped or overheated area, or other inappropriate environment, the interference that can cause damage, including unforeseeable accident, spill with liquid or food, or any actions that cause damages to Tablet and accessories.
2. Tablet and accessory are damaged due to the natural disaster.
3. Tablet and accessory are repaired, changed parts, adjusted, modified, connected, customized without any authorization by Skyworth.
4. Using of Tablet and accessory together with, or connect with the Tablet or accessory that are neither provided nor certified by

Skyworth including any accessory are inappropriate to use together with Tablet and accessory.

5. Small alteration in the brightness and color on the screen might occur in each Tablet and accessory,
 1. might results in bright or dark dots on the screen. This is called as pixel defect. It can occur when these pixels
 2. are malfunction and cannot be modified. The Pixel defect of 2 pixels is considered acceptable. Small alteration in
 3. a picture taken by a camera might occur in each Tablet and accessory is considered normal and it is not the
 4. camera module to be deemed as malfunction.
5. Editing, scarping, crossing over the IMEI number of the Tablet or accessory, including the warranty number will be deemed as the termination of the warranty.
6. Damaging of the label, warranty sticker on the mobile will be deemed as termination of the warranty.
7. Skyworth will not assure provided that the software from Skyworth will be up to your wishes or the working process of the software will not be discontinued or flawless.
8. Skyworth will not assured provided that the additional software to download or install by you for the purpose of work or entertainment will be up to your wishes without mistakes and flaw that is out of control of Skyworth.
9. The warranty and responsibilities of Skyworth are not covered the malfunction of any software or access of information from virus, or unauthorized access, which cause the damage in the banking transaction, E-banking, or any important information, or

using the mobile phone illegally.

10. The warranty will not cover the loss of personal information during the use or during the installation, software remove, including applications, songs, videos, and any memberships that Customer has already purchased.
11. The warranty will not cover the responsibility of the loss of any personal information during the repair at Authorized Service center of Skyworth, including the applications, songs, videos, and any memberships that Customer has already purchased.
12. The warranty will not cover the damage that occurs from the use of any device under "Skyworth brand" with other products which are not the product of Skyworth.
13. The warranty will not cover any expenses in the co-ordination with Skyworth for solving the problem and the process of delivering for examination and repair service.

(1) This device is also designed to meet the requirements for exposure to radio waves established by the Federal Communications Commission (USA).

(2) The SAR limit adopted by USA is 1.6 W/Kg averaged over one gram of tissue. The highest SAR value reported to the FCC for this device type is compliant with this limit.

SAR information on this and other model device can be viewed on-line at <http://www.fcc.gov/oet/ea/fccid/>. Please use the device

FCC ID number for search, ZC4E7.

(3) This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

--Reorient or relocate the receiving antenna.

--Increase the separation between the equipment and receiver.

-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help.

(4) This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

(5) Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.