



Wireless FM Transmitter PWFMT3

Compatibility


Compatible with most audio devices such as GPS devices, Smartphones, Mobile Phones, and MP3 players.

Specifications

- Supports full frequency range (87.5 – 108 MHz)
- Powered by 12V DC outlet
- 3.5 mm input aux cable
- Standard-USB pass through connector
- SD/MMC slot

Package Contents

1. Car MP3 FM Transmitter
2. 3.5 mm Aux Cable
3. Remote Control



Connecting the Car Transmitter and Mobile Device

1. Connect the car transmitter to your car's 12V outlet.
2. Plug one end of the 3.5 mm aux cable into the outlet on the car transmitter and the other end into the headphone port on your mobile device (Fig. 1).





Plugging USB drives and SD/MMC Cards into the Car Transmitter

1. Plug your USB drive into the USB port (B) located on the back of the car transmitter.
2. Insert your SD/MMC card into the slot (A) located on the back of the car transmitter.




Playing Music from your Mobile Device, USB Drive, or SD/MMC Card

1. Set your car stereo to a clear FM channel (a channel that does not currently carry a radio station's frequency).
2. Set the car transmitter to the same FM channel by pressing the -A button to decrease and the B+ button to increase the FM channel frequency on your car transmitter. The LCD display will show the FM channels as you are scrolling up (B+) or down (-A). Optionally, you can use the remote control to set the radio frequency (Fig. 3).
3. If playing music from your mobile device through the 3.5 mm aux cable, control the music from your device and ensure that the volume on your mobile device is about 3/4 maximum volume.
4. If playing music from a USB or SD/MMC card, press the Previous, Next, or Play/Pause buttons located on the car transmitter (Fig. 4). Optionally, you can use the remote control.



Using the Remote Control

- CH-, CH+ and CH buttons:** Press CH- to decrease the FM channel frequency or CH+ to increase the channel frequency. Press CH along with buttons 0-9 to set a radio frequency. For example press CH and 1, 0, 5, 1 to dial to 105.1MHz.
- Prev, Next, and Play/Pause buttons:** Press to go to the previous song, play or pause your music, or move to the next song on your play list.
- VOL- and VOL+ buttons:** Press to decrease or increase the volume.
- EQ button:** Press to switch music modes.
- 0-9 buttons:** Press to select a music track. For example press buttons 1 and 5 to select track #15. Or press together with the CH button to set up a radio frequency (refer to A).
- Folder buttons:** Press these buttons to navigate from previous and next folders when using USB drives or SD cards.



iPod and iPhone are trademarks of Apple Inc., registered in the U.S. and other countries.

For additional information or questions about this product call us toll free at 866-446-4327 or email us at info@premierxsre.com

15.19 Labelling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

15.21 Changes or modification warning

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

* RF warning for Portable device:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

15.105 Information to the user.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.