



XIRCOM, INC.

RealPort 2 Bluetooth 16 Bit Type III PC Adapter

Model: R2BT

LIST OF CHANNELS AND THEIR FREQUENCIES

CHANNEL NUMBER	FREQUENCY (MHz)	CHANNEL NUMBER	FREQUENCY (MHz)
1	2402	28	2429
2	2403	29	2430
3	2404	30	2431
4	2405	31	2432
5	2406	32	2433
6	2407	33	2434
7	2408	34	2435
8	2409	35	2436
9	2410	36	2437
10	2411	37	2438
11	2412	38	2439
12	2413	39	2440
13	2414	40	2441
14	2415	41	2442
15	2416	42	2443
16	2417	43	2444
17	2418	44	2445
18	2419	45	2446
19	2420	46	2447
20	2421	47	2448
21	2422	48	2449
22	2423	49	2450
23	2424	50	2451
24	2425	51	2452
25	2426	52	2453
26	2427	53	2454
27	2428	54	2455

XIRCOM, INC.

RealPort 2 Bluetooth 16 Bit Type III PC Card Adapter

Model: R2BT

LIST OF CHANNELS AND THEIR FREQUENCIES
(CONTINUED)

CHANNEL NUMBER	FREQUENCY (MHz)	CHANNEL NUMBER	FREQUENCY (MHz)
55	2456	68	2469
56	2457	69	2470
57	2458	70	2471
58	2459	71	2472
59	2460	72	2473
60	2461	73	2474
61	2462	74	2475
62	2463	75	2476
63	2464	76	2477
64	2465	77	2478
65	2466	78	2479
66	2467	79	2480
67	2468		

EXAMPLE OF A HOPPING SEQUENCE

Example of a hopping sequence in data mode: Example of a 79 hopping sequence in data mode: 40, 21, 44, 23, 42, 53, 46, 55, 48, 33, 52, 35, 50, 65, 54, 67, 56, 37, 60, 39, 58, 69, 62, 71, 64, 25, 68, 27, 66, 57, 70, 59, 72, 29, 76, 31, 74, 61, 78, 63, 01, 41, 05, 43, 03, 73, 07, 75, 09, 45, 13, 47, 11, 77, 15, 00, 64, 49, 66, 53, 68, 02, 70, 06, 01, 51, 03, 55, 05, 04