

SERIAL#



MS30BT



W A K E R S

**MODEL: MS30BT**

**AM/FM/USB/BT/AUX IN Radio**  
**12VOLT DC NEG. GROUND**

GRAY ———— RED ———— RIGHT  
(Rear Line Out) (AUX IN)

WHITE ———— LEFT  
RED ———— RIGHT  
WHITE ———— LEFT

E13 XX - XXXXXX



**FCC ID: OPDMS30BT**

(POWER)  
RED ———— +12V DC Switched  
BLACK ———— GROUND  
BLUE ———— Power Amp Remote  
(SPEAKERS)  
GRAY ———— RIGHT FRONT (+)  
GRAY/BLACK ———— RIGHT FRONT (-)  
WHITE ———— LEFT FRONT (+)  
WHITE/BLACK ———— LEFT FRONT (-)  
VIOLET ———— RIGHT REAR (+)  
VIOLET/BLACK ———— RIGHT REAR (-)  
GREEN ———— LEFT REAR (+)  
GREEN/BLACK ———— LEFT REAR (-)  
USE 4 OHM SPEAKERS

\*REPLACE FUSE WITH 10 AMPA TO TYPE FUSE

**IMPORTANT: DO NOT BRIDGE (COMBINE) SPEAKER OUTPUTS**  
**FAILURE TO WIRE CORRECTLY MAY CAUSE DAMAGE TO UNIT**

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS:

- (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND
- (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRABLE OPERATION.



www.asaelectronics.com  
MADE IN CHINA



Electronics  
Address: #75  
Phone: 978-252-6100  
Fax: 978-252-6100  
www.electronics.com



label

MS30BT  
SERIAL#