

Address

SAR Test Report

Client Name : C-SMARTLINK INFORMATION TECHNOLOGY CO., LIMITED 101 to 501, Factory Building 1, No. 91 Hengping Road, Baoan

Community, Yuanshan Street, Longgang District, Shenzhen, China

Page 1 of 82

Product Name : HDMI WIFI DONGLE

FCC ID : 2ACFF-WD1401ATX

Date : Dec. 30, 2022



Shenzhen Anbotek Compliance Laboratory Limited





Page 2 of 82

Contents

1.	State	tement of Compliance		nbote	ε
2.	Gen	neral Information	And		otek
	2.100	Client Information	Anboi	- Pre-	
	2.2	Description of Equipment Under Test (EUT)	prib	5 ⁴⁶	
	2.3	Device Category and SAR Limits	Å	abotek	
	2.4	Applied Standard	· · · ·	vootek	800000
	2.5	Environment of Test Site	por	Pro	K
	2.6	Test Configuration	puboter	And	
3.	Spec	cific Absorption Rate (SAR)	obotek	Anb	
	3.1	Introduction		404	
	3.2	SAR Definition	Pin	Hote	boten g
4.	SAR	R Measurement System	en. M		
	4.1	E-Field Probe	ootek	Anbo.	1
	4.2	Data Acquisition Electronics (DAE)	wotek	Anbore	
	4.3	Robot	Anstek	odaa	
	4.4	Measurement Server	And	Å	
	4.5 🕨	Phantom	Anbo		
	4.6	Device Holder	N. DO	pote.	
	4.7	Data Storage and Evaluation	Yok	anbotek	
5.	Test	t Equipment List		botek	
6.	Tiss	sue Simulating Liguids	Anbo.		
7.	Svst	tem Verification Procedures	Anbote	Pur	
8.	EUT	۲ Testing Position	photo	an Ar	
	8.1	Body Worn Position		otek	
9.	Меа	asurement Procedures		-otek	
	9.1	Spatial Peak SAR Evaluation	o ^{te} .	Ant	
	9.2	Power Reference Measurement	oboten	Anbe	
	9.3	Area Scan Procedures	botek	Anbor	
	9.4	Zoom Scan Procedures		h	
	9.5	Volume Scan Procedures	Anu		
	9.6	Power Drift Monitoring	Anb		
10	. Cond	nducted Power	tek 1	mboli	
11	Ante	enna Location	otek	Anboten	
12	.SAR	R Test Results Summary	nu sek	nbote	
13	. Simu	ultaneous Transmission Analysis	Anbu		
ek	13.1	Simultaneous TX SAR Considerations	Anbor		
	13.2	Evaluation of Simultaneous SAR	odaa.	Her.	
14	.Mea	asurement Uncertainty	e ^{x.}	abotek	

Shenzhen Anbotek Compliance Laboratory Limited

Address: 1/F., Building D, Sogood Science and Technology Park, Sanwei Community, Hangcheng Street, Bao'an District, Shenzhen, Guangdong, China. Tel:(86) 755–26066440 Fax: (86) 755–26014772 Email: service@anbotek.com

Anbotek Product Safety

Report No.: 1	8220WC20293301	Page 3 of 82	
Appendix A.	EUT Photos and Test Setup Photos	Aubotek Anbo	
Appendix B.	Plots of SAR System Check	m nhote	
Appendix C.	Plots of SAR Test Data	Am	
Appendix D.	DASY System Calibration Certificate	ier Anber	

Shenzhen Anbotek Compliance Laboratory Limited





TEST REPORT

Applicant :	C-SMARTLINK INFORMATION TECHNOLOGY CO., LIMITED
Manufacturer :	C-SMARTLINK INFORMATION TECHNOLOGY CO., LIMITED
Product Name :	HDMI WIFI DONGLE
Model No. :	WD1401A, HUC-WP101, WD1401, WD1401B, WD1401C, WD1401D, WD1402, WD1402A, WD1402B, WD1402C, WD1402D
Trade Mark :	N/A Anborek Anborek Anborek Anborek Anborek
Rating(s) :	DC 5V from Type-C
otek Anboro	IEC 62200 1528-2020-

Test Standard(s) IEC-62209-1528:2020: ANSI/IEEE C95.1:2005; FCC 47 CFR Part 2 (2.1093)

The device described above is tested by Shenzhen Anbotek Compliance Laboratory Limited to determine the maximum emission levels emanating from the device and the severe levels of the device can endure and its performance criterion. The measurement results are contained in this test report and Shenzhen Anbotek Compliance Laboratory Limited is assumed full of responsibility for the accuracy and completeness of these measurements. Also, this report shows that the EUT (Equipment Under Test) is technically compliant with the IEC-62209-1528:2020, FCC 47 CFR Part 2 (2.1093:2013), ANSI/IEEE C95.1:2005, and Reference FCC KDBs requirements.

This report applies to above tested sample only and shall not be reproduced in part without written approval of Shenzhen Anbotek Compliance Laboratory Limited.

Date of Receipt Date of Test

Dec. 05, 2022 Dec. 05, 2022 ~ Dec. 30, 2022

4 of 82

Page

GM KOM

(Engineer / Kingkong Jin)

(Supervisor / Bibo Zhang)

Approved & Authorized Signer

(Manager / Tom Chen)

Shenzhen Anbotek Compliance Laboratory Limited

Address: 1/F., Building D, Sogood Science and Technology Park, Sanwei Community Hangcheng Street, Bao'an District, Shenzhen, Guangdong, China. rel:(86) 755-26066440 Fax: (86) 755-26014772 Email: service@anbotel

Hotline 400-003-0500 www.anbotek.co

Prepared By

Reviewer



Version

Page 5 of 82

	Version No.	Date	Description
	Anb 01 Anb	Dec. 30, 2022	Original
No ₁	Anbotek A	nbotek Anbotek	Anboret Annotek Anboret Anbor
bote	K Anbolistek	Anbotek Anbot	rek anborek Anborek Anborek anbor
Anb	oten Anbu	Anbotek An	htorotek Anbotek Anbotek An
P	nbon Anbo	tek Anboter	Indotek Anbotek Anbotek Anbotek
e¥-	And obotek A	botek Anbou	Anbotek Anboten Anotek Anbotek Anbotek

Anbo

Shenzhen Anbotek Compliance Laboratory Limited

Address: 1/F., Building D, Sogood Science and Technology Park, Sanwei Community, Hangcheng Street, Bao'an District, Shenzhen, Guangdong, China. Tel:(86) 755–26066440 Fax: (86) 755–26014772 Email: service@anbotek.com



1. Statement of Compliance

The maximum results of Specific Absorption Rate (SAR) found during testing are as follows.

		Highest Reported 1g-SAR(W/Kg)	SAR Test Limit	
Frequency Band		Body-worn(0mm)	(W/Kg)	
e pri	WIFI 2.4GHz	0.344	Anboten Ant	
Jek M	WIFI 5.2GHz	0.338	1.6	
Lotek	WIFI 5.8GHz	0.299	Anbore	
nº stek	Test Result	PASS	stek Anbo	

Page 6 of 82

<Highest SAR Summary>

This device is in compliance with Specific Absorption Rate (SAR) for general population/uncontrolled exposure limits (1.6 W/kg) specified in FCC 47 CFR part 2 (2.1093) and ANSI/IEEE C95.1-2005, and had been tested in accordance with the measurement methods and procedures specified in IEC-62209-1528:2020.

Shenzhen Anbotek Compliance Laboratory Limited





2. General Information

2.1 Client Information

Applicant	:	C-SMARTLINK INFORMATION TECHNOLOGY CO., LIMITED
Address	:	101 to 501, Factory Building 1, No. 91 Hengping Road, Baoan Community, Yuanshan Street, Longgang District, Shenzhen, China
Manufacturer	:	C-SMARTLINK INFORMATION TECHNOLOGY CO., LIMITED
Address	:	101 to 501, Factory Building 1, No. 91 Hengping Road, Baoan Community, Yuanshan Street, Longgang District, Shenzhen, China

Page 7 of 82

2. 2 Description of Equipment Under Test (EUT)

Product Name	:	HDMI WIFI DONGLE			
Model No.	:	WD1401A, HUC-WP101, WD1401, WD1401B, WD1401C, WD1401D, WD140 WD1402A, WD1402B, WD1402C, WD1402D			
Trade Mark	:	V/A wet apporet Antonieu Antonieu Antonieu Antonieu Antonieu I			
Test Power Supply	:	DC 5V from Type-C	C 5V from Type-C		
Product	:	Operation Frequency:	2.4GWiFi: 2412-2462MHz 5.2GWiFi:5180MHz~5240MHz 5.8GWiFi:5745MHz~5825MHz		
Description		Modulation Type:	OFDM with BPSK/QPSK/16QAM/64QAM/256QAM		
		Antenna Type:	Internal Antenna		
Remark: 1) For a m the Use	ore r's	detailed features descript Manual.	ion, please refer to the manufacturer's specifications or		

Shenzhen Anbotek Compliance Laboratory Limited





2.3 Device Category and SAR Limits

This device belongs to portable device category because its radiating structure is allowed to be used within 20 centimeters of the body of the user. Limit for General Population/Uncontrolled exposure should be applied for this device, it is 1.6 W/kg as averaged over any 1 gram of tissue.

Page 8 of 82

2.4 Applied Standard

The Specific Absorption Rate (SAR) testing specification, method, and procedure for this device is in accordance with the following standards:

FCC 47 CFR Part 2 (2.1093:2013)

ANSI/IEEE C95.1:2005

IEC-62209-1528:2020

KDB 865664 D01 SAR Measurement 100 MHz to 6 GHz v01r04

- KDB 865664 D02 RF Exposure Reporting v01r02
- KDB 447498 D01 General RF Exposure Guidance v06
- KDB248227 D01 802 11 Wi-Fi SAR v02r02
- KDB 941225 D06 Hotspot SARv02r01
- KDB648474 D04 Handset SAR v01r03

2. 5 Environment of Test Site

Items	Required	Actual
Temperature (℃)	18-25	22~23
Humidity (%RH)	30-70	55~65

2.6 Test Configuration

For WIFI SAR testing, engineering testing software installed on the EUT can provide continuous transmitting RF signal.

Shenzhen Anbotek Compliance Laboratory Limited



3. Specific Absorption Rate (SAR)

3.1 Introduction

nbotek

Product Safety

SAR is related to the rate at which energy is absorbed per unit mass in an object exposed to a radio field. The SAR distribution in a biological body is complicated and is usually carried out by experimental techniques or numerical modeling. The standard recommends limits for two tiers of groups, occupational/controlled and general population/uncontrolled, based on a person's to exercise control over his or her exposure. awareness and ability general, In occupational/controlled exposure limits higher than the limits general are for population/uncontrolled.

age 9 of 82

3. 2 SAR Definition

The SAR definition is the time derivative (rate) of the incremental energy (dW) absorbed by (dissipated in) an incremental mass (dm) contained in a volume element (dv) of a given density (ρ). The equation description is as below:

$$SAR = \frac{d}{dt} \left(\frac{dW}{dm} \right) = \frac{d}{dt} \left(\frac{dW}{\rho dv} \right)$$

SAR is expressed in units of Watts per kilogram (W/kg)

SAR measurement can be either related to the temperature elevation in tissue by

$$\mathbf{SAR} = \mathbf{C}\left(\frac{\mathbf{\delta T}}{\mathbf{\delta t}}\right)$$

Where: C is the specific head capacity, δT is the temperature rise and δ tisthe exposure duration, or related to the electrical field in the tissue by

$$SAR = \frac{\sigma |E|^2}{\rho}$$

Where: σ is the conductivity of the tissue, ρ is the mass density of the tissue and E is the RMS electrical field strength.

However for evaluating SAR of low power transmitter, electrical field measurement is typically applied.

Shenzhen Anbotek Compliance Laboratory Limited

Address: 1/F., Building D, Sogood Science and Technology Park, Sanwei Community, Hangcheng Street, Bao'an District, Shenzhen, Guangdong, China. Tel:(86) 755–26066440 Fax: (86) 755–26014772 Email: service@anbotek.com



4. SAR Measurement System



Page 10 of 82

DASY System Configurations

The DASY system for performance compliance tests is illustrated above graphically. This system consists of the following items:

- A standard high precision 6-axis robot with controller, a teach pendant and software
- A data acquisition electronic (DAE) attached to the robot arm extension
- A dosimetric probe equipped with an optical surface detector system
- The electro-optical converter (EOC) performs the conversion between optical and electrical signals
- A measurement server performs the time critical tasks such as signal filtering, control of the robot operation and fast movement interrupts.
- > A probe alignment unit which improves the accuracy of the probe positioning
- A computer operating Windows XP
- DASY software
- Remove control with teach pendant and additional circuitry for robot safety such as warming lamps, etc.
- The SAM twin phantom
- A device holder
- Tissue simulating liquid

Shenzhen Anbotek Compliance Laboratory Limited

Address: 1/F., Building D, Sogood Science and Technology Park, Sanwei Community, Hangcheng Street, Bao'an District, Shenzhen, Guangdong, China. Tel:(86) 755–26066440 Fax: (86) 755–26014772 Email: service@anbotek.com



botek

Product Safety

Report No.: 18220WC20293301

Dipole for evaluating the proper functioning of the system

components are described in details in the following sub-sections.

4.1 E-Field Probe

The SAR measurement is conducted with the dosimetric probe (manufactured by SPEAG). The probe is specially designed and calibrated for use in liquid with high permittivity. The dosimetric probe has special calibration in liquid at different frequency. This probe has a built in optical surface detection system to prevent from collision with phantom.

ade 11

<ex3dv4 probe<="" th=""><th>a Ant hoter Ant</th><th>otek Anbo</th></ex3dv4>	a Ant hoter Ant	otek Anbo
Construction	Symmetrical design with triangular core Built-in shielding against static charges PEEK enclosure material (resistant to organic solvents, e.g., DGBE)	stelt
Frequency	10 MHz to 6 GHz; Linearity: ± 0.2 dB	
Directivity	 ± 0.3 dB in HSL (rotation around probe axis) ± 0.5 dB in tissue material (rotation normal to probe axis) 	tek bote
Dynamic Range	10 μ W/g to 100 mW/g; Linearity: ± 0.2 dB (noise: typically < 1 μ W/g)	Photo of EX3DV4
Dimensions	Overall length: 330 mm (Tip: 20 mm) Tip diameter: 2.5 mm (Body: 12 mm) Typical distance from probe tip to dipole centers: 1 mm	ek Anbotek Anbotek ootek Anbotek Anbotek Anbotek Anbotek Anbotek

E-Field Probe Specification <EX3DV4 Probe>

> E-Field Probe Calibration

Each probe needs to be calibrated according to a dosimetric assessment procedure with accuracy better than \pm 10%. The spherical isotropy shall be evaluated and within \pm 0.25dB. The sensitivity parameters (NormX, NormY, and NormZ), the diode compression parameter (DCP) and the conversion factor (ConvF) of the probe are tested. The calibration data can be referred to appendix C of this report.

4. 2 Data Acquisition Electronics (DAE)

The data acquisition electronics (DAE) consists of a highly sensitive electrometer-grade preamplifier with auto-zeroing, a channel and gain-switching multiplexer, a fast 16 bit AD-converter and a command decoder and control logic unit. Transmission to the measurement server is

Shenzhen Anbotek Compliance Laboratory Limited



Page 12 of 82 accomplished through an optical downlink for data and status information as well as an optical uplink for commands and the clock.

The input impedance of the DAE is 200MOhm; the inputs are symmetrical and floating. Common mode rejection is above 80dB.



Photo of DAE

4.3 Robot

The SPEAG DASY system uses the high precision robots (DASY5: TX60XL) type from Stäubli SA (France). For the 6-axis controller system, the robot controller version (DASY5: CS8c) from Stäubli is used. The Stäubli robot series have many features that are important for our application:

- High precision (repeatability ±0.035 mm)
- High reliability (industrial design)
- Jerk-free straight movements
- Low ELF interference (the closed metallic construction shields against motor control fields)



Photo of DASY5

Shenzhen Anbotek Compliance Laboratory Limited





4. 4 Measurement Server

The measurement server is based on a PC/104 CPU board with CPU (DASY5: 400 MHz, Intel Celeron), chipdisk (DASY5: 128 MB), RAM (DASY5: 128 MB). The necessary circuits for communication with the DAE electronic box, as well as the 16 bit AD converter system for optical detection and digital I/O interface are contained on the DASY I/O board, which is directly connected to the PC/104 bus of the CPU board.

Page 13 of 82

The measurement server performs all the real-time data evaluation for field measurements and surface detection, controls robot movements and handles safety operations.



Photo of Server for DASY5

4.5 Phantom

<SAM Twin Phantom>

Shell Thickness	2 ± 0.2 mm;	200
	Center ear point: 6 ± 0.2 mm	
Filling Volume	Approx. 25 liters	TUD
Dimensions	Length: 1000 mm; Width: 500 mm;	6
	Height: adjustable feet	
Measurement	Left Hand, Right Hand, Flat	The
Areas	Phantom	P P
	unbole Ann otek unbolek Ar	and the second second
	Anboten Anbo tek nbotek An	noter Anbrie

Photo of SAM Phantom

The bottom plate contains three pair of bolts for locking the device holder. The device holder positions are adjusted to the standard measurement positions in the three sections. A white cover is provided to tap the phantom during off-periods to prevent water evaporation and changes in the liquid parameters. On the phantom top, three reference markers are provided to identify the phantom position with respect to the robot.

Shenzhen Anbotek Compliance Laboratory Limited

Address: 1/F., Building D, Sogood Science and Technology Park, Sanwei Community, Hangcheng Street, Bao'an District, Shenzhen, Guangdong, China. Tel:(86) 755–26066440 Fax: (86) 755–26014772 Email: service@anbotek.com



<ELI4 Phantom>

± 0.2 mm (sagging: <1%)
pprox. 30 liters
ajor ellipse axis: 600 mm inor axis:400 mm Photo of ELI4 Phantom

14 of 82

Page

The ELI4 phantom is intended for compliance testing of handheld and body-mounted wireless devices in the frequency range of 30 MHz to 6 GHz. ELI4 is fully compatible with standard and all known tissue simulating liquids.

Shenzhen Anbotek Compliance Laboratory Limited

Address: 1/F., Building D, Sogood Science and Technology Park, Sanwei Community, Hangcheng Street, Bao'an District, Shenzhen, Guangdong, China. Tel:(86) 755-26066440 Fax: (86) 755-26014772 Email: service@anbotek.com

4.6 Device Holder

Anbotek

Product Safety

The SAR in the phantom is approximately inversely proportional to the square of the distance between the source and the liquid surface. For a source at 5 mm distance, a positioning uncertainty of ± 0.5 mm would produce a SAR uncertainty of $\pm 20\%$. Accurate device positioning is therefore crucial for accurate and repeatable measurements. The positions in which the devices must be measured are defined by the standards.

Page 15 of 82

The DASY device holder is designed to cope with different positions given in the standard. It has two scales for the device rotation (with respect to the body axis) and the device inclination (with respect to the line between the ear reference points). The rotation center for both scales is the ear reference point (ERP). Thus the device needs no repositioning when changing the angles.

The DASY device holder is constructed of low-loss POM material having the following dielectric parameters: relative permittivity ε = 3 and loss tangent δ = 0.02. The amount of dielectric material has been reduced in the closest vicinity of the device, since measurements have suggested that the influence of the clamp on the test results could thus be lowered.



Shenzhen Anbotek Compliance Laboratory Limited



4.7 Data Storage and Evaluation

Data Storage

The DASY software stores the assessed data from the data acquisition electronics as raw data (in microvolt readings from the probe sensors), together with all the necessary software parameters for the data evaluation (probe calibration data, liquid parameters and device frequency and modulation data) in measurement files. The post-processing software evaluates the desired unit and format for output each time the data is visualized or exported. This allows verification of the complete software setup even after the measurement and allows correction of erroneous parameter settings. For example, if a measurement has been performed with an incorrect crest factor parameter in the device setup, the parameter can be corrected afterwards and the data can be reevaluated.

age 16 of 82

The measured data can be visualized or exported in different units or formats, depending on the selected probe type (e.g., [V/m], [A/m], [mW/g]). Some of these units are not available in certain situations or give meaningless results, e.g., a SAR-output in a non-lose media, will always be zero. Raw data can also be exported to perform the evaluation with other software packages.

Data Evaluation

The DASY post-processing software (SEMCAD) automatically executes the following procedures to calculate the field units from the microvolt readings at the probe connector. The parameters used in the evaluation are stored in the configuration modules of the software:

Probe parameters:	- Sensitivity	Norm _i , a _{i0} , a _{i1} ,	8
	- Conversion factor	ConvF _i	
	- Diode compression point	dcpi	
Device parameters:	- Frequency	f fanboter P	
	- Crest factor	tek Cf unbotek	
Media parameters:	- Conductivity	ako hotek	
	- Density	por Ann otel	

These parameters must be set correctly in the software. They can be found in the component documents or they can be imported into the software from the configuration files issued for the DASY components. In the direct measuring mode of the multi-meter option, the parameters of the actual system setup are used. In the scan visualization and export modes, the parameters stored in the corresponding document files are used.

The first step of the evaluation is a linearization of the filtered input signal to account for the compression characteristics of the detector diode. The compensation depends on the input signal, the diode type and the DC-transmission factor from the diode to the evaluation electronics. If the exciting field is pulsed, the crest factor of the signal must be known to correctly compensate for peak power.

Shenzhen Anbotek Compliance Laboratory Limited

nbotek

Product Safety

The formula for each channel can be given as:

$$\mathbf{V_i} = \mathbf{U_i} + \mathbf{U_i^2} \cdot \frac{\mathbf{cf}}{\mathbf{dcp_i}}$$

age 17 of 82

with V_i = compensated signal of channel i, (i = x, y, z)

 U_i = input signal of channel i, (i = x, y, z)

cf = crest factor of exciting field (DASY parameter)

dcp_i = diode compression point (DASY parameter)

From the compensated input signals, the primary field data for each channel can be evaluated:

E-field Probes: $E_i = \sqrt{\frac{V_i}{Norm_i \cdot ConvF}}$

H-field Probes: $H_i = \sqrt{V_i} \cdot \frac{a_{i0} + a_{i1}f + a_{i2}f^2}{f}$

with V_i = compensated signal of channel i,(i = x, y, z)

Norm_i= sensor sensitivity of channel i, (i = x, y, z), $\mu V/(V/m)^2$ for E-field Probes

ConvF= sensitivity enhancement in solution

a_{ij}= sensor sensitivity factors for H-field probes

f = carrier frequency [GHz]

 E_i = electric field strength of channel i in V/m

H_i= magnetic field strength of channel i in A/m

The RSS value of the field components gives the total field strength (Hermitian magnitude)

$$E_{tot} = \sqrt{E_x^2 + E_y^2 + E_z^2}$$

The primary field data are used to calculate the derived field units.

$$SAR = E_{tot}^2 \cdot \frac{\sigma}{\rho \cdot 1000}$$

with SAR = local specific absorption rate in mW/g

E_{tot}= total field strength in V/m

 σ = conductivity in [mho/m] or [Siemens/m]

 ρ = equivalent tissue density in g/cm³

Note that the density is set to 1, to account for actual head tissue density rather than the density of the tissue simulating liquid.

Shenzhen Anbotek Compliance Laboratory Limited



Anbotek

Product Safety

5. Test Equipment List

Manufacturar	Nome of Equipment	Turne/Medel		Calibration	
Manufacturer	Name or Equipment	i ype/wodei	Serial Number	Last Cal.	Due Date
SPEAG	2450MHz System Validation Kit	D2450V2	910	Jun 15,2021	Jun 14,2024
SPEAG	5GHz System Validation Kit	D5GHzV2	1160	Oct. 02, 2021	Oct. 01, 2024
SPEAG	Data Acquisition Electronics	DAE4	387	Sept.06,2022	Sept.05,2023
SPEAG	Dosimetric E-Field Probe	EX3DV4	7396	May 06,2022	May 05,2023
Agilent	ENA Series Network Analyzer	E5071C	MY46317418	Oct.22, 2022	Oct.21,2023
SPEAG	DAK	DAK-3.5	1226	NCR	NCR
SPEAG	ELI Phantom	QDOVA004AA	2058	NCR	NCR
AR	Amplifier	ZHL-42W	QA1118004	NCR	NCR
Agilent	Power Meter	N1914A	MY50001102	NCR	NCR
Agilent	Power Sensor	N8481H	MY51240001	Oct.22, 2022	Oct.21, 2023
R&S	Spectrum Analyzer	N9020A	MY51170037	Oct.22, 2022	Oct.21, 2023
Agilent	Signal Generation	N5182A	MY48180656	Oct.22, 2022	Oct.21, 2023
Worken	Directional Coupler	0110A05601O- 10	COM5BNW1A2	Oct.22, 2022	Oct.21, 2023

18

ade

Note:

1. The calibration certificate of DASY can be referred to appendix C of this report.

- The dipole calibration interval can be extended to 3 years with justification. The dipoles are also not
 physically damaged, or repaired during the interval.
- 3. The Insertion Loss calibration of Dual Directional Coupler and Attenuator were characterized via the network analyzer and compensated during system check.
- I. The dielectric probe kit was calibrated via the network analyzer, with the specified procedure (calibrated in pure water) and calibration kit (standard) short circuit, before the dielectric measurement. The specific procedure and calibration kit are provided by Agilent.
- 5. In system check we need to monitor the level on the power meter, and adjust the power amplifier level to have precise power level to the dipole; the measured SAR will be normalized to 1W input power according to the ratio of 1W to the input power to the dipole. For system check, the calibration of the power amplifier is deemed not critically required for correct measurement; the power meter is critical and we do have calibration for it.

Shenzhen Anbotek Compliance Laboratory Limited





6. Tissue Simulating Liquids

For the measurement of the field distribution inside the SAM phantom with DASY, the phantom must be filled with around 25 liters of homogeneous body tissue simulating liquid. For head SAR testing, the liquid height from the ear reference point (ERP) of the phantom to the liquid top surface is larger than 15 cm, which is shown in Fig. 6.1. For body SAR testing, the liquid height from the center of the flat phantom to the liquid top surface is larger than 15 cm, which is shown as followed:





19

ade

Photo of Liquid Height for Head SAR

Photo of Liquid Height for Body SAR

The following t	able gives	the recipe	s for tissue sit	nulating nq	ulu.	00.	Pri V	Loter Ant
Frequency	Water	Sugar	Cellulose	Salt	Preventol	DGBE	Conductivity	Permittivity
(MHz)	(%)	(%)	(%)	(%)	(%)	(%)	(σ)	(er)
		·		For Hea	d			
900	40.3	57.9	0.2	1.4	0.2	0	0.97	41.5
1750	55.2	0.000	0	0.3	0 Anbo	44.5	1.37 M	40.1
1800,1900,2000	55.2	00	0	0.3	otek 0 Ant	44.5	1.40	40.0
2450	55.0	0,000	0	oter 0	nbotet	45.0	1.80	39.2
2600	54.8	× 0 M	0	0.1	Anb Oek	45.1	1.96	39.0
5000	65.5	ote ^k 0	17.2	0,04	17.3	0,000	5.27	35.3
5000	78.6	0	10.7	0	10.7	6 p. 0	6.00	48.2

The following table gives the recipes for tissue simulating liquid.

Shenzhen Anbotek Compliance Laboratory Limited



Anbotek Product Safety

2450

5200

Page 20 of 82 Report No.: 18220WC20293301 The following table shows the measuring results for simulating liquid. **Measured Tissue** Measured **Target Tissue** Liquid Frequency Dev. **Test Date** Dev. Temp. (℃) ٤r σ ٤r σ (%) (MHz) (%)

-1.05

-1.23

1.74

4.65

-3.33

-1.27

22.6

22.3

38.79

35.46

1.80

4.71

39.2

35.9

Shenzhen Anbotek Compliance Laboratory Limited

Address: 1/F., Building D, Sogood Science and Technology Park, Sanwei Community, Hangcheng Street, Bao'an District, Shenzhen, Guangdong, China. Tel:(86) 755–26066440 Fax: (86) 755–26014772 Email: service@anbotek.com



12/26/2022

12/27/2022

Page 21 of 82

7. System Verification Procedures

Each DASY system is equipped with one or more system validation kits. These units, together with the predefined measurement procedures within the DASY software, enable the user to conduct the system performance check and system validation. System validation kit includes a dipole, tripod holder to fix it underneath the flat phantom and a corresponding distance holder.

Purpose of System Performance check

The system performance check verifies that the system operates within its specifications. System and operator errors can be detected and corrected. It is recommended that the system performance check be performed prior to any usage of the system in order to guarantee reproducible results. The system performance check uses normal SAR measurements in a simplified setup with a well characterized source. This setup was selected to give a high sensitivity to all parameters that might fail or vary over time. The system check does not intend to replace the calibration of the components, but indicates situations where the system uncertainty is exceeded due to drift or failure.

System Setup

In the simplified setup for system evaluation, the EUT is replaced by a calibrated dipole and the power source is replaced by a continuous wave that comes from a signal generator. The calibrated dipole must be placed beneath the flat phantom section of the SAM twin phantom with the correct distance holder. The distance holder should touch the phantom surface with a light pressure at the reference marking and be oriented parallel to the long side of the phantom. The equipment setup is shown below:



System Setup for System Evaluation

Shenzhen Anbotek Compliance Laboratory Limited

Address: 1/F., Building D, Sogood Science and Technology Park, Sanwei Community, Hangcheng Street, Bao'an District, Shenzhen, Guangdong, China. Tel:(86) 755–26066440 Fax: (86) 755–26014772 Email: service@anbotek.com





Page 22 of 82

Photo of Dipole Setup

Validation Results

Comparing to the original SAR value provided by SPEAG, the verification data should be within its specification of 10%. The table below shows the target SAR and measured SAR after normalized to 1W input power. It indicates that the system performance check can meet the variation criterion and the plots can be referred to Appendix A of this report.

Frequency (MHz)	Liquid Type	Power fed onto reference dipole (mW)	Targeted SAR (W/kg)	Measured SAR (W/kg)	Normalized SAR (W/kg)	Deviatio n (%)	Test Date
2450	Head	250	24.3	5.79	23.16	-4.69	12/26/2022
5200	Head	100	80.7 Month	7.67	76.7	-4.96	12/27/2022

Target and Measurement SAR after Normalized

Shenzhen Anbotek Compliance Laboratory Limited





8. EUT Testing Position

8.1 Body Worn Position

Body-worn operating configurations are tested with the belt-clips and holsters attached to the device and positioned against a flat phantom in a normal use configuration. Per KDB 648474 D04, body-worn accessory exposure is typically related to voice mode operations when handsets are carried in body-worn accessories. The body-worn accessory procedures in FCC KDB 447498 D01 v06, 2015 should be used to test for body-worn accessory SAR compliance, without a headset connected to it. This enables the test results for such configuration to be compatible with that required for hotspot mode when the body-worn accessory test separation distance is greater than or equal to that required for hotspot mode, when applicable. When the reported SAR for body-worn accessory, measured without a headset connected to the handset is < 1.2 W/kg, the highest reported SAR configuration for that wireless mode and frequency band should be repeated for that body-worn accessory with a handset attached to the handset.

Page 23 of 82

Accessories for body-worn operation configurations are divided into two categories: those that do not contain metallic components and those that do contain metallic components and those that do contain metallic components. When multiple accessories that do not contain metallic components are supplied with the device, the device is tested with only the accessory that dictates the closest spacing to the body. Then multiple accessories that contain metallic components are test with the device with each accessory. If multiple accessories share an identical metallic component (i.e. the same metallic belt-chip used with different holsters with no other metallic components) only the accessory that dictates the closest spacing to the body is tested.

wolveyd leld

Body Worn Position

Shenzhen Anbotek Compliance Laboratory Limited

wojugud jeld

Address: 1/F., Building D, Sogood Science and Technology Park, Sanwei Community, Hangcheng Street, Bao'an District, Shenzhen, Guangdong, China. Tel:(86) 755–26066440 Fax: (86) 755–26014772 Email: service@anbotek.com



Anbotek

Product Safety

9. Measurement Procedures

The measurement procedures are as follows:

(a) Use base station simulator (if applicable) or engineering software to transmit RF power continuously (continuous Tx) in the middle channel.

age 24 of 82

- (b) Keep EUT to radiate maximum output power or 100% duty factor (if applicable)
- (c) Measure output power through RF cable and power meter.
- (d) Place the EUT in the positions as setup photos demonstrates.
- (e) Set scan area, grid size and other setting on the DASY software.
- (f) Measure SAR transmitting at the middle channel for all applicable exposure positions.
- (g) Identify the exposure position and device configuration resulting the highest SAR
- (h) Measure SAR at the lowest and highest channels at the worst exposure position and device configuration if applicable.

According to the test standard, the recommended procedure for assessing the peak spatial-average SAR value consists of the following steps:

- (a) Power reference measurement
- (b) Area scan
- (c) Zoom scan
- (d) Power drift measurement

9.1 Spatial Peak SAR Evaluation

The procedure for spatial peak SAR evaluation has been implemented according to the test standard. It can be conducted for 1g and 10g, as well as for user-specific masses. The DASY software includes all numerical procedures necessary to evaluate the spatial peak SAR value.

The base for the evaluation is a "cube" measurement. The measured volume must include the 1g and 10g cubes with the highest averaged SAR values. For that purpose, the center of the measured volume is aligned to the interpolated peak SAR value of a previously performed area scan.

The entire evaluation of the spatial peak values is performed within the post-processing engine (SEMCAD). The system always gives the maximum values for the 1g and 10g cubes. The algorithm to find the cube with highest averaged SAR is divided into the following stages:

- (a) Extraction of the measured data (grid and values) from the Zoom Scan
- (b) Calculation of the SAR value at every measurement point based on all stored data (A/D values and measurement parameters)
- (c) Generation of a high-resolution mesh within the measured volume

Shenzhen Anbotek Compliance Laboratory Limited

Address: 1/F., Building D, Sogood Science and Technology Park, Sanwei Community, Hangcheng Street, Bao'an District, Shenzhen, Guangdong, China. Tel:(86) 755–26066440 Fax: (86) 755–26014772 Email: service@anbotek.com

nbotek

Product Safety

Page 25 of 82

- (d) Interpolation of all measured values form the measurement grid to the high-resolution grid
- (e) Extrapolation of the entire 3-D field distribution to the phantom surface over the distance from sensor to surface
- (f) Calculation of the averaged SAR within masses of 1g and 10g

9. 2 Power Reference Measurement

The Power Reference Measurement and Power Drift Measurements are for monitoring the power drift of the device under test in the batch process. The minimum distance of probe sensors to surface determines the closest measurement point to phantom surface. This distance cannot be smaller than the distance of sensor calibration points to probe tip as defined in the probe properties.

9. 3 Area Scan Procedures

The area scan is used as a fast scan in two dimensions to find the area of high field values, before doing a fine measurement around the hot spot. The sophisticated interpolation routines implemented in DASY software can find the maximum found in the scanned area, within a range of the global maximum. The range (in dB0 is specified in the standards for compliance testing. For example, a 2 dB range is required in IEEE standard 1528 and IEC 62209 standards, whereby 3 dB is a requirement when compliance is assessed in accordance with the ARIB standard (Japan), if only one zoom scan follows the area scan, then only the absolute maximum will be taken as reference. For cases where multiple maximums are detected, the number of zoom scans has to be increased accordingly.

Area scan parameters extracted from FCC KDB 865664 D01 SAR measurement 100 MHz to 6 GHz.

	11 1-1		
	\leq 3 GHz	> 3 GHz	
Maximum distance from closest measurement point (geometric center of probe sensors) to phantom surface	$5 \pm 1 \text{ mm}$	$\frac{1}{2} \cdot \delta \cdot \ln(2) \pm 0.5 \text{ mm}$	
Maximum probe angle from probe axis to phantom surface normal at the measurement location	$30^{\circ} \pm 1^{\circ}$	$20^{\circ} \pm 1^{\circ}$	
	≤ 2 GHz: ≤ 15 mm 2 – 3 GHz: ≤ 12 mm	$3 - 4$ GHz: ≤ 12 mm $4 - 6$ GHz: ≤ 10 mm	
Maximum area scan spatial resolution: Δx_{Area} , Δy_{Area}	When the x or y dimension of the test device, in the measurement plane orientation, is smaller than the above, the measurement resolution must be \leq the corresponding x or y dimension of the test device with at least one measurement point on the test device.		

Shenzhen Anbotek Compliance Laboratory Limited

Address: 1/F., Building D, Sogood Science and Technology Park, Sanwei Community, Hangcheng Street, Bao'an District, Shenzhen, Guangdong, China. Tel:(86) 755–26066440 Fax: (86) 755–26014772 Email: service@anbotek.com

9. 4 Zoom Scan Procedures

Zoom scans are used assess the peak spatial SAR values within a cubic averaging volume containing 1 gram and 10gram of simulated tissue. The zoom scan measures points (refer to table below) within a cube shoes base faces are centered on the maxima found in a preceding area scan job within the same procedure. When the measurement is done, the zoom scan evaluates the averaged SAR for 1 gram and 10 gram and displays these values next to the job's label. Zoom scan parameters extracted from FCC KDB 865664 D01 SAR measurement 100 MHz to 6

age 26

of

GHz.

			\leq 3 GHz	> 3 GHz	
nbo, b,	4 A	oter Ann	stek snbo	A toole	
Maximum zoom scan spatial resolution: Δx_{Zoom} , Δy_{Zoom}			$\leq 2 \text{ GHz:} \leq 8 \text{ mm}$ 2 - 3 GHz: $\leq 5 \text{ mm}^*$	3 4 GHz: ≤ 5 mm [*] 4 – 6 GHz: ≤ 4 mm [*]	
	uniform ;	grid: ∆z _{Zoom} (11)	≤ 5 mm	3 – 4 GHz: ≤ 4 mm 4 – 5 GHz: ≤ 3 mm 5 – 6 GHz: ≤ 2 mm	
Maximum zoom scan spatial resolution, normal to phantom surface	graded	$\Delta z_{Z_{200m}}(1)$: between 1 st two points closest to phantom surface	\leq 4 mm	3 – 4 GHz: ≤ 3 mm 4 – 5 GHz: ≤ 2.5 mm 5 – 6 GHz: ≤ 2 mm	
	grid	∆z _{Zoom} (n>1): between subsequent points	$\leq 1.5 \cdot \Delta z_{Zoom}(n-1)$		
Minimum zoom scan volume	x, y, z		\geq 30 mm	3 – 4 GHz: ≥ 28 mm 4 – 5 GHz: ≥ 25 mm 5 – 6 GHz: ≥ 22 mm	

Note: δ is the penetration depth of a plane-wave at normal incidence to the tissue medium; see draft standard IEEE P1528-2011 for details.

When zoom scan is required and the <u>reported</u> SAR from the area scan based 1-g SAR estimation procedures of KDB 447498 is ≤ 1.4 W/kg, ≤ 8 mm, ≤ 7 mm and ≤ 5 mm zoom scan resolution may be applied, respectively, for 2 GHz to 3 GHz, 3 GHz to 4 GHz and 4 GHz to 6 GHz.

Shenzhen Anbotek Compliance Laboratory Limited



9.5 Volume Scan Procedures

The volume scan is used for assess overlapping SAR distributions for antennas transmitting in different frequency bands. It is equivalent to an oversized zoom scan used in standalone measurements. The measurement volume will be used to enclose all the simultaneous transmitting antennas. For antennas transmitting simultaneously in different frequency bands, the volume scan is measured separately in each frequency band. In order to sum correctly to compute the 1g aggregate SAR, the EUT remain in the same test position for all measurements and all volume scan use the same spatial resolution and grid spacing. When all volume scan were completed, the software, SEMCAD postprocessor can combine and subsequently superpose these measurement data to calculating the multiband SAR.

Page 27 of 82

9.6 Power Drift Monitoring

All SAR testing is under the EUT install full charged battery and transmit maximum output power. In DASY measurement software, the power reference measurement and power drift measurement procedures are used for monitoring the power drift of EUT during SAR test. Both these procedures measure the field at a specified reference position before and after the SAR testing. The software will calculate the field difference in dB. If the power drift more than 5%, the SAR will be retested.

Shenzhen Anbotek Compliance Laboratory Limited

Address: 1/F., Building D, Sogood Science and Technology Park, Sanwei Community, Hangcheng Street, Bao'an District, Shenzhen, Guangdong, China. Tel:(86) 755–26066440 Fax: (86) 755–26014772 Email: service@anbotek.com



10. Conducted Power

N		19.	-0° F
Test	Frequency	Maximum Peak Conducted Output Power	LIMIT
Channel	(MHz)	(dBm)	dBm
Anbotek	Anboten Anbo	TX 802.11b Mode	k Anboten Anbo
CH01	2412	17.09	30
CH06	2437	18.33	30
CH11	2462	17.51	30 30
nbotek k	Anbo, M. Anbote	TX 802.11g Mode	Anbu hotek Anbotek
CH01	2412	have 16.55 mores	an and 30 model
CH06	2437	17.87 March 17.87	30 ^{ek} Milos
CH11	2462	17.87	30
untek p	Anbotek Anbote.	TX 802.11n20 Mode	Anbotek Anbote.
CH01	2412	17.56	Anborak 30 Anborr
CH06	2437	15.65	30 Miles and
CH11	2462	17.81	30
ek An	boten Anbe	TX 802.11n40 Mode	Anbotek Anbo
CH03	2422	16.88	30 30
CH06	2437	17.86 http://www.	30 March
CH09	2452	17.88 Minutes	30
V.0 .	Det .	ALC	AU 141

Page 28 of 82

<WLAN 2.4GHz Conducted Power>

Shenzhen Anbotek Compliance Laboratory Limited

Address: 1/F., Building D, Sogood Science and Technology Park, Sanwei Community, Hangcheng Street, Bao'an District, Shenzhen, Guangdong, China. Tel:(86) 755–26066440 Fax: (86) 755–26014772 Email: service@anbotek.com

Anbotek Product Safety

Report No.: 18220WC20293301

<WIFI 5.2GHz Conducted Power>

Configuration Band I (5150 - 5250 MHz)						
Mode	Test channel	Maximum Conducted Output Power (dBm)	FCC Limit (dBm)			
11a	CH36	10.25	24			
11a	CH40	11.11 M	24			
11a	CH48	14.23	24			
11n(HT20)	CH36	9.88 ores	24			
11n(HT20)	CH40	10.98	24			
11n(HT20)	CH48	10.98	24 March 24			
11n(HT40)	CH38	10.76	24			
11n(HT40)	CH46	12.11 and	24			
11ac(HT20)	CH36	9.73	24			
11ac(HT20)	CH40	11.43	24			
11ac(HT20)	CH48	13.38	24			
11ac(HT40)	CH38	11.17 borek	24			
11ac(HT40)	CH46	hite and the state	24			
11ac(HT80)	CH42	11.84	24			
16 AV	01-	-OT	V			

Page 29 of 82

Shenzhen Anbotek Compliance Laboratory Limited

Address: 1/F., Building D, Sogood Science and Technology Park, Sanwei Community, Hangcheng Street, Bao'an District, Shenzhen, Guangdong, China. Tel:(86) 755–26066440 Fax: (86) 755–26014772 Email: service@anbotek.com

Report No.: 18220WC20293301 <WIFI 5.8GHz Conducted Power>

Configuration Band IV (5725 - 5850 MHz)							
Mode	Test channel	Maximum Conducted Output Power (dBm)	FCC Limit (dBm)				
11a	CH149	10.41	30				
potek 11a	CH157	10.42	30				
model 11a Model	CH165	13.89	30				
11n HT20	CH149	11.57 Market M	30				
11n HT20	CH157	11.17	30				
11n HT20	CH165	11.28	30				
11n HT40	CH151	12.12	30				
11n HT40	CH159	11.00 Million	30				
11ac HT20	CH149	10.87	30				
11ac HT20	CH157	10.90	30				
11ac HT20	CH165	10.79	30				
11ac HT40	CH151	11.73 bore	30				
11ac HT40	CH159	11.34	30				
11ac HT80	CH155	11.78 miles	30				

Page 30 of 82

Shenzhen Anbotek Compliance Laboratory Limited





Note:

1. Per KDB 447498 D01, the 1-g SAR test exclusion thresholds for 100 MHz to 6 GHz at *test separation distances* \leq 50 mm are determined by:

age 31

[(max. power of channel, including tune-up tolerance, mW) / (min. test separation distance, mm)] $\cdot [\sqrt{f(GHz)}] \leq 3.0$ for 1-g SAR, where

f(GHz) is the RF channel transmit frequency in GHz

Power and distance are rounded to the nearest mW and mm before calculation

The result is rounded to one decimal place for comparison

Mode	Frequency (GHz)	Maximum Conducted Output Power	Max. Tune-up Power (dBm)	Max. Power (mW)	Test distance (mm)	Result	exclusion thresholds for 1-g SAR
802.11b	2437	18.33	19	79.43	Albore 5 An	24.80	3.0
802.11a	5240	14.23	An ^{bo} 15	31.62	Anbor 5	14.48	3.0
802.11a	5825	13.89	14	25.12	5 tek	12.13	3.0

Base on the result of note1, RF exposure evaluation of 2.4G WIFI, 5.2G/5.8GWIFI mode is required.

- 3. Per KDB 248227 D01, choose the highest output power channel to test SAR and determine further SAR exclusion.
- 4. Per KDB 248227 D01, In the 2.4 GHz band, separate SAR procedures are applied to DSSS and OFDM configurations to simplify DSSS test requirements. SAR is not required for the following 2.4 GHz OFDM conditions:
 - 1) When KDB Publication 447498 SAR test exclusion applies to the OFDM configuration.
 - 2) When the highest reported SAR for DSSS is adjusted by the ratio of OFDM to DSSS specified maximum output power and the adjusted SAR is \leq 1.2 W/kg.
 - DSSS SAR value* (OFDM power/DSSS power)
- 2.4GWIFI:0.257 W/kg *(38.99 mW/47.75 mW)= 0.210W/kg

Shenzhen Anbotek Compliance Laboratory Limited





11.Antenna Location

EUT Left Edge

EUT Top Edge



EUT Right Edge

Page 32 of 82

EUT Bottom Edge

EUT BACK VIEW	

Distance of The Antenna to the EUT surface and edge						
Antennas F	Front	Back	Top Side	Bottom Side	Left Side	Right Side
WLAN <2	25mm	<25mm	58mm	<25mm	<25mm	64mm

Positions for SAR tests; Hotspot mode							
Antennas	Front	Back	Top Side	Bottom Side	Left Side	Right Side	
WLAN	Yes	Yes	botek No Anbo	Yes	Yes	No	
- AV 7				181		1-0	

General Note: Referring to KDB 941225 D06, When the overall device length and width are \geq 9cm*5cm, the test distance is 10mm, SAR must be measured for all sides and surfaces with a transmitting antenna located with 25mm from that surface or edge.

Shenzhen Anbotek Compliance Laboratory Limited





12. SAR Test Results Summary

General Note:

1. Per KDB 447498 D01 v06, 2015, the reported SAR is the measured SAR value adjusted for maximum tune-up tolerance.

Scaling Factor = tune-up limit power (mW) / EUT RF power (mW), where tune-up limit is the maximum rated power among all production units.

age 33

Reported SAR(W/kg)= Measured SAR(W/kg)* Scaling Factor

- 2. Per KDB 447498 D01 v06, 2015, for each exposure position, if the highest output channel reported SAR≤0.8W/kg, other channels SAR testing are not necessary
- 3. Per KDB865664 D01, for each frequency band, repeated SAR measurement is required only when the measured SAR is ≥ 0.8 W/Kg; if the deviation among the repeated measurement is ≤ 20 %, and the measured SAR <1.45W/Kg, only one repeated measurement is required.
- When the user enables the personal Wireless router functions for the handsets, actual operations include simulta neous transmission of both the Wi-Fi transmitting frequency and thus cannot be valuated for SAR under actual use conditions. The "Portable Hotspot" feature on the handset was

NOT activated, to ensure the SAR measurements were evaluated for a single transmissionfrequency RF signal.

Plot No.	Band	Mode	Test Position	Gap (cm)	Freq. (MHz)	Averag e Power (dBm)	Tune-U p Limit (dBm)	Scalin g Factor	Powe r Drift (dB)	Measure d SAR _{1g} (W/kg)	Reporte d SAR _{1g} (W/kg)
oter	WIFI 2.4GHz	b	Front	0	2437	18.33	19	1.037	0.05	0.317	0.329
#1	WIFI 2.4GHz	b	Back	0	2437	18.33	19	1.037	0.03	0.332	0.344
	WIFI 2.4GHz	b	Left Side	0	2437	18.33	19	1.037	0.01	0.286	0.296
Pur	WIFI 2.4GHz	b	Bottom Side	0.00	2437	18.33	19	1.037	-0.03	0.228	0.236
5	WIFI 5.2GHz	a	Front	0	5240	14.23	15	1.054	0.03	0.314	0.331
#2	WIFI 5.2GHz	а	Back	0	5240	14.23	15	1.054	0.02	0.321	0.338
notel	WIFI 5.2GHz	а	Left Side	0 0	5240	14.23	15	1.054	0.01	0.291	0.307
Anbc	WIFI 5.2GHz	a	Bottom Side	0.0	5240	14.23	15	1.054	-0.02	0.255	0.269
P	WIFI 5.8GHz	a a	Front	0	5825	13.89	14	1.008	0.10	0.284	0.286
#3	WIFI 5.8GHz	а	Back	0 🖻	5825	13.89	14	1.008	0.09	0.297	0.299
tek	WIFI 5.8GHz	a	Left Side	0	5825	13.89	14	1.008	0.05	0.266	0.268
nbotek	WIFI 5.8GHz	a a Anbo	Bottom Side	otek 0	5825	13.89	14	1.008	-0.04	0.201	0.203

Shenzhen Anbotek Compliance Laboratory Limited





13. Simultaneous Transmission Analysis

13.1 Simultaneous TX SAR Considerations

1. N/Aster product problem product problem	No.	Applicable S	imultaneous T	ransmission			
	1.	N/A	Ano	Anbotek	Anbor	Anotek	P2

Note:

- 1. WIFI 2.4GHz and 5GHz share the same antenna, and cannot transmit simultaneously.
- 2. Bluetooth stand-alone SAR tests are not required and are considered zero in the SAR summation.
- 3. Multi-band transmission analysis for Body SAR is performed following EN62209-2 procedure.

Page 34 of 82

13.2 Evaluation of Simultaneous SAR

N/A

Shenzhen Anbotek Compliance Laboratory Limited





14. Measurement Uncertainty

PerKDB865664D01 SAR Measurement 100MHz to 6GHz, when the highest measured 1-gSAR within a frequency band is<1.5W/Kg, the extensive SAR measurement uncertain tyanalys is described in IEC-62209-1528:2020 is not required in SAR reports submitted for equipment approval.

Page 35 of 82

Shenzhen Anbotek Compliance Laboratory Limited

Address: 1/F., Building D, Sogood Science and Technology Park, Sanwei Community, Hangcheng Street, Bao'an District, Shenzhen, Guangdong, China. Tel:(86) 755–26066440 Fax: (86) 755–26014772 Email: service@anbotek.com



Page 36 of 82

Appendix A. EUT Photos and Test Setup Photos



Body Frant(0mm)

Body Back(0mm)



Body Left (0mm)



(0mm) Body Bottom (0mm)

Shenzhen Anbotek Compliance Laboratory Limited





Appendix B. Plots of SAR System Check

2450MHz Head System Check Date:12/26/2022

DUT: Dipole 2450 MHz; Type: D2450V2; Serial: D2450V2 - SN:910 Communication System: UID 0, CW; Frequency: 2450 MHz;Duty Cycle: 1:1 Medium parameters used: f = 2450 MHz; σ = 1.74 S/m; ϵ_r = 38.79; ρ = 1000 kg/m³ Phantom section: Flat Section

Page 37 of 82

DASY5 Configuration:

- Probe: EX3DV4 SN7396; ConvF(7.57, 7.57, 7.57); Calibrated: 05,06.2022;
- Sensor-Surface: 2mm (Mechanical Surface Detection)
- Electronics: DAE4 Sn387; Calibrated: 09.06.2022
- Phantom: SAM; Type: QD000P40CD; Serial: TP:1670
- Measurement SW: DASY52, Version 52.8 (2); SEMCAD X Version 14.6.10 (7164)

Configuration/Pin=250mW/Area Scan (81x81x1):Interpolated grid: dx=1.200 mm, dy=1.200 mm Maximum value of SAR (interpolated) = 18.49 W/kg

Configuration/Pin=250mW/Zoom Scan (7x7x7)/Cube 0:Measurement grid: dx=5mm, dy=5mm, dz=5mm

Reference Value = 83.71 V/m; Power Drift = 0.05 dB Peak SAR (extrapolated) =21.63 W/kg SAR(1 g) =5.79 W/kg; SAR(10 g) = 12.81 W/kg Maximum value of SAR (measured) = 15.74 W/kg



Shenzhen Anbotek Compliance Laboratory Limited

Address: 1/F., Building D, Sogood Science and Technology Park, Sanwei Community, Hangcheng Street, Bao'an District, Shenzhen, Guangdong, China. Tel:(86) 755–26066440 Fax: (86) 755–26014772 Email: service@anbotek.com



5200MHzHeadSystemCheck Date:12/27/2022

DUT: Dipole 5GHz; Type: D5GHzV2; Serial: D5GHzV2-SN: 1160 Communication System: UID0,CW;Frequency:5200MHz;DutyCycle:1:1 Medium parameters used: f=5200MHz; σ =4.65S/m; ϵ_r =35.46; ρ =1000kg/m³ Phantom section: Flat Section

DASY5Configuration:

- Probe:EX3DV4–SN7396;ConvF(4.93,4.93,4.93);Calibrated: 05,06.2022;
- Sensor-Surface:2mm(Mechanical Surface Detection)
- Electronics:DAE4Sn387;Calibrated: 09,06.2022
- Phantom:SAM;Type:QD000P40CD;Serial:TP:1670
- MeasurementSW:DASY52,Version52.8(2);SEMCADXVersion14.6.10(7164)

Configuration/Pin=100mW/ZoomScan(7x7x7)/Cube0:Measurementgrid:dx=4mm,dy=4mm,dz=1.4mm Reference Value=57.69V/m; Power Drift=-0.04dB Peak SAR(extrapolated)=31.28W/kg

age 38 of 82

SAR(1g)=7.67W/kg; SAR(10g)=7.91W/kg Maximum value of SAR(measured)=20.16W/kg

Configuration/Pin=100mW/AreaScan(71x71x1):Interpolatedgrid:dx=1.000mm,dy=1.000mm Maximum value of SAR(interpolated)=18.44W/kg



Shenzhen Anbotek Compliance Laboratory Limited



Appendix C. Plots of SAR Test Data

#1

nbotek

Product Safety

Date: 12/26/2022

age

39 of 82

WIFI 2.4G _802.11b_Body Back _Ch06

Communication System: UID 0, wifi (fcc) (0); Frequency: 2437 MHz; Duty Cycle: 1:1 Medium parameters used (interpolated): f = 2437 MHz; σ = 1.74. S/m; ϵ_r = 38.79; ρ = 1000 kg/m³ Phantom section: Flat Section

DASY5 Configuration:

•Probe: EX3DV4 - SN7396; ConvF(7.53, 7.53, 7.53); Calibrated: 05,06.2022;

•Sensor-Surface: 4mm (Mechanical Surface Detection)

•Electronics: DAE4 Sn387; Calibrated: 09.06.2022

•Phantom: SAM 1; Type: SAM;

•Measurement SW: DASY52, Version 52.8 (2); SEMCAD X Version 14.6.10 (7164)

Configuration/BACK/Area Scan (33x17x1): Measurement grid: dx=10mm, dy=10mm

Maximum value of SAR (measured) = 0.329 W/kg

Configuration/BACK/Zoom Scan (7x7x7)/Cube 0: Measurement grid: dx=5mm, dy=5mm, dz=5mm

Reference Value = 8.43 V/m; Power Drift = 0.03 dB Peak SAR (extrapolated) = 0.312 W/kg

SAR(1 g) = 0.332 W/kg; SAR(10 g) = 0.135 W/kg Maximum value of SAR (measured) = 0.326 W/kg



Shenzhen Anbotek Compliance Laboratory Limited

Address: 1/F., Building D, Sogood Science and Technology Park, Sanwei Community, Hangcheng Street, Bao'an District, Shenzhen, Guangdong, China. Tel:(86) 755–26066440 Fax: (86) 755–26014772 Email: service@anbotek.com



#2

Page 40 of 82

Date: 12/27/2022

WIFI 5.2G _802.11a_Body Front _5240

Communication System: UID 0, 802.11a (0); Frequency: 5240 MHz; Duty Cycle: 1:1 Medium parameters used: f = 5240 MHz; σ = 4.65 S/m; ϵ_r = 35.46; ρ = 1000 kg/m³ Phantom section: Flat Section

DASY5Configuration:

- Probe:EX3DV4–SN7396;ConvF(4.93,4.93,4.93);Calibrated: 05,06.2022;
- Sensor-Surface:2mm(Mechanical Surface Detection)
- Electronics:DAE4Sn387;Calibrated: 09.06.2022
- Phantom:SAM;Type:QD000P40CD;Serial:TP:1670
- MeasurementSW:DASY52,Version52.8(2);SEMCADXVersion14.6.10(7164)

BODY/BACK/Area Scan (8x12x1): Measurement grid: dx=15mm, dy=15mm Maximum value of SAR (measured) = 0.357 W/kg

BODY/BACK/Zoom Scan (5x5x7)/Cube 0: Measurement grid: dx=8mm, dy=8mm, dz=5mm Reference Value =5.651 V/m; Power Drift = 0.02 dB Peak SAR (extrapolated) = 0.465 W/kg SAR(1 g) = 0.321W/kg; SAR(10 g) = 0.161 W/kg Maximum value of SAR (measured) = 0.374 W/kg



Shenzhen Anbotek Compliance Laboratory Limited

Address: 1/F., Building D, Sogood Science and Technology Park, Sanwei Community, Hangcheng Street, Bao'an District, Shenzhen, Guangdong, China. Tel:(86) 755–26066440 Fax: (86) 755–26014772 Email: service@anbotek.com



#3

Date: 12/27/2022

Page 41 of 82

WIFI 5.8G _802.11a_Body BACK _5825

Communication System: UID 0, 802.11a (0); Frequency: 5825 MHz;Duty Cycle: 1:1 Medium parameters used: f = 5825 MHz; σ = 4.65 S/m; ϵ_r = 35.46; ρ = 1000 kg/m³ Phantom section: Flat Section

DASY5Configuration:

- Probe:EX3DV4–SN7396;ConvF(4.93,4.93,4.93);Calibrated: 05,06.2022;
- Sensor-Surface:2mm(Mechanical Surface Detection)
- Electronics:DAE4Sn387;Calibrated:09.06.2022
- Phantom:SAM;Type:QD000P40CD;Serial:TP:1670
- MeasurementSW:DASY52, Version52.8(2); SEMCADXVersion14.6.10(7164)

BODY/BACK/Area Scan (8x12x1): Measurement grid: dx=15mm, dy=15mm Maximum value of SAR (measured) = 0.439 W/kg

BODY/BACK/Zoom Scan (5x5x7)/Cube 0: Measurement grid: dx=8mm, dy=8mm, dz=5mm Reference Value = 14.62 V/m; Power Drift = 0.09 dB Peak SAR (extrapolated) = 0.457 W/kg SAR(1 g) = 0.297 W/kg; SAR(10 g) = 0.157 W/kg Maximum value of SAR (measured) = 0.371 W/kg



Shenzhen Anbotek Compliance Laboratory Limited

Address: 1/F., Building D, Sogood Science and Technology Park, Sanwei Community, Hangcheng Street, Bao'an District, Shenzhen, Guangdong, China. Tel:(86) 755–26066440 Fax: (86) 755–26014772 Email: service@anbotek.com



Anbotek Product Safety

Page 42 of 82

Appendix D. DASY System Calibration Certificate

Shenzhen Anbotek Compliance Laboratory Limited





Network Analyzer E5071C MY46110673 13-Jan-22 (CTTL, No.J22X00285) Jan -22 Name Function ignature Calibrated by: Yu Zongying SAR Test Engineer Reviewed by: Lin Hao SAR Test Engineer Approved by: Qi Dianyuan SAR Project Leader Issued: May06 , 2022

This calibration certificate shall not be reproduced except in full without written approval of the laboratory.

Certificate No: Z21-98671

Page 1 of 11

Shenzhen Anbotek Compliance Laboratory Limited





 Add: No.51 Xueyuan Road, Haidian District, Beijing, 100191, China

 Tel: +86-10-62304633-2218
 Fax: +86-10-62304633-2209

 E-mail: cttl@chinattl.com
 <u>Http://www.chinattl.cn</u>

Glossary:

TSL	tissue simulating liquid
NORMx,y,z	sensitivity in free space
ConvF	sensitivity in TSL / NORMx,y,z
DCP	diode compression point
CF	crest factor (1/duty cycle) of the RF signal
A,B,C,D	modulation dependent linearization parameters
Polarization Φ	Φ rotation around probe axis
Polarization θ	θ rotation around an axis that is in the plane normal to probe axis (at measurement center), i
	θ =0 is normal to probe axis

age

of

Connector Angle information used in DASY system to align probe sensor X to the robot coordinate system Calibration is Performed According to the Following Standards:

- a) IEEE Std 1528-2013, "IEEE Recommended Practice for Determining the Peak Spatial-Averaged Specific Absorption Rate (SAR) in the Human Head from Wireless Communications Devices: Measurement Techniques", June 2013
- b) IEC 62209-1, "Procedure to measure the Specific Absorption Rate (SAR) for hand-held devices used in close proximity to the ear (frequency range of 300MHz to 3GHz)", February 2005
- c) IEC 62209-2, "Procedure to determine the Specific Absorption Rate (SAR) for wireless communication devices used in close proximity to the human body (frequency range of 30 MHz to 6 GHz)", March 2010

d) KDB 865664, "SAR Measurement Requirements for 100 MHz to 6 GHz"

Methods Applied and Interpretation of Parameters:

- NORMx, y, z: Assessed for E-field polarization θ=0 (f≤900MHz in TEM-cell; f>1800MHz: waveguide). NORMx, y, z are only intermediate values, i.e., the uncertainties of NORMx, y, z does not effect the E²-field uncertainty inside TSL (see below ConvF).
- NORM(f)x,y,z = NORMx,y,z* frequency_response (see Frequency Response Chart). This linearization is implemented in DASY4 software versions later than 4.2. The uncertainty of the frequency response is included in the stated uncertainty of ConvF.
- DCPx, y, z: DCP are numerical linearization parameters assessed based on the data of power sweep (no uncertainty required). DCP does not depend on frequency nor media.
- PAR: PAR is the Peak to Average Ratio that is not calibrated but determined based on the signal characteristics.
- Ax,y,z; Bx,y,z; Cx,y,z; VRx,y,z:A,B,C are numerical linearization parameters assessed based on the data of power sweep for specific modulation signal. The parameters do not depend on frequency nor media. VR is the maximum calibration range expressed in RMS voltage across the diode.
- ConvF and Boundary Effect Parameters: Assessed in flat phantom using E-field (or Temperature Transfer Standard for f≤800MHz) and inside waveguide using analytical field distributions based on power measurements for f >800MHz. The same setups are used for assessment of the parameters applied for boundary compensation (alpha, depth) of which typical uncertainty valued are given. These parameters are used in DASY4 software to improve probe accuracy close to the boundary. The sensitivity in TSL corresponds to NORMx,y,z* ConvF whereby the uncertainty corresponds to that given for ConvF. A frequency dependent ConvF is used in DASY version 4.4 and higher which allows extending the validity from±50MHz to±100MHz.
- Spherical isotropy (3D deviation from isotropy): in a field of low gradients realized using a flat phantom exposed by a patch antenna.
- Sensor Offset: The sensor offset corresponds to the offset of virtual measurement center from the
 probe tip (on probe axis). No tolerance required.
- Connector Angle: The angle is assessed using the information gained by determining the NORMx (no uncertainty required).

Certificate No: Z21-98671

Page 2 of 11

Shenzhen Anbotek Compliance Laboratory Limited

Address: 1/F., Building D, Sogood Science and Technology Park, Sanwei Community, Hangcheng Street, Bao'an District, Shenzhen, Guangdong, China. Tel:(86) 755–26066440 Fax: (86) 755–26014772 Email: service@anbotek.com