



www.xinjismart.com

Made in China

FC CE RoHS

© 2023 XINJI Smart. All rights reserved.

Heart rate monitoring
The measurement starts after the green indicator light at the bottom is on, and is completed after the vibration occurs in about 30-60s. The measurement is based on PPG technology.

Blood oxygen monitoring
The measurement starts after the red indicator light at the bottom is on, and is completed after the vibration occurs in about 30-60s. The measurement is based on PPG technology.

Sleep monitoring
It records and shows your sleep status that day. The data is updated every day and synchronized to the APP in the same time.

Sport mode
Get active your way by choosing your favorite workout modes, including hiking, running, climbing, cycling, basketball, yoga and elliptical and so on.

Breath training
Select the corresponding time, and follow the prompts on the watch until it is completed.

Women's health
Set your gender to female in the app and add information about the menstrual period. You can set up a period reminder with app.

Alarm clock
Find the alarm function in the list and add alarm clock according to the corresponding settings.

Stopwatch
Click the triangle icon to start and click again to pause (the left icon means resetting).

Timer
Count down from a specified time with the timer, and it ends with the vibration reminder.

Music
Turn on notification reminder in the app and open the music player on the watch to control music playback.

Watch face
Long press the home screen to switch watch faces. You can install hundreds of different watch faces on your watch through the app, or customize your favorite picture as a watch face.

Menu style
Select a menu style in watch settings. The menu supports list mode and smart mode.

Power on/off
Long press button for 3s to power on. The watch will automatically power on when it is charging. Choose 'Power Off' in the watch setting and click 'V' icon to shutdown.

System info
View the Bluetooth name, Mac address, Firmware version number and other information of the watch.

Reset
All personal data will be removed if you confirm to restore factory settings.

Warranty card

Customer information		Seller information	
Name		Name	
Add.		Add.	
E-mail		Purchase Date	
P.C.		Product model	
Tel		Invoice number	
Date	Malfunction	Process result	




COBEE C1 PROS SMART WATCH
USER MANUAL

Scan the QR code to get multilingual user manual.

Packing list

Smart Watch x1
Charging Cable x1
Watch Bands (Extra) x1
User Manual x1

Specifications

Product model: C1 PROS
Waterproof rating: IP68
Sensor: 3-axis G-sensor
Battery capacity: 280mAh
Synchronization method: Bluetooth
Resolution: 240*296
Display: 1.91 inch TFT
Battery life: about 7-10 days
Working temperature: -10°C-50°C
Compatible system: IOS 12.0 or above, Android 6.0 or above

Please read the instructions before use

- The watch has a water resistance rating of 5ATM. It can be used normally in daily life such as washing hands, raining, etc. Do not put the watch in hot water, do not perform underwater pressing operations or deep diving. Not recommended to wear it in the shower.
- The waterproof function is not permanently effective, and the protective performance may be reduced due to daily wear and tear.
- Do not disassemble the product or replace the battery without authorization. If the product fails, please contact the after-sales service department.
- Avoid touching the screen surface with sharp or sticky objects to avoid damage. Avoid dropping the product on the ground or being strongly impacted by other objects. Avoid exposing the watch to corrosive liquids to avoid damage to the watch.
- Charge the battery for two hours before use. Please avoid overcharging at 100% for an extended time. Place the magnetic charging cable on the back of your smart watch and the end of the charging cable magnetically sticks to the back of your watch and aligns it properly.
- Please use the charger with an input voltage of 5V/1A or 5V/2A and XINJI's original charging cable.
- This product is not a medical device and cannot be used for medical purposes or as basis for diagnosis of any medical condition. Detection results are provided for reference only. Please consult professional medical institutions if you feel unwell.
- The company reserves the right to change or modify all the information in the document without notice. Due to software upgrades, the functions may vary in specific software versions.

APP download & login

OnWear Pro App download

- Get OnWear Pro app in the App Store on your iPhone.
- Get OnWear Pro app in Google Play on your Android phone.
- Or scan the QR code in the watch to download the APP (compatible: IOS12.0 or above / Android6.0 or above).

After installing the APP, please register and log in according to the interface prompts, and turn on Bluetooth at the same time.

In the Device interface of OnWear Pro app, select the Bluetooth name: "XINJI-C1PROS" for binding, and the watch can be used normally.

Method of operation

From the home screen, swipe up from the bottom of the screen to enter the function menu list interface

From the home screen, swipe down from the top of the screen to enter the the information list interface.

From the home screen, swipe left from the right of the screen to enter the interface of steps, heart rate, sleep and other interfaces.

From the home screen, swipe right from the left of the screen to enter the fast interface.

Exercise data
Check the corresponding date for the day, including steps, distance, and calories.

Message
Turn on notification reminder and call reminder in the app, and information received by the mobile phone will be pushed to the smart watch synchronously. The watch can store multiple pieces of information.

Weather
Turn on Weather Push in the app, and the weather will be automatically synchronized to the watch.

Frequent contacts
After the watch is connected to the mobile APP, find the frequently used contacts in the settings, and add contacts as required.

Dial
After connecting the APP, match the watch Bluetooth with the mobile phone, the Bluetooth display connection state, you can call from the watch.

Language Assistant
After the watch is connected to the mobile APP, the language assistant function can be used directly.

说明书折页
128克双面铜版, 4C印刷, 正反14P风琴折,
490×70mm

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement in portable exposure condition without restriction.