
 <small>A Phoenix Mecano Company</small>	Issue Department: Bedding Division	Date:	2021-07-20
	System Instruction	Author:	
Instruction of RF400B		Edition:	1.1
		Page 1 of 4	

Instruction of RF400B



Figure 1 button of remote

 <small>A Phoenix Mecano Company</small>	Issue Department: Bedding Division	Date:	2021-07-20
	System Instruction	Author:	
	Instruction of RF400B		
		Edition:	1.1
		Page 2 of 4	

1 Item

1.1 ZG button (16)

Click the ZG button, the actuator moves to ZG position, stop when click any button during the movement;

Press and hold the ZG button for 5s, timer LED of remote flashes, the control box records current position as ZG position;

When in the process of moving to memory positions, the head and foot actuators move first, then the tilt and lumbar actuators move;

1.2 AntiSnore button (14)

Click AntiSnore button, actuators move to AntiSnore position, stop when click any button during movement;

Press and hold AntiSnore button for 5s, timer LED of remote flashes, the control box records current position as AntiSnore position;

When in the process of moving to memory positions, the head and foot actuators move first, then the tilt and lumbar actuators move;

1.3 Reset all memory positions to default settings (9) + (16)


Press and hold ZG+FLAT buttons (button 1 and 16 in figure 2) for 5s, timer LED of remote flashes, the control box reset all memory positions to default settings;

1.4 Head up (7)

Press and hold HEAD UP button of remote, head actuator moves out, stop when released;

1.5 Head down (8)

Press and hold HEAD DOWN button of remote, head actuator moves in, stop when released;

 <small>A Phoenix Mecano Company</small>	Issue Department: Bedding Division	Date:	2021-07-20
	System Instruction	Author:	
Instruction of RF400B		Edition:	1.1
		Page 3 of 4	

1.6 Lumbar up ④

Press and hold Lumbar up button of remote, Lumbar actuator moves out, stop when released;

1.7 Lumbar down ⑥

Press and hold Lumbar down button of remote, Lumbar actuator moves in, stop when released;

1.8 Foot up ⑩

Press and hold FOOT UP button of remote, foot actuator moves out, stop when released;

1.9 foot down ⑫

Press and hold FOOT DOWN button of remote, foot actuator moves in, stop when released;
When moving to flat position, lumbar actuator and tilt actuator move first, after 500ms, head and foot actuators start moving;

1.10 Flat ⑨


Click FLAT button, the bed goes flat, stop when click any button during the process of going flat;

1.11 Massage head ①

Click MASSAGE HEAD button, head massage motor switches massage intensity, massage intensity switches among 0-1-2-3;

1.12 Massage foot ③

Click MASSAGE Foot button, head massage motor switches massage intensity, massage intensity switches among 0-1-2-3;

 <small>A Phoenix Mecano Company</small>	Issue Department: Bedding Division	Date:	2021-07-20
	System Instruction	Author:	
	Instruction of RF400B		
		Edition:	1.1
		Page 4 of 4	

1.13 Massage timer ②

If the massage motors do not work, the button is invalid, if the massage motors work, click the button to switch the massage time, when massage time switch to 0, turn off the massage;

1.14 Under bed light ⑤

Click the under bed light button, the under bed light switch its on/off state; After the under bed light opens, if do not manually close, it will automatically turn off after 5 minutes;

1.15 Memory position (13) (15)

Click memory position to move the actuator to the memory position.

FCC Warning:

Please take attention that changes or modification not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

ISED RSS Warning:

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radioexempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.