

SAR Evaluation Report

IN ACCORDANCE WITH THE REQUIREMENTS OF FCC OET BULLETIN 65 SUPPLEMENT C IC RSS 102 ISSUE 1 : 1999

FOR

UHF FM TRANSCEIVER

MODEL: MC1000

FCC ID: B4HMC1000

REPORT NUMBER: 06J10748-7

ISSUE DATE: MARCH 26, 2007

Prepared for

PORTA PHONE CO. **145 DEAN KNAUSS DRIVE** NARRAGANSETT, RI 02882, USA

Prepared by

COMPLIANCE CERTIFICATION SERVICES 47173 BENICIA STREET FREMONT, CA 94538, USA



NVLAP LAB CODE 200065-0

Revision History

Rev.	Issued date	Revisions	Revised By
	March 26, 2007	Initial issue	Sunny Shih

CERTIFICATE OF COMPLIANCE (SAR EVALUATION)

DATES OF TEST: March 26, 2007			
APPLICANT:	PORTA PHONE CO.		
ADDRESS:	145 DEAN KNAUSS DRIVE, NARRAGANSETT, RI 02882, USA		
FCC ID:	B4HMC1000		
MODEL:	MC1000		
DEVICE CATEGORY:	Portable Device		
EXPOSURE CATEGORY:	Occupational/Controlled Exposure		

UHF FM TRANSCEIVER

Test Sample is a:	Production unit	
Rule Parts	Frequency Range [MHz]	The Highest SAR Values [1g_mW/g] at 50 % duty factor
95A	462.5625 - 462.7250	0.9

This wireless portable device has been shown to be capable of compliance for localized specific absorption rate (SAR) for Occupational/Controlled Exposure limits specified in ANSI/IEEE Std. C95.1-1992 and had been tested in accordance with the measurement procedures specified in FCC OET 65 Supplement C (Edition 01-01) and RSS 102.

Note: The results documented in this report apply only to the tested sample, under the conditions and modes of operation as described herein. This document may not be altered or revised in any way unless done so by Compliance Certification Services and all revisions are duly noted in the revisions section. Any alteration of this document not carried out by Compliance Certification Services will constitute fraud and shall nullify the document. No part of this report may be used to claim product certification, approval, or endorsement by NVLAP, NIST, or any government agency.

Approved & Released For CCS By:

Hsin Fr Shih

Hsin Fu Shih Engineering Supervisor Compliance Certification Services Tested By:

Winay Dorouch

Ninous Davoudi EMC Engineer Compliance Certification Services

TABLE OF CONTENTS

1	EQl	JIPMENT UNDER TEST (EUT) DESCRIPTION	5
2	FAC	CILITIES AND ACCREDITATION	6
3	SYS	STEM DESCRIPTION	7
4	COI	MPOSITION OF INGREDIENTS FOR TISSUE SIMULATING LIQUIDS	8
5	TES	T POSITIONS FOR DEVICES OPERATING NEXT TO A PERSON'S EAR	9
	5.1	CHEEK/TOUCH POSITION	10
	5.2	EAR/TILT POSITION	11
	5.3	TEST POSITIONS FOR BODY-WORN AND OTHER SIMILAR CONFIGURATIONS	12
6	SIM	ULATING LIQUID PARAMETERS CHECK	13
	6.1	SIMULATING LIQUID PARAMETER CHECK RESULT	14
7	SYS	STEM PERFORMANCE CHECK	16
	7.1	SYSTEM PERFORMANCE CHECK RESULTS	17
8	SAF	R MEASURMENT PROCEDURE	18
	8.1	DASY4 SAR MEASURMENT PROCEDURE	19
9	COI	NDUCTED OUTPUT POWER	20
10	SAF	R MEASURMENT RESULTS	21
	10.1	BODY-WORN POSITION	21
	10.2	FACE-HELD POSITION	22
11	ME	ASURMENT UNCERTAINTY	23
	11.1	MEASURMENT UNCERTAINTY FOR 300 MHZ – 3000 MHZ	23
12	EQI	JIPMENT LIST AND CALIBRATION	24
13	EUT	PHOTOS	25
14	ATT	ACHMENTS	27

1 EQUIPMENT UNDER TEST (EUT) DESCRIPTION

UHF FM Transceiver	
Normal operation:	Face-held and Body worn (Belt-clip)
Earphone/Headset Jack:	Headset with micropone and speaker
Duty cycle:	100%
Antenna(s):	Helical, ¼ wave with SMA-J connector, gain = 0 dBi
Power supply:	Recharge battery - KYD, Model BL06028, rated 6 Vdc, 1100 mA

2 FACILITIES AND ACCREDITATION

The test sites and measurement facilities used to collect data are located at 561F Monterey Road, Morgan Hill, California, USA. The sites are constructed in conformance with the requirements of ANSI C63.4, ANSI C63.7 and CISPR Publication 22. All receiving equipment conforms to CISPR Publication 16-1, "Radio Interference Measuring Apparatus and Measurement Methods."



CCS is accredited by NVLAP, Laboratory Code 200065-0. The full scope of accreditation can be viewed at http://www.ccsemc.com.

No part of this report may be used to claim product certification, approval, or endorsement by NVLAP, NIST, or any government agency.

3 SYSTEM DESCRIPTION



The DASY4 system for performing compliance tests consists of the following items:

- A standard high precision 6-axis robot (Stäubli RX family) with controller, teach pendant and software. An arm extension for accommodating the data acquisition electronics (DAE).
- A dosimetric probe, i.e., an isotropic E-field probe optimized and calibrated for usage in tissue simulating liquid. The probe is equipped with an optical surface detector system.
- A data acquisition electronics (DAE) which performs the signal amplification, signal multiplexing, AD-conversion, offset measurements, mechanical surface detection, collision detection, etc. The unit is battery powered with standard or rechargeable batteries. The signal is optically transmitted to the EOC.
- The function of the measurement server is to perform the time critical tasks such as signal filtering, control of the robot operation and fast movement interrupts.
- A probe alignment unit which improves the (absolute) accuracy of the probe positioning.
- A computer operating Windows 2000 or Windows XP.
- DASY4 software.
- Remote controls with teach pendant and additional circuitry for robot safety such as warning lamps, etc.
- The SAM twin phantom enabling testing left-hand and right-hand usage.
- The device holder for handheld mobile phones.
- Tissue simulating liquid mixed according to the given recipes.
- Validation dipole kits allowing to validate the proper functioning of the system.

4 COMPOSITION OF INGREDIENTS FOR TISSUE SIMULATING LIQUIDS

The following tissue formulations are provided for reference only as some of the parameters have not been thoroughly verified. The composition of ingredients may be modified accordingly to achieve the desired target tissue parameters required for routine SAR evaluation.

Ingredients			Frequency (MHz)							
(% by weight)	4	50	83	35	· 9′	15	19	00	24	50
Tissue Type	Head	Body	Head	Body	Head	Body	Head	Body	Head	Body
Water	38.56	51.16	41.45	52.4	41.05	56.0	54.9	40.4	62.7	73.2
Salt (NaCl)	3.95	1.49	1.45	1.4	1.35	0.76	0.18	0.5	0.5	0.04
Sugar	56.32	46.78	56.0	45.0	56.5	41.76	0.0	58.0	0.0	0.0
HEC	0.98	0.52	1.0	1.0	1.0	1.21	0.0	1.0	0.0	0.0
Bactericide	0.19	0.05	0.1	0.1	0.1	0.27	0.0	0.1	0.0	0.0
Triton X-100	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	36.8	0.0
DGBE	0.0	0.0	0.0	0.0	0.0	0.0	44.92	0.0	0.0	26.7
Dielectric Constant	43.42	58.0	42.54	56.1	42.0	56.8	39.9	54.0	39.8	52.5
Conductivity (S/m)	0.85	0.83	0.91	0.95	1.0	1.07	1.42	1.45	1.88	1.78

Salt: 99+% Pure Sodium ChlorideSugar: 98+% Pure SucroseWater: De-ionized, 16 MΩ+ resistivityHEC: Hydroxyethyl CelluloseDGBE: 99+% Di(ethylene glycol) butyl ether, [2-(2-butoxyethoxy)ethanol]Triton X-100 (ultra pure): Polyethylene glycol mono [4-(1,1, 3, 3-tetramethylbutyl)phenyl]ether

5 TEST POSITIONS FOR DEVICES OPERATING NEXT TO A PERSON'S EAR

This category includes most wireless handsets with fixed, retractable or internal antennas located toward the top half of the device, with or without a foldout, sliding or similar keypad cover. The handset should have its earpiece located within the upper 1/4 of the device, either along the centerline or off-centered, as perceived by its users. This type of handset should be positioned in a normal operating position with the "test device reference point" located along the "vertical centerline" on the front of the device aligned to the "ear reference point". The "test device reference point" should be located at the same level as the center of the earpiece region. The "vertical centerline" should bisect the front surface of the handset at its top and bottom edges. A "ear reference point" is located on the outer surface of the head phantom on each ear spacer. It is located 1.5 cm above the center of the ear canal entrance in the "phantom reference plane" defined by the three lines joining the center of each "ear reference point" (left and right) and the tip of the mouth.

A handset should be initially positioned with the earpiece region pressed against the ear spacer of a head phantom. For the SCC-34/SC-2 head phantom, the device should be positioned parallel to the "N-F" line defined along the base of the ear spacer that contains the "ear reference point". For interim head phantoms, the device should be positioned parallel to the cheek for maximum RF energy coupling. The "test device reference point" is aligned to the "ear reference point" on the head phantom and the "vertical centerline" is aligned to the "phantom reference plane". This is called the "initial ear position". While maintaining these three alignments, the body of the handset is gradually adjusted to each of the following positions for evaluating SAR:



5.1 CHEEK/TOUCH POSITION

The device is brought toward the mouth of the head phantom by pivoting against the "ear reference point" or along the "N-F" line for the SCC-34/SC-2 head phantom.

This test position is established:

- i. When any point on the display, keypad or mouthpiece portions of the handset is in contact with the phantom.
- ii. (or) When any portion of a foldout, sliding or similar keypad cover opened to its intended self-adjusting normal use position is in contact with the cheek or mouth of the phantom.

For existing head phantoms – when the handset loses contact with the phantom at the pivoting point, rotation should continue until the device touches the cheek of the phantom or breaks its last contact from the ear spacer.



Cheek / Touch Position

5.2 EAR/TILT POSITION

With the handset aligned in the "Cheek/Touch Position":

- i. If the earpiece of the handset is not in full contact with the phantom's ear spacer (in the "Cheek/Touch position") and the peak SAR location for the "Cheek/Touch" position is located at the ear spacer region or corresponds to the earpiece region of the handset, the device should be returned to the "initial ear position" by rotating it away from the mouth until the earpiece is in full contact with the ear spacer.
- ii. (otherwise) The handset should be moved (translated) away from the cheek perpendicular to the line passes through both "ear reference points" (note: one of these ear reference points may not physically exist on a split head model) for approximate 2-3 cm. While it is in this position, the device handset is tilted away from the mouth with respect to the "test device reference point" until the inside angle between the vertical centerline on the front surface of the phone and the horizontal line passing through the ear reference point is by 15°. After the tilt, it is then moved (translated) back toward the head perpendicular to the line passes through both "ear reference points" until the device touches the phantom or the ear spacer. If the antenna touches the head first, the positioning process should be repeated with a tilt angle less than 15° so that the device and its antenna would touch the phantom simultaneously. This test position may require a device holder or positioner to achieve the translation and tilting with acceptable positioning repeatability.

If a device is also designed to transmit with its keypad cover closed for operating in the head position, such positions should also be considered in the SAR evaluation. The device should be tested on the left and right side of the head phantom in the "Cheek/Touch" and "Ear/Tilt" positions. When applicable, each configuration should be tested with the antenna in its fully extended and fully retracted positions. These test configurations should be tested at the high, middle and low frequency channels of each operating mode; for example, AMPS, CDMA, and TDMA. If the SAR measured at the middle channel for each test configuration (left, right, Cheek/Touch, Tilt/Ear, extended and retracted) is at least 3.0 dB lower than the SAR limit, testing at the high and low channels is optional for such test configuration(s). If the transmission band of the test device is less than 10 MHz, testing at the high and low frequency channels is optional.



5.3 TEST POSITIONS FOR BODY-WORN AND OTHER SIMILAR CONFIGURATIONS

Without the belt-clips or holsters

Body-worn accessories may not always be supplied or available as options for some devices that are intended to be authorized for body-worn use. A separation distance of 1.5 cm between the back of the device and a flat phantom is recommended for testing body-worn SAR compliance under such circumstances. Other separation distances may be used, but they should not exceed 2.5 cm. In these cases, the device may use body-worn accessories that provide a separation distance greater than that tested for the device provided however that the accessory contains no metallic components.

6 SIMULATING LIQUID PARAMETERS CHECK

The simulating liquids should be checked at the beginning of a series of SAR measurements to determine of the dielectric parameters are within the tolerances of the specified target values. The relative permittivity and conductivity of the tissue material should be within \pm 5% of the values given in the table below.



Set-up for liquid parameters check

Reference Values of Tissue Dielectric Parameters for Head and Body Phantom (for 150 – 3000 MHz and 5800 MHz)

The head tissue dielectric parameters recommended by the IEEE SCC-34/SC-2 in IEEE Standard 1528 have been incorporated in the following table. These head parameters are derived from planar layer models simulating the highest expected SAR for the dielectric properties and tissue thickness variations in a human head. Other head and body tissue parameters that have not been specified in P1528 are derived from the tissue dielectric parameters computed from the 4-Cole-Cole equations and extrapolated according to the head parameters specified in IEEE Standard 1528.

Target Frequency (MHz)	He	ad	Body		
raiget i requency (ivii iz)	ε _r	σ (S/m)	ε _r	σ (S/m)	
150	52.3	0.76	61.9	0.80	
300	45.3	0.87	58.2	0.92	
450	43.5	0.87	56.7	0.94	
835	41.5	0.90	55.2	0.97	
900	41.5	0.97	55.0	1.05	
915	41.5	0.98	55.0	1.06	
1450	40.5	1.20	54.0	1.30	
1610	40.3	1.29	53.8	1.40	
1800 – 2000	40.0	1.40	53.3	1.52	
2450	39.2	1.80	52.7	1.95	
3000	38.5	2.40	52.0	2.73	
5800	35.3	5.27	48.2	6.00	

(ε_r = relative permittivity, σ = conductivity and ρ = 1000 kg/m³)

6.1 SIMULATING LIQUID PARAMETER CHECK RESULT

Simulating Liquid Dielectric Parameters Check Result @ Head 450 MHz

Room Ambient Temperature = 22°C; Relative humidity = 50%

Measured by: Ninous Davoudi

f (MHz)	imulating Lic Temp. (°C)	quid Depth (cm)		Parameters		Measured	Target	Deviation (%)	Limit (%)
450	21	15	e'	44.2067	Relative Permittivity (ε_r):	44.2067	43.5	1.62	± 5
400	21	10	e"	34.1888	Conductivity (σ):	0.85588	0.87	-1.62	± 5
Liquid Ch	neck								
Ambient	temperat	ure: 22.0 d	deg	. C; Liqu	id temperature: 21.0 o	deg C			
March 26	6, 2007 08	8:06 AM							
Frequence	су	e'			e"				
3000000	00.	48	.30)71	43.7504				
3100000	00.	47	.96	808	42.9393				
3200000	00.	47	.64	65	42.0209				
3300000	00.	47	.35	539	41.1551				
3400000	00.	47	.07	'80	40.3134				
3500000	00.	46	.66	677	39.6198				
3600000	00.	46	.35	535	38.9766				
3700000	00.	46	.1949 38.2914						
3800000	00.	45	.8840 37.7278						
3900000	00.	45	.59	930	37.1270				
4000000	00.	45	.34	22	36.7181				
4100000	00.	45	6.12	200	36.1418				
4200000	00.	44	.93	858	35.6269				
4300000	00.	44	.69	961	35.0853				
4400000	00.	44	.44	02	34.6284				
4500000	00.	44	.20	67	34.1888				
4600000	00.	44	.02	253	33.7879				
4700000	00.	43	.75	542	33.4007				
4800000	00.	43	.57	20	32.9540				
4900000	00.	43	.34	86	32.7403				
5000000	00.	43	30.8	859	32.3387				
The cond	luctivity (σ) can be	giv	en as:					
$\sigma = \omega \varepsilon_{\theta}$	e"=2πj	fε₀e"							
where f	• = target f	$f * 10^{6}$							
EØ	= 8.854 *	* 10 ⁻¹²							

Simulating Liquid Dielectric Parameters Check Result @ Muscle 450 MHz

Room Ambient Temperature = 22°C; Relative humidity = 50%

Measured by: Ninous Davoudi

S	imulating Li	quid			Parameters	Measured	Target	Deviation (%)	Limit (%)
f (MHz)	Temp. (°C)	Depth (cm)				modourou		Deviation (70)	2
450	21	15	e'	56.3419	Relative Permittivity (ε_r):	56.342	56.7	-0.63	± 5
400	21	10	e"	35.7388	Conductivity (σ):	0.895	0.94	-4.82	± 5
Liquid Ch	neck								
Ambient	temperat	ure: 22.0 d	deg	. C; Liqu	id temperature: 21.0 o	deg C			
March 26	6, 2007 0	8:27 AM	-	-	-	-			
Frequence	су	e'			e"				
3000000	00.	58	8.58	399	47.3746				
3100000	00.	58	3.39	975	46.2494				
3200000	00.	58	3.17	762	45.0642				
3300000	00.	58	8.06	678	44.0822				
3400000	00.	57	'.89	977	43.0887				
3500000	00.	57	.66	615	42.2548				
3600000	00.	57	.53	366	41.3999				
3700000	00.	57	.42	218	40.7224				
3800000	00.	57	.29	915	40.0576				
3900000	00.	57	.16	64	39.2708				
4000000	00.	57	.05	534	38.7721				
4100000	00.	56	6.92	217	38.0289				
4200000	00.	56	6.79	973	37.4179				
4300000	00.	56	6.65	509	36.7771				
4400000	00.	56	6.45	571	36.2209				
4500000	00.	56	5.34	19	35.7388				
4600000	00.	56	5.19	953	35.3097				
4700000	00.	56	6.06	62	34.8478				
4800000	00.	55	5.91	79	34.4433				
4900000	00.	55	5.82	209	34.1664				
5000000	00.	55	5.71	11	33.7282				
The conductivity (σ) can be given as:									
$\sigma = \omega \varepsilon_{\theta}$	e"=2πj	fε₀e"							
where f	f = target j	f * 10 ⁶							
EO	= 8.854 *	* 10 ⁻¹²							

7 SYSTEM PERFORMANCE CHECK

The system performance check is performed prior to any usage of the system in order to guarantee reproducible results. The system performance check verifies that the system operates within its specifications of $\pm 10\%$.

System Performance Check Measurement Conditions

- The measurements were performed in the flat section of the SAM twin phantom filled with Head simulating liquid of the following parameters.
- The DASY4 system with an Isotropic E-Field Probe EX3DV3-SN: 3531 was used for the measurements.
- The dipole was mounted on the small tripod so that the dipole feed point was positioned below the center marking of the flat phantom section and the dipole was oriented parallel to the body axis (the long side of the phantom). The standard measuring distance was 10 mm (above 1 GHz) and 15 mm (below 1 GHz) from dipole center to the simulating liquid surface.
- The coarse grid with a grid spacing of 15 mm was aligned with the dipole. For 5 GHz band - The coarse grid with a grid spacing of 10 mm was aligned with the dipole.
- Special 5 x 5 x 7 fine cube was chosen for cube integration(dx=dy=7.5mm; dz=5mm).
 For 5 GHz band Special 8x8x8 fine cube was chosen for cube integration(dx=dy=4.3mm; dz=3mm)
- Distance between probe sensors and phantom surface was set to 4 mm.
 For 5 GHz band Distance between probe sensors and phantom surface was set to 2.0mm
- The dipole input power (forward power) was $398 \text{mW} \pm 3\%$.
- The results are normalized to 1 W input power.

Reference SAR Values for Head-tissue

IEEE Standard 1528-2003 Recommended Reference Value.

Frequency (MHz)	Distance (mm)	1g SAR [W/kg]	10g SAR [W/kg]
300	15	3.0	2.0
450	15	4.9	3.3
835	15	9.6	6.2
900	15	10.8	6.9
1450	10	29.0	16.0
1800	10	38.1	19.8
1900	10	39.7	20.5
2000	10	41.1	21.1
2450	10	52.4	24.0
3000	10	63.8	25.7

Note: All SAR values normalized to 1 W forward power.

7.1 SYSTEM PERFORMANCE CHECK RESULTS

System Validation Dipole: D450V2 SN:1003

Date: March 26, 2007

Room Ambient Temperature = 22°C; Relative humidity = 50%

Normalize Head Simulating Liquid Deviation Lim it SAR (mW/g) d Target (%) (%) f (MHz) Temp. (°C) Depth (cm) to 1 W 8.70 1 g 2.12 5.3 4.9 ± 10 450 21 15 3.4 4.31 1.37 3.3 10g ± 10

Measured by: Ninous Davoudi

8 SAR MEASURMENT PROCEDURE

A summary of the procedure follows:

- a) A measurement of the SAR value at a fixed location is used as a reference value for assessing the power drop of the EUT. The SAR at this point is measured at the start of the test, and then again at the end of the test.
- b) The SAR distribution at the exposed flat section of the flat phantom is measured at a distance of 4 mm from the inner surface of the shell. The area covers the entire dimension of the EUT and the horizontal grid spacing is 15 mm x 15 mm. Based on this data, the area of the maximum absorption is determined by Spline interpolation. The first Area Scan covers the entire dimension of the EUT to ensure that the hotspot was correctly identified.

For 5 GHz band - The SAR distribution at the exposed flat section of the flat phantom is measured at a distance of 2.0 mm from the inner surface of the shell. The area covers the entire dimension of the EUT and the horizontal grid spacing is 10 mm x 10 mm. Based on this data, the area of the maximum absorption is determined by Spline interpolation. The first Area Scan covers the entire dimension of the EUT to ensure that the hotspot was correctly identified.

c) Around this point, a volume of X=Y= 30 and Z=21 mm is assessed by measuring 5 x 5 x 7 mm points. On the basis of this data set, the spatial peak SAR value is evaluated with the following procedure:

For 5 GHz band - Around this point, a volume of X=Y=24 and Z=20 mm is assessed by measuring 7 x 7 x 9 mm points. On the basis of this data set, the spatial peak SAR value is evaluated with the following procedure:

- (i) The data at the surface are extrapolated, since the centre of the dipoles is 1.2 mm away from the tip of the probe and the distance between the surface and the lowest measuring point is 1.3 mm. The extrapolation is based on a least square algorithm. A polynomial of the fourth order is calculated through the points in z-axes. This polynomial is then used to evaluate the points between the surface and the probe tip.
- (ii) The maximum interpolated value is searched with a straightforward algorithm. Around this maximum the SAR values averaged over the spatial volumes (1 g and 10 g) are computed using the 3D-Spline interpolation algorithm. The 3D-Spline is composed of three one-dimensional splines with the "Not a knot"- condition (in x, y and z-direction). The volume is integrated with the trapezoidal algorithm. One thousand points (10 x 10 x 10) are interpolated to calculate the averages.
- (iii) All neighbouring volumes are evaluated until no neighbouring volume with a higher average value is found.
- (iv) The SAR value at the same location as in Step (a) is again measured to evaluate the actual power drift.

8.1 DASY4 SAR MEASURMENT PROCEDURE

Step 1: Power Reference Measurement

The Power Reference Measurement and Power Drift Measurements are for monitoring the power drift of the device under test in the batch process. The Minimum distance of probe sensors to surface determines the closest measurement point to phantom surface. The minimum distance of probe sensors to surface is 2.1 mm. This distance cannot be smaller than the Distance of sensor calibration points to probe tip as defined in the probe properties (for example, 1.2 mm for an EX3DV3 probe type).

Step 2: Area Scan

The Area Scan is used as a fast scan in two dimensions to find the area of high field values, before doing a fine measurement around the hot spot. The sophisticated interpolation routines implemented in DASY4 software can find the maximum locations even in relatively coarse grids. When an Area Scan has measured all reachable points, it computes the field maximal found in the scanned area, within a range of the global maximum. The range (in dB) is specified in the standards for compliance testing. For example, a 2 dB range is required in IEEE Standard 1528, EN 50361 and IEC 62209 standards, whereby 3 dB is a requirement when compliance is assessed in accordance with the ARIB standard (Japan). If only one Zoom Scan follows the Area Scan, then only the absolute maximum will be taken as reference. For cases where multiple maximums are detected, the number of Zoom Scans has to be increased accordingly.

Step 3: Zoom Scan

Zoom Scans are used to assess the peak spatial SAR values within a cubic averaging volume containing 1 g and 10 g of simulated tissue. The Zoom Scan measures $5 \times 5 \times 7$ points within a cube whose base faces are centered on the maxima found in a preceding area scan job within the same procedure. When the measurement is done, the Zoom Scan evaluates the averaged SAR for 1 g and 10 g and displays these values next to the job's label.

For 5 GHz band – Same as above except the Zoom Scan measures 7 x 7 x 9 points.

Step 4: Power drift measurement

The Power Drift Measurement measures the field at the same location as the most recent power reference measurement within the same procedure, and with the same settings. The Power Drift Measurement gives the field difference in dB from the reading conducted within the last Power Reference Measurement. This allows a user to monitor the power drift of the device under test within a batch process. The measurement procedure is the same as Step 1.

Step 5: Z-Scan

The Z Scan measures points along a vertical straight line. The line runs along the Z-axis of a onedimensional grid. In order to get a reasonable extrapolation, the extrapolated distance should not be larger than the step size in Z-direction.

9 CONDUCTED OUTPUT POWER

Frequency	Conducted	Conducted		
	Output Power	Output Power		
(MHz)	(dBm)	(mW)		
462.629	29.9	977.24		

10 SAR MEASURMENT RESULTS

10.1 BODY-WORN POSITION



GMRS (Duty cycle: 100%; Crest factor: 1)

	Measured SAR	Power Drift	Extrapolated ¹⁾ SAR	SAR Values 1g (mW/g)
t (MHz)	1g (mW/g)	(dB)		@ 50% Duty Factor
462.625	1.85	-0.03	1.9	0.9

Notes:

- The exact method of extrapolation is Measured SAR x 10^(-drift/10). The SAR reported at the end of the measurement process by the DASY4 system can be scaled up by the Power drift to determine the SAR at the beginning of the measurement process.
- 2) The transmission band of the EUT is less than 10 MHz, therefore testing at the high and low frequency channels is optional.
- 3) The battery was fully charged in accordance with manufacture's instructions prior to SAR measurements.
- 4) Please see attachments for the detailed measurement data and plots showing the maximum SAR location of the EUT.

10.2 FACE-HELD POSITION



Notes:

 The exact method of extrapolation is Measured SAR x 10^(-drift/10). The SAR reported at the end of the measurement process by the DASY4 system can be scaled up by the Power drift to determine the SAR at the beginning of the measurement process.

2) The transmission band of the EUT is less than 10 MHz, therefore testing at the high and low frequency channels is optional.

3) The battery was fully charged in accordance with manufacture's instructions prior to SAR measurements.

4) Please see attachments for the detailed measurement data and plots showing the maximum SAR location of the EUT.

11 MEASURMENT UNCERTAINTY

11.1 MEASURMENT UNCERTAINTY FOR 300 MHz - 3000 MHz

	Tel (+0/)	Probe	Dist		C: (40 m)	Std. Unc.(±%)	
Uncertainty component	10I. (±%)	Dist.	DIV.	CI (1g)	CI (10g)	Ui (1g)	Ui(10g)
Measurement System							
Probe Calibration	4.80	Ν	1	1	1	4.80	4.80
Axial Isotropy	4.70	R	1.732	0.707	0.707	1.92	1.92
Hemispherical Isotropy	9.60	R	1.732	0.707	0.707	3.92	3.92
Boundary Effects	1.00	R	1.732	1	1	0.58	0.58
Linearity	4.70	R	1.732	1	1	2.71	2.71
System Detection Limits	1.00	R	1.732	1	1	0.58	0.58
Readout Electronics	1.00	Ν	1	1	1	1.00	1.00
Response Time	0.80	R	1.732	1	1	0.46	0.46
Integration Time	2.60	R	1.732	1	1	1.50	1.50
RF Ambient Conditions - Noise	1.59	R	1.732	1	1	0.92	0.92
RF Ambient Conditions - Reflections	0.00	R	1.732	1	1	0.00	0.00
Probe Positioner Mechnical Tolerance	0.40	R	1.732	1	1	0.23	0.23
Probe Positioning With Respect to Phantom Shell	2.90	R	1.732	1	1	1.67	1.67
Extrapolation, interpolation, and integration algorithms for							
max. SAR evaluation	3.90	R	1.732	1	1	2.25	2.25
Test sample Related							
Test Sample Positioning	1.10	Ν	1	1	1	1.10	1.10
Device Holder Uncertainty	3.60	Ν	1	1	1	3.60	3.60
Power and SAR Drift Measurement	5.00	R	1.732	1	1	2.89	2.89
Phantom and Tissue Parameters							
Phantom Uncertainty	4.00	R	1.732	1	1	2.31	2.31
Liquid Conductivity - Target	5.00	R	1.732	0.64	0.43	1.85	1.24
Liquid Conductivity - Meas.	8.60	Ν	1	0.64	0.43	5.50	3.70
Liquid Permittivity - Target	5.00	R	1.732	0.6	0.49	1.73	1.41
Liquid Permittivity - Meas.	3.30	Ν	1	0.6	0.49	1.98	1.62
Combined Standard Uncertainty	RSS				11.44	10.49	
Expanded Uncertainty (95% Confidence Interval)			K=2			22.87	20.98
Notesfor table							
1. Tol tolerance in influence quaitity							
2. N - Nomal							
3. R - Rectangular							
4. Div Divisor used to obtain standard uncertainty							

5. Ci - is te sensitivity coefficient

12 EQUIPMENT LIST AND CALIBRATION

Name of Equipment	Manufacturor	Type/Medal	Sorial Number	Cal. Due date		
Name of Equipment			Senai Number	MM	DD	Year
Robot - Six Axes	Stäubli	RX90BL	N/A		-	N/A
Robot Remote Control	Stäubli	CS7MB	3403-91535			N/A
DASY4 Measurement Server	SPEAG	SEUMS001BA	1041			N/A
Probe Alignment Unit	SPEAG	LB (V2)	261			N/A
SAM Phantom (SAM1)	SPEAG	TP-1185	QD000P40CA			N/A
SAM Phantom (SAM2)	SPEAG	TP-1015	N/A			N/A
Electronic Probe kit	HP	85070C	N/A			N/A
S-Parameter Network Analyzer	Agilent	8753ES-6	US39173569	2	14	2008
E-Field Probe	SPEAG	EX3DV4	3552	5	30	2007
Data Acquisition Electronics	SPEAG	DAE3 V1	427	11	16	2007
System Validation Dipole	SPEAG	D450V2	1003	5	22	2006
Power Meter	Agilent	E4416A	GB41291160	12	2	2007
Power Meter	HP	438A	3513U04320	9	4	2007
Amplifier	Mini-Circuits	ZVE-8G	360			N/A
Amplifier	Mini-Circuits	ZHL-42W	D072701-5			N/A
Radio Communication Tester	R &S	CMU 200	104096	11	16	2007
Signal Generator	HP	83732B	US34490599	10	5	2008
Simulating Liquid	CCS	H450	N/A	Withi	n 24 h	rs of first test
Simulating Liquid	CCS	M450	N/A	Withi	า 24 h	rs of first test

13 EUT PHOTOS



EUT with Headset (microphone & headphone)

Front view



EUT with Belt-clip & Battery



14 ATTACHMENTS

No.	Contents	No. Of Pages
1	System Performance Check Plots	2
2	SAR Test Plots	4
3	Certificate of E-Field Probe - EXDV4SN3552	9
4	Certificate of System Validation Dipole - D450V2 SN:1003	9

END OF REPORT