

CSI-DSP95-252-L7, CSI-DSP95-252-U7C, CSI-DSP95I-252-L7, CSI-DSP95I-252-U7C, CSI-DSP95-255-L7, CSI-DSP95-255-U7C, CSI-DSP95I-255-L7, and CSI-DSP95I-255-U7C,

# **Table of Contents**

Product Projectration Information	1
Product Registration information	4
Document Purpose / Intended Osers	4
Application	4
Radio and Television Interference	4
Safety Guidelines	4
Important Safety Information	
Terms used in this manual	5
Ternis used in this manual	
Product introduction	ວ
Band Plan and Filter Naming Convention	6
LTE Filter File Naming Convention	6
Functional Overview	7
LED Indicator	7
Local Communication Interface Ports	8
	0
	0
Ethernet	8
Monitoring & Alarms	9
System Set-Up Considerations	9
Selection of external attenuators to be used in line with the Antenna Port(s)	9
1.1 Port Configuration	9
Donor Port	10
	10
Server Port	TU
Attenuator Selection Guidelines	10
Mounting the Digital Repeater	.11
Wall Mounting	.11
19" Relay Rack Mounting	.11
19" Four Post Back Mounting	11
Important Installation Notices	12
important instanation notes	
Installation rips	12
Donor Antenna	12
Indoor Antennas	12
Optional Accessories	12
Circuit Operational Description	13
Functional Block Diagram	13
Machanical Diock Diagram	1 /
	14
Environmental Requirements	14
AC Power Specifications	14
Operating Power Parameters	15
Mechanical Drawing	16
System Status	17
Web hased GUI Session	17
l coal Notwork	10
	10
RF Configuration	19
Program a Filter	19
Remote Network	20
SNMP Configuration	20
System Health	21
Install & Unload	21
Pahaat	22
	22
Alarm Configuration	22
Log Configuration	22
Change Password	23
Text Menu Interface (Local Access)	23
Terminal Emulation Program	24
Terminal Emulation Setup	25
	20
	20
Teiner Session (Remote Access)	28
Telnet Session Login	29
Modem Interface (Remote Access with login)	30
Additional Tips	31
Suggested spectrum analyzer setting	33
RF Notes	33
Industry Certifications/Registration Numbers:	31
Index y continentions/registration numbers	25
	35

#### **Product Registration Information**

The serial number may be found on the label on the bottom panel near the power connectors. Note this number below. Retain this manual, along with proof of purchase, to serve as a permanent record of your purchase.

MODEL NUMBER	SERIAL NUMBER	PURCHASE DATE
POINT OF SALE COM	PANY	

DISCLAIMER: All information and statements contained herein are accurate to the best of the knowledge of Cellular Specialties, Inc. (CSI), but Cellular Specialties makes no warranty with respect thereto, including without limitation any results that may be obtained from the products described herein or the infringement by such products of any proprietary rights of any persons. Use or application of such information or statements is at the users sole risk, without any liability on the part of Cellular Specialties, Inc. Nothing herein shall be construed as licence or recommendation for use, which infringes upon any proprietary rights of any person. Product material and specifications are subject to change without notice. Cellular Specialties' standard terms of sale and the specific terms of any particular sale apply.

#### **Document Purpose / Intended Users**

The purpose of this document is to provide a step-by-step procedure to help the experienced technician/engineer install and commission an in-building wireless enhancement repeater system using CSI's Digital Repeater. Following the procedures outlined will minimize risks associated with modifying a live system and prevent service interruptions. This document assumes the technician/ engineer understands the basic principles and functionality involved with Repeater and in-building systems. It is geared to the practical concerns of the installer.

#### Application

This guide should be applied whenever a need exists to add Digital Repeater capability to an existing system or when this capability is being included with a new installation.

#### Radio and Television Interference

NOTE: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense. In order to maintain compliance with FCC regulations shielded cables must be used with this equipment. Operation with non-approved equipment or unshieled cabled is likely to result in interference to radio & television reception. Changes and Modifications not expressly approved by Cellular Specialties can void your authority to operate this equipment under Federal Communications Commissions rules.

#### **Safety Guidelines**

The general safety information in this guideline applies to both operating and service personnel. Specific warnings and cautions will be found in other parts of this manual where they apply, but may not appear in this summary. Failure to comply with these precautions or specific warnings elsewhere in the manual violates safety standards of design, manufacture, and intended use of equipment. Cellular Specialties, Inc. assumes no liability for the customer's failure to comply with these requirements:

#### Grounding

This Digital Repeater system is designed to operate from 100-240 VAC and should always be operated with the ground wire properly connected. Do not remove or otherwise alter the grounding lug on the power cord.

#### Explosive Atmospheres

To avoid explosion or fire, do not operate this product in the presence of flammable gases or fumes.

#### Lightning Danger

Do not install or make adjustments to this unit during an electrical storm. Use of a suitable lightning arrester, such as CSI's model number CSI-CAP, is very strongly recommended.

#### No User Serviceable Parts Inside

HAZARDOUS VOLTAGES ARE PRESENT WHEN THE COVER IS REMOVED. Opening the chassis will void your warranty. If you suspect a malfunction with this product, call your dealer or the Cellular Specialties Support Line at: (603) 626-6677, Toll Free (USA) 1-877-844-4274.

#### **Important Safety Information**

Antennas used for the purpose of radiating signals indoors are limited to a *maximum* gain of 3 dBi. The outdoor antenna used for the purpose of communicating to the wireless infrastructure is limited to 14dBi gain, or any combination of gain and loss that equates to 14dB at input. Each antenna must be positioned to observe minimum separation requirements from all users and bystanders. The following guidelines should be used when considering separation distances.

*INDOOR* antennas must be placed such that, under normal conditions, personnel cannot come within 122 cm (~4.0 ft.) from any inside antenna. Adhering to this minimum separation will ensure that the employee or bystander cannot exceed RF exposures beyond the maximum permissible limit as defined by section 1.1310 i.e. limits for General Population/Uncontrolled Exposure.

*OUTDOOR* antenna must be positioned such that, under normal conditions, personnel cannot approach closer than 183 cm. (~6 ft.). A directional antenna having a maximum gain of 14 dBi is used, precautions should be taken to prevent personnel from routinely passing through the main radiation beam at a distance closer than specified.

#### Terms used in this manual

 AGC= Automatic Gain Control
 ERP= Effective Radiated Power

 APC= Automatic Power Control
 FPGA= Field Programmable Gate Array

 AUI= Attachment Unit Interface
 LED= Light Emitting Diode

 CPU= Central Processing Unit
 OIP3= Third-Order Intercept Point

 CSI= Cellular Specialties, Inc.
 RF= Radio Frequency

 DAS= Distributed Antenna System
 SBC= Single board Computer

 DHCP= Dynamic Host Configuration
 SNMP= Simple Network Management Protocol

 TMI= Text Menu Interface
 TMI= Text Menu Interface

DSP= Digital Signal Processing EEPROM= Electrically Erasable Programmable readonly Memory SNMP= Simple Network Management Proto TMI= Text Menu Interface USB = Universal Serial Bus UHCI = Universal Host Controller Interface

#### **Product Introduction**

Cellular Specialties, Inc. (CSI) developed the DSP85-252, DSP85-255, DSP85I-252 and DSP85I-255 digital repeaters for use within enclosed structures where sufficient signal from local cell sites to operate cell phones is unavailable. Adequate signal must be available outside the structure as a prerequisite to achieving in-building coverage. The Digital Repeater is connected to an external antenna, usually on the roof, and to one or more internal antennas placed strategically throughout the area where wireless service is desired.

The external antenna typically is directional, such as a "yagi". Internal antennas are typically omnidirectional, although various other types may be used depending on the coverage application. The **CSI DSP Repeater** amplifies both the "uplink" (phone to tower) & "downlink" (tower to phone) signals thus facilitating communications to and from the intended wireless infrastructure.

With a maximum total of **+85**dB nominal gain on both the up and down links, gain can be adjusted over a range from +53.5dB to +85dB in 0.5dB steps. Control of the repeater is achieved utilizing a computer connected to com port 1 or 2 or via a Crossover Ethernet cable connected to the Ethernet port.

A specific filtering process modifies each amplification chain. This process digitally converts the assigned spectrum and then applies digital signal processing (DSP) techniques. DSP is used to create passbands that selects the RF energy passing through either the uplink or downlink paths. After the digital processing is complete, the information is converted back to an analog signal that is applied to the remaining stages of amplification. The resulting signals emitted by the repeater are specific to the network service providers' requirements. If these requirements change, only the DSP configuration parameters need change in order to adapt. Configuration parameters are created at the factory and supplied as files that may be downloaded to the repeater. The filter set configurations stored in memory determine the unit's adaptability to various field applications. The following pages describe the Cellular and PCS band plans as well as the convention CSI uses to identify and store the files that make up the filter set. All CSI repeaters are shipped with an active filter set that is programmed according to the ordering parties' specifications. In most cases, the installer will not be required to program a filter.

#### **Band Plan and Filter Naming Convention**



### LTE Filter File Naming Convention

	-											
POSITION:	1	2	3	4	5	6	7	8	9	10	11	12
Definition:	Band	Mod Type	Block 1	Sub Block 1	Block 2	Sub Block 2	Block 3	Sub Block 3	Block 4	Sub Block 4	Separator	¥ariant
					Note: These p	osition columns	are added	as additional blocks are nee	eded.		•	
	I = LTE	g = GSM	A - C	0 = Full	A - C	0 = Full	A - C	0 = Full	A - C	0 = Full	-	0= Standard
		c = CDMA		1-7 = Sub		1-7 = Sub		1-7 = Sub		1-7 = Sub		Guard Band
		w = WCDMA										
		i = iDEN										
		<b>p</b> = P25										
		e = E-UTRA (L	Jpper)					LTE Lower Blocks	Uplink(MHz)	Downlink(MHz)		
Notes:		I = E-UTRA (Lo	ower)					AO	698-704	728-734		
Modulation ty	pe determines t	he guard band	at the edg	es of each pas:	sband. Modula	tion type field v	/ill also be	BO	704-710	734-740		
used to indic	ate a carrier wh	io has unique s	ub-block c	lesignation.				CO	710-716	740-746		
								LTE Lower Sub Blocks	Uplink(MHz)	Downlink(MHz)		
Up to four su	b-blocks may d	efined, resulting	g in a maxi	num filename le	ngth of 12 cha	racters.		A1	698.5-703.5	728.5-733.5		
								B1	704.5-709.5	734.5-739.5		
Example:	IIA1B1-0	(LTE band, E-	UTRA Mod	Type, Lower A	1, B1, with Sta	andard guard ba	and.)	C1	710.5-715.5	740.5-745.5		
	leC0-0	(LTE band, E-	UTRA Mod	Type, Upper C	with Standard	guard band.)		LTE Upper Blocks	Uplink(MHz)	Downlink(MHz)		
	IIC1-0	(LTE band, E-	UTRA Mod	Type, Lower C	1 with Standar	d guard band.)		CO	698-704	746-757		
								LTE Upper Sub Blocks	Uplink(MHz)	Downlink(MHz)		
								C1	776.5-786.5	746.5-756.5		

Note: All Variant/Guard Band designators other than 0 are user defined custom filters.

#### **Functional Overview**

The CSI-repeater incorporates the following features for convenient operation, access, protection, and control.

- Network Configuration and Control using either a webpage style GUI through any standard browser or a menu driven user interface using the serial port. (Note: GUI does not require Internet access.)
- User Gain Control (affects all passbands)
- Automatic Gain Control
- Automatic Power Control
- Oscillation Protection
- Over Drive Protection (P.A. limiting)
- Under/Over Voltage Protection
- Fault Protection
- Alarm Notification Local/Remote
- Upgrade Support Local/Remote
- External Interfaces USB/Ethernet/Serial
- Re-loadable filters Local/Remote
- Web-based monitoring and control Local/Remote
- Persistent Status and Error information

#### **LED Indicator**

Automatic safety precautions are built into the amplifier system. In the case of a catastrophic system event, a shutdown circuit is incorporated that will disable all emissions should the uplink input or downlink input be overdriven or should an oscillation or output overpower event occur. The amplifier will periodically attempt to recover from the detected condition automatically. Warning light indicators are as follows:

When a boot up is complete and no alarm conditions exist, the LED indicator will be illuminated green. Should a fault condition develop the LED will illuminate red and the user may check the status page of the GUI for the nature of the fault.\*

\*Note: During Power up, the repeater will require a approximately three minutes for the internal computer to boot up. During this time the LED on the front panel may light and go out several times.

Do not unplug the unit while it is in the boot up process!

### **Local Communication Interface Ports**

To allow monitoring and control, the repeater is equipped with four ports that provide external communication access (1 Ethernet CAT-5, 2 DB-9 serial, and 1 USB). The Ethernet, CAT-5 port is provided as a primary communications port to the PC. One serial interface provides communications to local PC and the second to an external modem when provided. The USB interface provides a means to download files from a memory device and may also be used by an external modem. The DB-9 pin assignments conform to the standard Electronic Industries Association (EIA232) specification. A diagram of the pin descriptions is provided on this page for reference.

Connecting a null modem cable to one of the COM ports and using a terminal emulation program with a PC will allow communication to the control processor's Text Menu Interface (TMI). See command line interface section for further detail.



#### **EIA232 Pin Specifications**

The diagram above is for reference only, it's intended to provide a quick source for pinout information in the event it should be necessary to adapt your serial cable because of an unusual connector configuration. In the vast majority of cases this information will not be needed.

#### **USB** Interface

The Universal Serial Bus (USB) interface conforms to Intel's Universal Host Controller Interface (UHCI) version 1.1 dated March 21, 1996. This interface will support data transfer rates up to 12 Mbps and can be used for software updates and filter file uploads.

#### Ethernet

The Ethernet AUI conforms to IEEE 802.3 and is capable of supporting 10/100 Mbps communications speeds. This port is used to provide access to the GUI.

#### **Monitoring & Alarms**

There are no physical connections provided to specifically communicate system or alarm status. This information is embedded in the information accessible via the communication ports described earlier.

#### System Set-Up Considerations

All cables should be checked for shorts and opens. Also verify that there are no cables with loose or poor connections. RF leakage could cause oscillation to occur under some conditions.

The rooftop antenna (Donor Antenna), if directional, should be checked for proper alignment along the calculated compass heading. Typically, the directional antenna would be aimed at the same site that your handset uses, but it may not always be so. <u>It is critical the installer contact the service provider for information on, and approval of, the site he or she has selected before the system is turned on.</u>

If cables and alignment are acceptable and a problem persists, it may be necessary to use a spectrum analyzer to examine the signal environment in which the unit is operating. The existence of strong adjacent channel signals within the frequency band(s) can cause the AGC to reduce the amplifier's gain or cause alarms. In some cases additional filtering or attenuation might be required to reject these unwanted signals. In some instances, the donor antenna can be reoriented horizontally, to place the interference source in an antenna pattern "null". There also may be some cases where the interference from outside signals is so great that they cannot be filtered or otherwise reduced or eliminated without expensive and possibly prohibitive measures. In these cases it may not be practical to use the CSI repeater for providing coverage to these sites.

#### Selection of external attenuators to be used in line with the Antenna Port(s)



#### 1:1 Port Configuration

Input: One dual band duplex port, from the dual band donor.

<u>Output:</u> One dual band duplex port, to the DAS.

#### **Donor Port**

If a CSI repeater is installed in an area with very strong desired and/or undesired signals, it is important to ensure that the overall signal levels are optimized to be within the best operating range of the repeater. Additionally, de-sensing of a nearby base station site must be avoided. These goals can be accomplished by properly attenuating the antenna port(s) in the path of the donor antenna(s). In effect, one can imagine that the particular repeater deployment is electrically moved farther from the base station using attenuators that are equivalent to increasing the path loss from the donor antenna to the base station. The following potential outcomes result from the use of attenuators on the donor port(s) of the unit: Uplink output power, as reported by the repeater, is reduced by the value of the attenuation, protecting nearby base stations. Downlink signal to noise ratio is high at the point of the attenuator, resulting in slight but negligible reduction in downlink performance. Other performance is essentially unchanged.

#### **Server Port**

Server port attenuation may also be necessary, particularly where a powered DAS is present. The selection guidelines below apply to both server and donor ports. In order to properly measure uplink signal strength, a signal generator should be used. If a signal generator is not available, placing a test call while under the server antenna with the least path loss to the repeater should provide reasonable data. The following potential outcomes result from the use of attenuators on the server port(s) of the CSI repeater: Downlink output power, as reported by the unit, is reduced by the value of the attenuation. Uplink incoming power from the DAS is reduced, along with potentially strong and/or harmful out-of-band signals (including noise) that are generated by the DAS.

#### **Attenuator Selection Guidelines**

Accurate attenuator values need to be chosen to ensure that the maximum total power (higher of Composite or In-Band Input) applied to the donor and server port(s) does not exceed the following thresholds:

Input Signal	Max Gain	Input Signal	Max Gain
≤-45 dBm	85 dB	-32.2 dBm	69 dB
-44.3 dBm	84 dB	-31.4 dBm	68 dB
-43.6 dBm	83 dB	-30.6 dBm	67 dB
-42.9 dBm	82 dB	-29.8 dBm	66 dB
-42.2 dBm	81 dB	-29 dBm	65 dB
-41.5 dBm	80 dB	-28.2 dBm	64 dB
-40.6 dBm	79 dB	-27.4 dBm	63 dB
-39.7 dBm	78 dB	-26.6 dBm	62 dB
-38.8 dBm	77 dB	-25.8 dBm	61 dB
-37.9 dBm	76 dB	-25 dBm	60 dB
-37 dBm	75 dB	-24.4 dBm	59 dB*
-36.2 dBm	74 dB	-23.8 dBm	58 dB*
-35.4 dBm	73 dB	-23.2 dBm	57 dB*
-34.6 dBm	72 dB	-22.6 dBm	56 dB*
-33.8 dBm	71 dB	-22 dBm	<u>≤</u> 55 dB*
-33 dBm	70 dB		
المريبة الملقلة بمعالماتهم والمعموم مستقرم	deep to material for floor to	attern atrenat	

\*We recommend padding this level due to potential for fluctuating signal.

-25 dBm is the maximum input signal level that should be applied to the repeater, even if the gain is lower than 55 dB.

Input signals exceeding these thresholds will result in composite input attenuation, called "ADC Protect" (Analog to Digital Converter Protection). Output power is reduced whenever the above thresholds are exceeded by reducing the gain by 1dB for each 1 dB that the threshold is exceeded. ADC Protect should not be confused with AGC (Automatic Gain Control), which reduces gain to prevent In-Band (measured) output power from exceeding the specified maximum output level. To determine the total power applied to the donor and server ports, please reference the "Composite Input" values as reported in the Web ("System Status") or Menu ("Link Status") interfaces (depicted and explained later in this manual).

#### Large delta's between in-band and composite input signals:

Care should be taken to isolate the best donor site to ensure the least possible delta between in-band and composite downlink signals. If the (downlink) composite input exceeds the in-band input by more than 3 dB for the LTE band the maximum output power will be reduced.

#### Mounting the Digital Repeater

The following diagrams illustrate the methods for mounting the repeater in a typical wall or rack installation. Brackets provided serve for both options.

#### Wall Mounting

Step 1: Install the wall mount brackets as shown in the drawing to the right.

Step 2: Mark the location of the wall anchoring holes and drill. The wall anchoring system you use for the repeater will need to be able to support at least 46 lbs/ 21kg. Install wall anchors and hang repeater as shown.



#### 19" Relay Rack Mounting

Mount the repeater as shown and secure front panel with screws. Note: the CSI digital repeaters must be supported in the 19" Relay Rack system with a shelf. **Do not rely on the front panel mount exclusively to support all the weight of the unit.** 

#### **19" Four Post Rack Mounting**

Install slid brackets on repeater as shown in the tapped holes provided. Slid repeater into the receiving brackets and secure with screws. The repeater must be supported in the rack system with slide rail. **Do not rely on the front panel mount exclusively to support all the weight of the unit.** 

#### **Optional Accessories**

A complete line of accessories is available from Cellular Specialties, Inc. Check with your CSI distributor for any additional items needed. Below are just a few examples suitable for most in-building needs.

#### •Outside Donor Antenna •UPS Panel - model number: CSI-AP/698/2.2K/7-10 Inside Omnidirectional Antenna Quad-band - model number: CSI-AO/700/2.7K/3 Directional Couplers 6dB - model number: CSI-DC6/700-2.7K/N 10dB - model number: CSI-DC10/700-2.7K/N 15dB - model number: CSI-DC15/700-2.7K/N 20dB - model number: CSI-DC20/700-2.7K/N 30dB - model number: CSI-DC30/700-2.7K/N Power Dividers 2:1 - model number: CSI-SPD2/700-2.7K/N 3.1 - model number: CSI-SPD3/700-2.7K/N 4:1 - model number: CSI-SPD4/700-2.7K/N •Grounding Kit - model number: CSI-GKIT •Lightning Arrestor - model number: CSI-CAP

Battery backup, 2 hr Single band 1 hour dual band - model number: CS48-985-600

Battery backup, 4 hr Single band 2 hour dual band - model number: CS48-985-601

#### •Cross Band Couplers

Quad band Rack Mount: CSI-CM250-7/C/AW/P (700 LTE, Cell, AWS and PCS) Quad band Wall Mount: CSI-CBC/696-2170/N (700 LTE, Cell, AWS and PCS) Tri band Rack Mount: CSI-CM250-U7C/C/P (700 Upper C LTE, Cell and PCS) Tri band Wall Mount: CSI-CBC21/740-1990/N (700 Upper C LTE, Cell and PCS) Tri band Rack Mount: CSI-CM250-L7AB/C/P (700 Lower A/B LTE, Cell and PCS) Tri band Wall Mount: CSI-CBC21/696-1990/N (700 Lower A/B LTE, Cell and PCS)

#### Important Installation Notes

Inadequate isolation between the outside and inside antennas may cause regenerative feedback in the system. This feedback can cause the amplifier to emit a continuous signal at maximum amplitude and, in some cases, interfere with normal operation of the donor site. Careful consideration of the layout and placement of the system is imperative to minimize this possibility and to minimize the amount of signal leaking from the building. See installation tips below for general guidelines.

The installer should refer to the Safety Guidelines section on page 4 and the Important Safety Information section on page 5 for proper antenna selection and installation. To avoid serious injury or death and damage to the repeater, do not install donor or server antennas near overhead power lines or high power components. Allow enough distance so that if antennas should fall they will not come in contact with those components.

Close proximity to the donor or server antennas with the repeater in operation may expose the user or installer to RF fields that exceed FCC limits for human exposure.

WARNING! AMPLIFIER OR HANDSET DAMAGE MAY OCCUR IF A HANDSET IS CONNECTED DIRECTLY TO THE REPEATER OR THE COAX THAT LEADS TO THE REPEATER.

#### Installation Tips **Donor Antenna**

- Accurately determine the azimuth to the donor cell site . Obtain the donor site information and approval from the 1 service provider/carrier. Ensure that the radiation path to the donor cell site is as unobstructed as possible.
- 2
- Mount the donor antenna at or toward the edge of the roof, in the direction of the donor site. Try to avoid having the RF 3 signal from the donor pass above the location(s) of the service antennas. Normally the service antennas will be behind and below the donor antenna if viewed from above. This approach will help avoid interference and feed back both, to and from the service antennas.
- 4. Normally mounting the donor antenna higher will allow a less obstructed path to the donor site. However, in high traffic metro areas avoid mounting the donor antenna any higher than necessary as the quality of the donor signal may start to become less stable and it is more likely to encounter adjacent channel interference.
- 5. When possible shield the donor antenna's back side by locating it so that any HVAC units and/or penthouse structures are behind the antenna relative to the donor cell site location.

#### Indoor Antennas

- Use omnidirectional antennas (see optional accessories) indoors, and locate them centrally with respect to the intended coverage area to minimize signal leakage to the outside. Use directional antennas indoors only in special cases when higher gain and directionality would be helpful and RF exposure limits will not be exceeded. To avoid repeater uplink overload and gain limiting mount the indoor antennas away from areas where mobile subscribers frequently use their phones such as desks or dispatch areas. 1
- 2

#### Indoor Antennas continued

3. To determine the quantity and locations of indoor antennas, use an appropriate phone's signal meter to determine areas of weak signals. These are the approximate areas where indoor antennas may be needed. Also be aware the signal from an indoor antenna, in most cases, can be expected to penetrate about two standard office sheetrock type walls to reach users. After two walls or if the walls are made of other materials, it may be necessary to split the available signal and add more antennas.

#### **Circuit Operational Description**

The repeater uses a single down-conversion/up-conversion scheme. There are multiple RF amplifier stages prior to each downconverting mixer. The down-converting mixers are followed by a single IF amplifier. A Digital Signal Processor block then processes the resultant digitized IF signal that was previously generated by an Analog-to-Digital Converter. The processed (filtered) digital signal is fed to a Digital-to-Analog converter and then up-converted to RF. A driver amplifier and a final power amplifier make up the final gain stages before application to the diplexer. The maximum total system gain (diplexer input to diplexer output) is nominally 85 dB for either the downlink or the uplink paths with both links having independent manual and automatic gain controls (AGC).

AGC reacts to analog power detection on both the input and output of the uplink and downlink RF chains. A control algorithm continuously monitors these detected values and dynamically adjusts various gain stages such that the net system gain value, entered manually, is maintained without either exceeding FCC parameters or overdriving the A/D converters.

Upon detection of oscillation the unit will shut down. After a "short duration" of 30 seconds the unit will attempt normal operation. If no continued oscillation is occurring the unit will stay on. However, if oscillation is still occurring, the repeater will remain shut down and retry 1 additional time in the "short duration" loop. If after these two "short duration" retries, the oscillation is still detected, it will turn off again and wait a "long duration" period of 10 minutes. If after 6 "long duration" retries, oscillation continues, the unit will go into a "disable duration" of 24 hours. It will continue in the "disable duration" loop and retry every 24 hours.

LED on the front panel display provide immediate visual indications of the unit's primary power and major or minor alarm status. The repeater features automatic shutdown protection, as a safety measure, should excessive drive be applied to the input or an oscillation condition occur. When in a protected mode, a control algorithm determines the appropriate method of recovery to a normal, previously defined state, or maintains the protection until manually reset.



#### **Functional Block Diagram**

## **Mechanical Specifications**

Parameter	Specification	Notes
Repeater Size		
Height	5.25 in.	3RU
Width	19.00 in.	
Depth	20.28 in.	
Weight	31.0 lbs / 14.1 kg	
Thermal Management	Fan Cooled	
Surface Coating	Powder Coat	
Color	Satin Black	

## AC Power Specifications

Parameter	Specification	Notes
AC Voltage	100 - 240 VAC	External Power Supply
AC Current	2.0 Amps 1.0 Amps	@ 120 VAC @ 230 VAC
AC Power Frequency	47 - 63 Hz	
Heat Output	700 BTU/Hr	

## **Environmental Requirements**

Parameter	Specification	Notes
Temperature Range	0° to 50° C (32° to 122° F)	
Relative Humidity	5% to 95%	Non-condensing

Parameter	Specification	Notes
<i>Maximum RF input Power without damage</i>	+10 dBm	
Linear Gain	85 dB	Factory Calibrated Gain
Pass Band Ripple	+/-1.5 dB	
Automatic Gain Control	30dBmax range	In 0.5 dB steps
Manual Gain Control	53.5-85 dB	In 0.5 dB steps
<i>Linear Output Power</i> (CSI-DSP85-252 Down Link)	+33 dBm max LTE +32 dBm	
(CSI-DSP85-252 Up Link )	+ 30dBm max LTE +29 dBm	
Linear Output Power (CSI-DSP85-255 Down Link)	+ 37 dBm max LTE +36 dBm	
(CSI-DSP85-255 Up Link )	30dBm max LTE +29 dBm	
OIP3		
(CSI-DSP85-252 Down Link) (CSI-DSP85-252 Up Link)	+ 51 dBm + 41 dBm	Measured with 2 CW tones at 14 dBm/tone
(CSI-DSP85-255 Down Link) (CSI-DSP85-255 Up Link)	+ 57 dBm + 41 dBm	Measured with 2 CW tones at 14 dBm/tone
Noise Figure (Avg)	6.0 dB	At Maximum Gain
Input VSWR (Typ)	<2.0:1	
Propagation Delay	<2.5 usec	
RMS Vector Error (EVM)	3% max	TDMA,EDGE,W-CDMA,CDMA2000
CDMA RHO	0.98 min	CDMA2000, 1x-EVD0
Connectors	N-Female	
Spurious Emissions & Applicable Documents FCC Industry Canada	-13 dBm max -13 dBm max	Per FCC part 2, 22, 24

## **Operating Power Parameters**

## **Mechanical Drawing**



#### Web based GUI Session

Primary access to the repeater is gained using a LAN connection and a web browser program such as Firefox by Mozilla, or Internet Explorer from Microsoft. The repeater ships with the default IP address of 192.168.1.100, but it can be changed later if required.

If connecting directly to the repeater from a laptop or PC with a crossover CAT-5E cable or over a LAN the user types the IP address of the repeater into the browser address line to connect. (Note: Most users will need to update the TCP/IP settings on their computer to enable connection to a host that has a static IP. Select "Use the following IP Address" and enter the IP Address as follows: 192.168.1.x, where "x" = any number from 2 to 254 inclusive other than 100. The subnet mask is 255.255.255.0. Questions pertaining to these settings should be referred to the user's IT department or you may refer to the Additional Tips section at the end of this manual.) When connection is made the user will be prompted for a user name and password. For the purpose of the GUI session, the default user name is **webuser** and the password is **csi1234**. This can also be changed as required. Internet access is not required to use the GUI. (Note: If you are connecting using a laptop, verify that your Ethernet port is powered. Some laptops will not allow Ethernet connection when on battery power. If this is the case with the laptop you are using you will need to plug it in or update the power settings.)



#### System Status

When login is complete the user is brought to the system status page. The links shown in the navagation box on the left are activated by clicking on them.

Edit View Histor	/ <u>B</u> ookmarks <u>T</u> ools <u>H</u> elp 🚺	<b>y</b> -			
- C ×	👔 🕜 🚺 http://192.168.1	.100/index.cgi		ය · 🖸	Google
lost Visited 🌮 Getting	Started 🦲 Latest Headlines 📄	Customize Lin	ks 📄 Windov	vs Marketplace	
ignupShield 💰 Fill-in	🔚 Save Form 🐇 1-Click Sign-in				
System Status	System Status				
Local Network	Timestamp	2010-02-20 -	09:48:00		
RF Configuration	System Uptime	10 days 0 hours	12 minutes		
Drostrom o Eitor	Software Version	2.6.0			
riogramica rinor	Serial Number	CMG90617-0	00000		
Remote Network	Model Number	DSP85-250-0	J7C		
SNMP Configuration	Item Number	CS10-443-410	0		
System Health	<sup>?</sup> Location	Unknown			
Install & Upload	Modem Status Information				
Reboot	Modem Not Connected				
Alarm Configuration	Band Type	LTE			
Email Configuration	Active Filter	teAlBI-0			
Log Configuration	Power	Down Link	Up Link		
Change Password	In-band Input <sup>2</sup> (dBm)	≤ -90.0	≤ -90.0		
Change Face from	Measured Output <sup>2</sup> (dBm)	≤ -5.0	≤ -5.0		
	Composite Input <sup>2</sup> (dBm)	≤ -63.0	≤ -63.0		
	Gain Control				
	AGC Mode	0:	n		
	AGC Control				
	AGC Attenuation (dB)	0.0	0.0		
	System Gain	85.0	85.0		
	RF Alarms				
	Over Range	OK	OK		
	Oscillation	OK	OK		
	Out of Band Overdrive	OK	OK		
	Low Signal	OK			

#### Local Network

If the user selects Local Network from the System Status page, the following screen is displayed and from here network configuration can be modified as required. The default is set to Static. Check with your IT department for explanation and approval of the DHCP and DHCP Server options you plan to use before you select them. \*NOTE: In units with software version 2.2.4 or prior, only letters, numbers and underscores are acceptable nomenclature. In units with software version 2.3.0 and up, Underscores are not acceptable; however, hyphens are acceptable.



After any changes are made press the refresh button to review the fields and ensure the change made is correct. Note: changing network settings will cause the current TCP/IP connection to fail because the change will take effect immediately. From here the user may return to the System Status screen or click on the other options.

#### **RF** Configuration

If the user would like to modify RF configuration click on the words RF Configuration in the navigation box and the screen below is displayed.

. C X A	http://192.168.1.100/rf.com		sh =	
	http://www.inden.inden.inden.inden.inden.inden.inden.inden.inden.inden.inden.inden.inden.inden.inden.inden.ind		W	
ost visited 🔄 Getong Started 👝 L	atest Headlines 🔄 Suggested sites			
Kr Configuration	1.2			
System Status	<b>RF</b> Configurat	ion		
Local Network	in comgan			
RF Configuration				
Program a Filter	Think AGC Attenuation	0.0.48		
Domoto Notwork	Downlink AGC Attenuation:	0.0 dB		
Remote Network	Downlink Measured Output <sup>2</sup>	7.7 dBm		
SNMP Configuration	Band Type:	LTE		
System Health	Uplink Gain	85.0 dB		
Install & Upload	Downlink Gain:	85.0 dB		
Rehoot		Neither link; leav	e unchanged	
	Set Gain For:	O Uplink only		
Alarm Configuration	100 000000	O Uplink and down	nlink	
Email Configuration	New Gain Setting.*	85.0	aB	
Log Configuration	Power Amplifier.	O Off		
Change Password				
Change Fassword	Change Settings			
	Countingle meanings			
	* Values will be rounded up to th	e nearest half		
	Gain values must be between 53.5	and 85.0 dB.		

The user inputs the gain value desired. Gain values from 53.5 dB to 85.0 dB may be selected. The repeater will not allow the user to set values outside this range. If a new filter set is required, the new filter may be selected from the "Program a Filter page" below.

#### **Program a Filter**

The user may select the desired filter by pressing the band/sub-band and modulation selection buttons. Undesired bands/sub-bands if lit will require the user to manually "deselect" them before programming. Pressing the Program button will complete the selection and load the desired filter. The time required to complete this process will take just a few moments. Note: If the filter desired is not currently in the unit, additional filters along with instructions on how to load them are available by contacting CSI.



#### **Remote Network**

If the repeater includes a USB modem kit, click on Remote Network in the navigation box and the screen below is displayed. Highlight the carrier on whose network the repeater and modem will be configured and click the Change Settings button. Refer to the documentation included with the modem kit for additional information on configuring the modem. If the repeater is connected to an ethernet device for remote access and/or monitoring, this feature must be disabled.

Remote Network - Mozilla Fire Elle Edit View History Bookmark	fox Elep
Most Visited 🏶 Getting Started 🦲	http://192.168.1.100/remo 77 * Left Google       Latest Headlines      Customize Links      **
System Status Local Network RE Configuration	Remote Network
Program a Filter Remote Network	Status: O Disabled O Enabled Carrier: Unknown
SNMP Configuration System Health Install & Upload	Change Sett Change Sett Sprint Telcel Telefonica
Reboot Alarm Configuration	US Cellular Verizon EvdoVerizon
Log Configuration Change Password	
Done	

#### **SNMP** Configuration

To change SNMP settings click SNMP Configuration in the navigation box, the screen below will be displayed. If the user is not well versed in Simple Network Management Protocol he or she should check with their IT professional for proper setting requirements.



#### System Health

By clicking System Health the current state of the repeater can be reviewed.

Edit View History Bookmarl	s Iools Help 🔘 -	1. 2.1	
) 🕞 C 🗙 🏠 🗍	http://192.168.1.100/sta	atus.cgi 🏠 -	G. Google
ost Visited 🌮 Getting Started 📥	Latest Headlines	ize Links 📄 Wind	ows Marketplace
gnupShield 💰 Fill-in 🔚 Save For	m 🖑 1-Click Sign-in		
System Status			
Local Network	System I	lealth	
	100		
RF Comguration	Band Type	LT	E
Program a Filter	(Celsius)	2:	9.2
Remote Network			
SNMP Configuration	Current (Amps)	1	9
System Health	Power Amplifier		
Cystern Polan	Status	0	n
Install & Upload	Current (Amps)	1.	6
Reboot	Alarms	Down Link	Up Link
Alarm Configuration	DAC PLL Lock	OK	OK
	LO PLL Lock	OK	OK
Email Configuration	FPGA	0	ĸ
Log Configuration		-	
Change Password	Event Log		
	*		****
	Clear Log Trig	gger Test Alarm	

\*\*\*The user may clear LED indicators, alarms and the Event Log by clicking the Clear Log button. \*\*\*\* If required, visit the "System Health" screen and click on "Trigger Test Alarm" and wait for confirmation that the Service Provider representative that is responsible for monitoring the repeater has been notified of the alarm. Be sure to "Clear All Logs" prior to logging out of the Web Interface.

#### Install & Upload

Should a software install or upgrade be needed it can be done from the Install & Upload screen shown below. As with the other screens it can be reached by clicking the words in the navigation box. Contact CSI for updates and instructions.



#### Reboot

If a reboot of the repeater becomes necessary click on the Reboot option in the navigation box and the Reboot page is displayed.



### **E-mail Configuration**

E-mail Configuration page allows the user to enter up to five E-mail addresses to which the repeater can send specified alarm messages when the repeater is connected via ethernet or wireless modem and E-mail Alarm Notification or Remote Networking are enabled. \*NOTE: In all fields the software will not allow the user to enter invalid characters.

Image: Sector	- C X A	Http://192.168.1.300 kesalconf.co		P
		Las particular and the second state	Bar way	
March Status do Native do Native Status do Native St	st Visited Ip Getting Started	Latest Headines 📋 Customize Links 🛄 Wir	idows Marketplace	
Applications       Ensemble Configurations         Configurations       For ensemble configurations taken do adapting the points if you can be there are not expected table of the data pupeling table of table	atores Street Dater	Email Confirmation		
Call Network Call Network Call Network Call Network Call Network See Call Network	/stem Status	Email Configuratio		
Fordigation of the second	ocal Network	Please consult your IT department before affort emails. Note: Finally will not be a	e changing any values if you are not sure you understand how this data will not if you do not have a valid betreast connection	
open an Fair mance between       between the base is base in the second second of the base angle is a base mance between the base is base in the second second of the base angle is a base ween the base is base in the second second of the base angle is a base ween the base is base in the second second of the base angle is a base ween the base is base in the second second of the base angle is a base ween the base is a base in the second second of the base angle is a base is a base is a base in the second second of the base angle is a base is a base is a base is a base in the second second of the base angle is a base is a base is a base is a base is a base is a base is a base is a base is a base is a base is a base is a base is	F Configuration	The second and and matine is shown	- to be a set of the same is init for destand the shows the same formation and	
ygen in Market Mer Configuration van Configurat		the new value and select the Save button	n. The configuration of a particular field will not be changed if the data input in	6
ande bakyverk sende bakyverk tysten i kodh utal 8 Jujad utal 8 Jujad nai Configuration nai Configuration nai Configuration nai Configuration nai Configuration nai Configuration nai Configuration Partiel Bassocial Configuration Partiel Bassocial Partiel Bassocial	rogram a riter	myals. Emails will not be sent if the sent current email configuration. To view all v	fer information is not supplied or is incorrect and valid data does not exist in t values present in the system after an error occurs, select Ernal Configuration a	he st
Bake Bundle       Optim Float       Value Neuron       Optim Float       Value Neuron       Value Neuron </td <td>ernote Network</td> <td>the left to redisplay this page.</td> <td></td> <td>1</td>	ernote Network	the left to redisplay this page.		1
Value Victor	NMP Configuration	Enable Emails		
stati 2 kplovati stori 2 kpl	ystem Health	ZING ALIGNO O ON O OFF		
dood     diff Pin Adam     vir, ST m	istall & Upload	Sender Email Account Configuration		
Advances and Tarrey ( and a second tarrey (	rehoot	SMTP Host Address	mitp.321.met	
Cardin Carding values road Configuration Toorige Password  Carding values  Andredice as all party Configurate Andredice as all party Configurate Prim Address 1 Prim Address 2 Prim Address 3 Prim Address 3 Prim Address 3 Prim Address 3 Prim Address 4 Prim Address 4 Prim Address 5 Prim Address 5 Prim Address 4 Prim Address 5 Prim Address 5 Prim Address 6 Prim Address 6 Prim Address 6 Prim Address 7 Prim Address 6 Prim Address 7 Prim Add		User Account Password	4	
med Configuration og Configuration og Configuration Prei 20 Aufendien ad Energe Configuration Aufendien ad Energe Configuration Aufendien ad Energe Configuration Aufendien ad Energe Configuration Aufendien ad Energe Configuration Preise Aufendien Preise Aufendien Preise Aufendien Register Fault Adverse Configuration Register Fault Adverse Configuration Registe	Narm Configuration	Confirm Password	1	
og Configuration Tange Password  Addination and Encycl Cologicunia Automation and Encycl Cologicunia Transper Davisourby (TLL) © (H ⊂) O(H Transper Lipse Venctry (TLL) © (H ⊂) O(H) Final Advers 1 Transper Lipse Venctry (TLL) © (H ⊂) O(H) Transper Lipse Venctry (TLL) © (TL	imail Configuration	Timeout (secs)	120	
Particle Parameter         Particle Parameter         Manufacture and Decrys Configuration         Manufacture and Decrys Configuration         Manufacture and Decrys Configuration         Manufacture and Decrys Configuration         Film Address *         Benefacture Datal Manufacture	.og Configuration	For	( <u>a</u>	
Availantionia Markania Bag Traingent (2009 00 cm) 0 cm Tal Conditionia 0 cm Band Markers 1 cm Band Advers 1 cm Band Advers 2 cm Band Advers 2 cm Band Advers 3 cm Band Advers 4 cm Ban	Change Password	Authenticate and Encrypt Configurat	Son	
Tandpadi. Lipi visioning (J. 10) © OH ⊂ OHP Tala Monage Cadegordine Frans Advisor © Proceed@40.201.est Badgets 201.est Exclud Advisor 2 Exclud Advisor 3 Exclud Advisor 3 Exclud Advisor 4 Heart Advisor 4 Exclud Advisor	-	Authentication Met	tod login	
Incommentation Com © Corp Family Reserver Competition Stream Prim Addenser Band Addensers Ender Addense		Transport Layer Security (1		
Famil Biorage Configuration       Joing et line       Brief Statil       Brie		TLD OPTIMIER OF	ARK CON COPP	
FrankAders Burgher Damit Monece BandAders 1 BandAders 2 BandAders 3 BandAders 4 BandAders		Email Message Configuration		
Budget 0 Beddater 4 Endot Advers 4 Endot 0 Det 0		From Addesse vzv	pcs@kits.321.net	
Becjefter Stand Adversor Reind Advers 1 Reind Advers 2 Reind Advers 3 Becker Advers 4 Becker Market Configuration Hendrick Stand Configuration Hendrick Stand Configuration Opt © Opt Progenery Sharet 7 0 Tetroson		Subject 0		
Enda Adexes 1 Enda Adexes 2 Enda Adexes 3 Enda Adexes 3 Enda Adexes 4 Enda Adexes 4 Enda Adexes 5 Heartens Enda Copy © Opp Heartens Enda Copy © Opp Heartens Deata Copy 0 Techcore Preperory flower() 4€		Recipient Email Addresses		
EndiAders 2 EndiAders 2 EndiAders 3 EndiAders 4 EndiAders 4 EndiAders 4 EndiAders 5 EndiAders 4 Off © 077 Modes Propose y found; 0		Email Address 1		
Enal Advers 3 Enal Advers 4 Enal Advers 4 Herefore Enal Control Contr		Email Address 2		
EndlAders 4 EndlAders 4 Isratheal Endle Heartheal Endle O Ott © 077 Moldo © Tase Proposety flower) 4		Email Address 3		
Tende Address > Hourdward Tende Address > Hiverten Randa ⊂ O corr Motion @ Trans ⊂ Ø Tende on Pregenory flowed) 46		Email Address 4		
Heartheat Danal Configuration Heartheat Bands ⊂ Octs © 0777 Molde © Trans ⊂ Vietoure Progenery Shanet) de		Email Address 5		
HendrasEnait O (201 © 0797 Mode 07 tesses O Yadose Preparecydwene) (8		Heartheat Email Configuration		
Mode © Tense O Verbose Enregennry (hone) 48		Heartbeat Emails C	910 ON 001	
Frequency (hours) 48		Mode 🧿	Tesse O Verbase	
		Frequency (hours) 48	Contraction and Contraction	
		Prequency (hours) 48		
Fund Macrosov		Email Massagas		
Email Messages		Email Messages		
Email Messages Ure the battern before its read work there make that are convertly in the enablemessage spress. Note		Email Messages Use the buttons below to send a test en	all and show the emails that are currently in the email message queue. Note	
Email Messager Une the http://dorisonal.exat. To the the http://dorisonal.exat.exat.exat.exat.exat.exat.exat.exat		Email Messages Use the buttons below to send a test en Test emails cannot be sent if the enail al receiver enail addresses	ul and show the enails that are currently in the enail message queue. Note: arms are disabled or if there are any errors in the enail configuration data and	foe
Email Messages Enclosed the state state is not and and due the scale that we constally in the real stategy quote. How For the attracts to send the scale are an disable of these are say source in the real configuration data suffer and the scale of the s		Email Messages Use the buttons below to send a test en Test emails cannot be sent if the enail al recipient enail addresses. Send Test Email	all and show the enails that are currently in the small nessage queue. Note uma are disabled or if there are any seriors in the small configuration data and	foe
Email Beneargers Email Messagers Type to tatatuse balance and a fact and and factor the results that are meaning in the medi meange space. Unter Type main fact and and the medi dame are detailed on of there are say means to be medi configuration, data, untiler response of the factors. [See Control Messages]		Email Messages Use the buttom below to send a test m Test enails cannot be send if the enail al requiret read addresses. Sterr Test Test Test	all and show the emails that are currently in the email nearage queue. Note annot are doubled on if there are any errors in the small configuration, data unit	lee

### **Alarm Configuration**

The Alarm Configuration page allows the user to specify what events will trigger an alarm.

\*NOTE: Letters, numbers & hyphens are the only acceptable nomenclature for the Location field and hyphens may not be used as the first or last character.

stem Status	Alarm Conf	igurat	ion				
cal Network	Below is the present confi Incheck an event to prev	iguration for a	each alarm	and their associated	events.		
Configuration	his operation could take	several minu	tes to com	plete.		1	
- 53	RF Alarms	Down Li	ink	Up Link			
igrani a niter	Over Range	Over Rar	age				
mate Network	Oscillation	Warning Shutdow	m	☑ Werning ☑ Shutdown			
MP Configuration	Out of Band Overdrive	C OOB		00B			
sten Heath	Low Signal	Low Sign	lac				
otominioukin	No Signal	No Signa	1				
tall & Upload	System Alarms						
hort	Synthesizer Lock	LO Phase	e Lock (als	o affects hardware)			
arm Configuration ail Configuration	Voltage	PA Unde PA Unde DC Over DC Unde Over Pos	Current Current Current or Current wer Up				
ange Password	Temperature	Overheat Under Te	t t t				
	Software	Software Software Property	Abort Error Failure				
	Hardware	LO Phase Filter Los LCD Fail DAC Res	e Lock (als ad ture ad Error	o affects synth lock)			
l	Apply Settings					J	
[	Alarm Origin Tag Set	tings					
	Loc	ation Softw	vare_Lab				

## Log Configuration

The Log Configuration page provides the user with the means to modify three aspects of how log files are created and stored as shown below.

C X A Intro/I/192.166.1.100/logcorf.cg Most Visited Getting Started Latest Headlines Customize Links Windows Merketplace System Status Local Network RF Configuration Program a Filter Remote Network SNMP Configuration System Health Install & Upload Reboot Alarm Configuration Endition Log Configuration Conf	C X A Introl/1/192.168.1.100/jogcorf.cg Most Visited G Getting Started Latest Headlines Customize Links Windows Marketplace System Status Local Network RF Configuration Program a Filter Remote Network SNMP Configuration System Health Install & Upload Reboot Alarm Configuration Log Configuration Earlier Configuration Configura	e Edit View History Bookman	ks Iools Help			
Weak Visited Getting Started   Latest Headlines Customize Links   Windows Merketplace   System Status   Local Network   RF Configuration   Program a Filter   Remote Network   SNMP Configuration   System Health   Install & Upload   Reboot   Alarm Configuration   Email Configuration   Email Configuration   Email Configuration   Configuration   Email Configuration   Log Configuration   Log Configuration   Log Configuration   Change Password	Mode Voided Cartery Started   System Status   Local Network   RF Configuration   Program a Filter   Remote Network   SNMP Configuration   System Health   Install & Upload   Reboot   Alarm Configuration   Email Configuration   Change Password	G 💽 • C 🗙 🏠 (	http://192.168.1.100/logconf	.cgi	ଘ • <b>ଢ</b> • ଉ	agle
System Status       Local Network         Local Network       Log Configuration         Program a Filter       Log Rotate Frequency 2 minutes         Remote Network       Log Rotate File Size         SNMP Configuration       100         System Health       Configure Logs         Install & Upload       Configuration         Alarm Configuration       Email Configuration         Log Configuration       Configuration         Change Password       Configuration	System Status   Local Network   RF Configuration   Program a Filter   Remote Network   SNMP Configuration   System Health   Install & Upload   Reboot   Alarm Configuration   Log Configuration   Configuration   Log Configuration	Most Visited 🌮 Getting Started 📒	Latest Headlines 📄 Customize L	inks 📄 Windows I	Marketplace	
System Status Local Network RF Configuration Program a Filter Remote Network SNMP Configuration System Health Install & Upload Reboot Alarm Configuration Email Configuration Log Configuration Change Password	System Status         Local Network         RF Configuration         Program a Filter         Remote Network         SNMP Configuration         System Health         Install & Upload         Reboot         Alarm Configuration         Log Configuration         Log Rotate File Count         Install & Opload         Email Configuration         Log Configuration         Configuration         Configuration         Configuration         Configuration         Configuration         Configuration         Log Configuration         Log Configuration         Change Password					
Local Network     Log Configuration       RF Configuration     Program a Filter       Remote Network     Log Rotate File Size       SNMP Configuration     100       System Health     Configure Logs       Install & Upload     Configure Logs       Alarm Configuration     Email Configuration       Log Configuration     Configuration       Configuration     Configuration	Log Configuration       RF Configuration       Program a Filter       Remote Network       SNMP Configuration       System Health       Install & Upload       Reboot       Alarm Configuration       Email Configuration	System Status	I C C			
RF Configuration         Program a Filter         Remote Network         SNMP Configuration         System Health         Install & Upload         Reboot         Alarm Configuration         Enail Configuration         Log Configuration         Configuration         Configuration         Configuration         Configuration         Configuration         Configuration         Configuration         Configuration         Change Password	RF Configuration         Program a Filter         Remote Network         SNMP Configuration         System Health         Install & Upload         Reboot         Alarm Configuration         Log Configuration         Email Configuration         Configuration         Configuration         Change Password	Local Network	Log Configu	ration		
Program a Filter       Log Rotate Frequency       2       minutes         Remote Network       Log Rotate File Size       100       Kilobytes         SNMP Configuration       Log Rotate File Count       10       Configure Logs         System Health       Configure Logs       Configure Logs       Configure Logs         Alarm Configuration       Email Configuration       Enail Configuration         Log Configuration       Configuration       Configuration         Change Password       Configuration       Contact File Count	Program a Filter     Log Rotate Frequency     2     minutes       Remote Network     Log Rotate File Size     100     Kilobytes       SNMP Configuration     Log Rotate File Count     10       System Health     Configure Logs     Install & Upload       Reboot     Alarm Configuration       Email Configuration     Enail Configuration       Log Configuration     Kilobytes	RF Configuration	8			
Remote Network     Log Rotate File Size     100     Kilobytes       SNMP Configuration     Log Rotate File Count     10     Configuration       System Health     Configure Logs     Configure Logs     Configuration       Reboot     Alarm Configuration     Email Configuration       Log Configuration     Configuration     Configuration       Configuration     Configuration     Configuration	Remote Network   SNMP Configuration   System Health   Install & Upload   Reboot   Alarm Configuration   Email Configuration   Log Configuration   Configuration   Change Password	Program a Filter	Log Rotate Frequency	2	minutes	
SNMP Configuration     Log Rotate File Count     10       System Health     Configure Logs       Install & Upload       Reboot       Alarm Configuration       Email Configuration       Log Configuration       Configuration       Change Password	SNMP Configuration     Log Rotate File Count     10       System Health     Configure Logs       Install & Upload     Install & Upload       Reboot     Alarm Configuration       Email Configuration     Install & Upload       Log Configuration     Install & Upload       Change Password     Install & Upload	Remote Network	Log Rotate File Size	100	Kilobytes	
System Health Configure Logs Install & Upload Reboot Alarm Configuration Email Configuration Log Configuration Change Password	System Health     Configure Logs       Install & Upload     Install & Upload       Reboot     Install & Upload       Alarm Configuration     Install Configuration       Log Configuration     Install & Upload       Change Password     Install & Upload	SNMP Configuration	Log Rotate File Count	10		
Install & Upload Reboot Alarm Configuration Email Configuration Log Configuration Change Password	Install & Upload Reboot Alarm Configuration Email Configuration Log Configuration Change Password	System Health	Configure Logs			
Reboot Alarm Configuration Email Configuration Log Configuration Change Password	Reboot Alarm Configuration Email Configuration Log Configuration Change Password	Install & Upload				
Alarm Configuration Email Configuration Log Configuration Change Password	Alarm Configuration Email Configuration Log Configuration Change Password	Reboot				
Email Configuration Log Configuration Change Password	Email Configuration Log Configuration Change Password	Alarm Configuration				
Log Configuration Change Password	Log Configuration Change Password	Email Configuration				
Change Password	Change Password	Log Configuration				
		Change Password				

#### **Change Password**

By clicking on the Change Password link the user is brought to the Change Password page. From here he or she can quickly and easily reset the password for the unit. A word of warning here be careful when setting the new password. If you forget what you set your password to you'll need to contact CSI at 1-877-844-4274 for assistance.

🕹 Change Password - Mozi	illa Firefox			
<u>Eile E</u> dit <u>V</u> iew Hi <u>s</u> tory <u>B</u> i	ookmarks <u>T</u> ools <u>H</u> elp 🕻	y.		0
G C X 🧃	http://192.168.1	1.100/password.cgi	☆ ★ Google	P
📄 Most Visited 🍄 Getting Start	ed 🗾 Latest Headlines 📄	Customize Links 📄 Windows Marketplace		
SignupShield 뤐 Fill-in 🔒 Si	ave Form <u> 1</u> -Click Sign-in			
System Status Local Network RF Configuration	Change Pa	issword		
Program a Filter Program a Filter Remote Network SNMP Configuration System Health Install & Upload Reboot Alarm Configuration Email Configuration Log Configuration Change Password	Change Password Account Password Confirm Password Save	webuser		
Done				.1

To end the session exit the browser, the user will be automatically logged out.

#### Text Menu Interface (Local Access)

Local access to the repeater TMI, also known as the console interface, is made by connecting a serial cable (optional), as shown in figure 1, from the serial connector of the laptop to either of the serial ports on the bottom end panel of the repeater. These connectors are labeled COM 1 and COM 2. In some cases, if the gender of the connector is not the same as shown in figure 1, a null modem adapter (optional) as shown in figure 2 may also be required.





Figure 1

#### **Terminal Emulation Program**

Many terminal emulation programs will work if properly configured. In the following description, "TeraTerm" is used to establish the TMI session. This program is readily available via the Internet and is free from Ayera Technologies at:

http://www.ayera.com/teraterm/

TeraTerm Pro Web works on Windows 95/98, 2000, XP. Here is the latest TeraTerm Pro Web release:

Version 3.1.3, October 8, 2002. ttpro313.zip

When the program is started, the following screen is displayed.

Tera Term: New connection 🛛 🔀
TCP/IP
Host: 127.0.0.1
Service:  Telnet TCP port#: 23 SSH Other
C Serial Port: COM1 🔽
OK Cancel Help

Select the Serial radio button and press OK as shown below.

Tera Term: New connection 🛛 🔀
С ТСР/ІР
Host: 127,0,0,1
Service: C Telnet TCP port#: C SSH
Port: COM1
OK Cancel Help

Note: It may be necessary, in the System Properties section of the control panel; using Device Manager to determine what COM port your computer uses for the communications port. In this case it is COM 1. This is not to be confused with the serial port on the bottom panel of the repeater labeled COM 1.

#### **Terminal Emulation Set-up**

Pressing "OK" will open up a blank dialog screen. Go to the setup dropdown menu and select Serial port to make changes to the serial port setup.



Configure the terminal program for the correct COM port, in this case COM 1 and 115200 baud rate as shown below.

Tera Term: Seri	al port setup	
Port:	COM1 -	ОК
Baud rate:	115200 💌	
Data:	8 bit 💌	Cancel
Parity:	none 💌	
Stop:	1 bit 💌	Help
Flow control:	none 💌	
Transmit dela	y :/char 0 r	nsec/line

#### TMI Login

After completing the serial port changes (pressing the enter key will be required to complete the action) the user will be prompted for a user name and password. The default user name is "**user**". The password is "**csi1234**". After entering the password and pressing return the TMI main menu will appear. Note: by default the Set Parameters option is disabled. To re-enable the user will press 1 and will be prompted for a user name and password. The default user name is **csi** and the password is **csi1234**.



Each "Set Parameter" selection, when chosen will be expanded to allow changing or setting of that parameter. For example from the Link Configuration menu on the previous page, selecting 1 - Adjust Gain will display the menu shown below.



After selecting option 1, downlink, the current user gain is displayed and the option to change it is accomplished by typing the desired gain at the prompt. The user is then returned to the previous menu.

💻 Tera Term Web 3.1 - COM1 VT 🛛 🔳 🗖 🖥	×
<u>File E</u> dit <u>S</u> etup We <u>b</u> C <u>o</u> ntrol <u>W</u> indow <u>H</u> elp	
Links: (1) downlink (2) uplink (r) Return to previous menu Link?	~
User Gain: Setting 85.00 dB User Gain? 80 Auto Setting Uplink Gain to 80.00 dB To override, set Uplink gain separately	
Link Configuration ====================================	
<ul> <li>(1) Adjust Gain</li> <li>(2) Select Active Filter</li> <li>(3) Filter Programming</li> <li>(4) PA Output Control</li> <li>(5) PA Oscillation Shutdown Control</li> <li>(6) PA Oscillation Timer Control</li> <li>(r) Return to previous menu</li> </ul>	•
	:

All the other options operate in much the same way. Some of the options will offer the user additional selections and will be self-explanatory. Below is one example of these additional options, the one shown below is the result of selecting (3) Filter Programming.

💻 Tera Term Web 3.1 - COM1 VT	
File Edit Setup Web Control Window Help	
Link Configuration Link Configuration (1) Adjust Gain (2) Select Active Filter (3) Filter Programming (4) PA Output Control (5) PA Oscillation Control (r) Return to previous menu ->	~
Scan USB for files? (y,n):n File names: (1) leA1-0 (2) leB1-0 (3) leA1B1-0 (4) lcA0B0-0 (5) leA3A4A6A7B3B4B6-0 (r) Return to previous menu	
Enter file number?	> .:

Note: Graceful session termination is important. Use Disconnect under the file dropdown menu to terminate a session, otherwise the port may become disabled and force the system to be rebooted.

#### **Telnet Session (Remote Access)**

Remote access to the repeater may be gained through a LAN connection and a terminal emulation program for TCP/IP. As with the serial connection, many terminal emulation programs will work, if properly configured. In the following description, "TeraTerm" is used to establish the Telnet session. Also, it will be required that the network configuration of the computer and the repeater being controlled be set up with the same Sub Net and Sub Net Mask in order to establish a link. In other words, the IP addresses of both the computer used and the repeater must use the same group of IP address number sets. For example, the repeater ships with the default IP address of 192.168.1.100 and a Sub Net Mask of 255.255.255.0. In order to connect, the computer to be used for the link would normally need an IP address of something like 192.168.1.12 with a Sub Net Mask of 255.255.255.0, the same Sub Net Mask as the repeater. In this example note: the last digit of the IP address may be any number except 1,100 and 255. Configuring your PC is normally fairly straight forward but it does vary somewhat with the operating system involved. If you require assistance, contact your IT department and they will be able to set up your PC for you or you may review the Additional Tips Section at the end of the manual.

When the TeraTerm program is started, the following screen is displayed. Change the default host IP address to the IP address of the repeater to be controlled. In the case of a new install, the default address is 192.168.1.100 and has been assigned at the factory. Select the service Telnet. The TCP Port must be 23.

### **Telnet Session Login**

Tera Term: New connection	×
Host: 192.168.1.100	-
Service:  Telnet TCP port#: 23 SSH Other	
Port: COM1 _	
OK Cancel Help	

Pressing the "OK" button will bring the user to the following screen, which will require the user to log in. The default user name is "**user**". The default password is "**csi1234**".

🚇 Tera Term Web 3.1 - 192.168.1.100 VT	
File Edit Setup Web Control Window Help	
Technologic Systems Linux Version 3.07a	<
csi-dsplogin: Password:	
	<b>v</b>

In the field after the prompt type the user name and password. After typing the password press the enter key and the main menu will be displayed as shown next.

📕 Tera Term Web 3.1	- 192.168.1.100 VT	
<u>File E</u> dit <u>S</u> etup We <u>b</u>	C <u>o</u> ntrol <u>W</u> indow <u>H</u> elp	
Waiting for Confi	guration Update	Complete
Waiting for Link	initialization	
Status	DNLINK	UPLINK
Configuration Attenuator 1 Attenuator 2 Attenuator 3 DAC 1 DAC 2 PIL 1 PIL 2 DPD 1 DPD 2 FPGA 1 FPGA 2 PRECOMP 1 PRECOMP 2	OK OK OK OK OK OK OK OK OK OK OK OK OK	OK OK OK OK OK OK OK OK OK OK OK
Link Initializati	on Complete	
Main Menu ======== (1) Set Parameter (2) Get Parameter (3) System Comman (x) Exit ->	s - Disabled s ds	×
		> .::

Telnet and serial sessions both provide access to the same Text Menu Interface. We have already shown many of the options available and all are self explanatory, so they will not be repeated.

#### Modem Interface (Remote Access with login)

A modem can also be used to gain remote access to the unit provided the repeater has been properly equipped. A selection of modems is available as an option. If the modem requires a SIM card for activation, special requirements must be met for the SIM card to become fully functional, contact the service provider. In addition, an IP address must be obtained and entered into the repeater.

Once the modem has been installed and activated, it can be accessed from any terminal emulation program just as in the serial and Telnet examples provided earlier. Access response time will depend on many factors, some of which are:

- Quality of the connection (RF signal in the case of wireless modems)
- Technology (CDMA, EDGE, GPRS, etc.)
- Network congestion (Throughput)

When a connection has been established, the same login screen shown in both the serial and Telnet examples is presented.

#### **Additional Tips**

Instructions to change TCP/IP settings on your Windows computer.

Click in the Network Connections Icon in the Control Panel. See below.



Right click on Local Area Connection - and select "Properties".



Scroll down to "Internet Protocol (TCP/IP) and click on the "Properties" button.

Local Area Connec	tion Properties	?
ieneral Advanced		
Connect using		
Broadcom NetX	reme 57xx Gigabit C	Configure
This connection uses th	he following items:	
Brie and Printe     OoS Packet S     Thtemet Proto	r Sharing for Microsoft cheduler col (TCP/IP)	Networks
lgstal	Urenotal	Properties
Description		and the second sec
Transmission Control wide area network p actoss diverse interc	Protocol/Internet Pro totocol that provides c onnected networks.	tocol. The default communication
Show icon in notific	ation area when conne	ected
Notily me when this	connection has limited	d or no connectivity
		K Cancel

If you are set up to use DHCP, the window shown below will be displayed.

eneral Alternate Configuration	a
You can get IP settings assign his capability. Otherwise, you r he appropriate IP settings	ed automatically if your network supports weed to ask your network administrator for
Dhain an IP address auto	omatically
O Uge the following IP addre	EEK.
P-address	
Subriel mail:	· · · · · · · · · · · · · · · · · · ·
Datant pataway	
Obtain DNS server addre	ss automatically
O Use the following DNS se	tver addresses.
Evelened DNS serves	
Alternate DNS server	
	Adganced
	OK Cano

Select "Use the following IP address:" and enter "192.168.1.2." The subnet mask should automatically populate to "255.255.255.0".

Serveral	
You can get IP settings assigned this capability. Otherwise, you nei the appropriate IP settings.	automatically if your network supports ed to asik your network administrator for
O Obtain an IP address autom	atically
Uge the following IP address	
IP address	192 168 1 2
Subnet mask:	255 . 255 . 255 . 0
Default gateway	I see a se
O Blain DNS serves address	adomatically
<ul> <li>Use the following DNS service</li> </ul>	er addresses:
Preferred DNS server:	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
Alternate DNS server	
	Advanced

Nothing else will need to be chosen or entered. Click "OK", then "OK again and retry connection.

A crossover Ethernet cable (supplied) must be used for Web Interface access. As a reminder, you must verify the Ethernet port on your laptop is powered. If your laptop is on battery power, the Ethernet port may be inactive by default. If this is the case simply plug in the laptop to a 110vac source or change the power settings to enable the Ethernet port when the laptop is using battery power.

#### Suggested spectrum analyzer setting

When troubleshooting RF issues, and when surveying challenging RF environments, it's important to have a spectrum analyzer capable of measuring the frequency that you are working with. An attenuator should be used to protect the input, when connected to a source of RF power such as the repeater or a powered DAS.

Both Uplink and Downlink should be measured. Downlink should be measured on the donor cable and at the output (server) port of the powered up repeater, and Uplink at the lead from the DAS (on fiber/powered DAS's, where the lead would connect to the server port on the repeater) and at the donor port with the repeater powered up. Measurements may also be necessary at server antenna locations. Your spectrum analyzer will need to be equipped with a whip antenna for this.

Resolution Bandwidth (RBW) should be set at 200 kHz for GSM and 1 MHz for CDMA. If you cannot select these values, the closest available values should be used. Video filter should be about one tenth of RBW. Other settings like span are whatever is appropriate. One should also make sure that there are no signals above the top of the screen.

If you cannot see an adjacent out of band signal when using the 1 MHz RBW filter, you can decrease the RBW, to see the close-in-frequency signals. Be sure to set the RBW back when you want to measure the power level.

#### **RF Notes**

To prevent overload of the DSP input stages, the maximum measured level of in-band or out of band signals should be less than -50 dBm when the DSP gain is set to 85 dB, -40 dBm when set to 75 dB, etc. This applies when there is one dominant signal and applies TO BOTH THE DOWNLINK AND UPLINK. If there are two dominant signals, and the gain is set to 85 dB, then the level of each signal should be kept to less than -53 dBm. With three signals, each should be less than -55 dBm. With ten signals each should be less than -60 dBm. This latter reduction prevents the composite power of the multiple signals from exceeding an acceptable level. Add fixed attenuators in line with the donor antenna line/DAS feed to keep signals below the levels indicated above.

#### **One Year Limited Warranty**

Seller warrants that its products are transferred rightfully and with good title; that its products are free from any lawful security interest or other lien or encumbrance unknown to Buyer; and that for a period of one year from the date of installation or fifteen months from the date of original shipment, whichever period expires first, such products will be free from defects in material and workmanship which arise under proper and normal use and service. Buyer's exclusive remedy hereunder is limited to Seller's correction (either at its plant or at such other place as may be agreed upon between Seller and Buyer) of such defects by repair or replacement at no cost to Buyer. Transportation costs in connection with the return of products to Seller's plant or designated facility shall be paid by Buyer. The provisions of this warranty shall be applicable with respect to any product which Seller replaces pursuant to it. SELLER MAKES NO WARRANTY, EXPRESS OR IMPLIED, OTHER THAN AS SPECIFICALLY STATED ABOVE. EXPRESSLY EXCLUDED ARE THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR PURPOSE. THE FOREGOING SHALL CONSTITUTE ALL OF SELLER'S LIABILITY (EXCEPT AS TO PATENT INFRINGE-MENT) WITH RESPECT TO THE PRODUCTS. IN NO EVENT SHALL SELLER BE LIABLE FOR SPECIAL, CONSEQUENTIAL OR INCIDENTAL DAMAGES, INSTALLATION COSTS, LOST REVENUE OR PROFITS, OR ANY OTHER COSTS OF ANY NA-TURE AS A RESULT OF THE USE OF PRODUCTS MANUFAC-TURED BY THE SELLER, WHETHER USED IN ACCORDANCE WITH INSTRUCTIONS OR NOT. UNDER NO CIRCUMSTANCES SHALL SELLER'S LIABILITY TO BUYER EXCEED THE ACTU-AL SALES PRICE OF THE PRODUCTS PROVIDED HEREUN-DER. No representative is authorized to assume for Seller any other liability in connection with the products.

#### Industry Certifications/Registration Numbers:

FCC: NVRCSI-DSP25XH-L7, NVRCSI-DSP25XH-U7C IC: 4307A-DSP25XH-L7, 4307A-DSP25XH-U7C

## Index

#### A

AC Current 14 AC Power Frequency 14 AC Power Specifications 14 AC Voltage 14 Additional Tips 31 AGC 5 Alarm Configuration 22 APC 5 Application 4 AUI 5 Automatic Gain Control 15

#### B

Box Weight 14

### С

CDMA RHO 15 Change Password 23 Circuit Operational Description 13 Connectors 15 CPU 5 CSI 5

### D

DAS 5 DHCP 5 Document Purpose / Intended Users 4 DSP 5

### E

EEPROM 5 Email Configuration: 22 Environmental Requirements 14 ERP 5 Event Log 21 Explosive Atmospheres 4

#### F

FPGA 5 Functional Block Diagram 13 Functional Overview 7

## G

Grounding 4

#### Η

Heat Output 14

#### I

Important Installation Notes 12 Important Safety Information 5 Inadequate isolation 12 Industry Certifications/Registration Numbers 34 Input VSWR 15 Install Software 21

### L

LED 5 LED Indicators 7 Lightning Danger 4 Linear Gain 15 Linear Output Power 15 Liner Output Power 15 Local Network 18 Log Configuration 23 login 17

## M

Manual Gain Control 15 Maximum RF input Power 15 Modem Interface 30 modulation selection 19 Monitoring & Alarms 9

## Ν

Noise Figure 15 null modem adapter 23

### 0

OIP3 15

## Р

Pass Band Ripple 15 Product Registration Information 4 Program a Filter 19 Propagation Delay 15

### R

Reboot 22 Relative Humidity 14 Remote Network 20 Repeater Size 14 Resolution Bandwidth 33 RF Configuration 19 RF Notes 33 RMS Vector Error 15

## S

SBC 5 serial cable 23 SNMP 5 SNMP Configuration 20
Spurious Emissions & Applicable Documents 15
Suggested spectrum analyzer setting 33
Surface Coating 14
System Health 21
System Status 18

### T

TCP/IP settings 31 Telnet Session 28, 29 Temperature Range 14 terminal emulation programs 24 Terms used in this manual 5 Thermal Management 14 TMI 5 troubleshooting RF issues 33

### U

UHCI 5 USB 5 USB Interface 8

#### W

Wall Mounting 11 Warranty 34 Web based GUI Session 17 Weight 14





670 North Commercial Street Manchester, NH 03101

Toll Free: 1.877.844.4274 Phone: 603.626.6677 Fax: 603.626.6042

www.cellularspecialties.com