IDENTIFICATION



USER GUIDE

ID HyWEAR compact

Hands-Free UHF RFID & Barcode Scan System



Note

© Copyright by FEIG ELECTRONIC GmbH Lange Strass 4 D-35781 Weilburg (Germany) Tel.: +49 6471 3109-0 <u>http://www.feig.de</u> <u>http://www.panmobil.com</u> <u>info@panmobil.com</u>

With the edition of this document, all previous editions become void. Indications made in this manual may be changed without previous notice.

Copying of this document and giving it to others and the use or communication of the contents thereof are forbidden without express authority. Offenders are liable to the payment of damages. All rights are reserved in the event of the grant of a patent or the registration of a utility model or design.

Composition of the information in this document has been done to the best of our knowledge. FEIG ELECTRONIC GmbH does not guarantee the correctness and completeness of the details given in this manual and may not be held liable for damages ensuing from incorrect or incomplete information. Since, despite all our efforts, errors may not be completely avoided, we are always grateful for your useful tips.

The instructions given in this manual are based on advantageous boundary conditions.

FEIG ELECTRONIC GmbH does not give any guarantee promise for perfect function in cross environments and does not give any guarantee for the functionality of the complete system which incorporates the subject of this document.

FEIG ELECTRONIC GmbH calls explicit attention that devices which are subject of this document are not designed with components and testing methods for a level of reliability suitable for use in or in connection with surgical implants or as critical components in any life support systems whose failure to perform can reasonably be expected to cause significant injury to human health. To avoid damage, injury or death the user or application designer must take reasonably prudent steps to protect against system failures.

FEIG ELECTRONIC GmbH assumes no responsibility for the use of any information contained in this document and makes no representation that they are free of patent infringement. FEIG ELECTRONIC GmbH does not convey any license under its patent rights nor the rights of others.



General Information Regarding this Document

Aim and Target Audience

This document is intended for users (e.g. in logistics and assembly) of the ID HyWEAR compact. It contains step-by-step instructions that explain the basic functions to make working with the ID HyWEAR compact as easy as possible. No prior experience is required.

Configuration

The instructions given in this user guide are based on the reader settings defined ex works. It is possible to configure own settings, therefore see 10.5 Configuration.



Contents

9	Operating Elements	18
8	Assembly	17
	7.3.1 Laser	
7.3	Optical	16
	7.2.2 Housing	
	7.2.1 Fingerless Glove	
7.2	Mechanical	16
	7.1.2 Scanner Unit	
	7.1.1 Battery	
7.1	Electrical	
7	Components	16
6	Technical Data	15
	5.3.2 USA (FCC)	14
	5.3.1 Europe (CE)	14
5.3	Approvals	14
5.2	Intended Use	13
5.1	Product Illustration	12
5	Product Description	12
4	Scope of Delivery	11
3.2	Applications	10
3.1	The ID HyWEAR compact	10
3	Introduction	10
2	Revision History of Documentation	9
1	Safety Instructions	8

Operating Elements 9

9.1	LEDs			
9.2	Buzzer			
9.3	Vibration Feedback			
9.4	Trigger Button18			
9.5	Left But	ton		
9.6	Right B	utton		
10	Operati	ion	19	
10.1	Chargin	g the Battery		
	10.1.1	Charging via ID HyWEAR Charging Station		
	10.1.2	Charging via USB-C		
10.2	Powerin	ng Up the ID HyWEAR compact		
10.3	Connec	ting to Host		
	10.3.1	Establishing a WiFi Connection		
	10.3.2	Establishing a Bluetooth Connection		
10.4	Scannin	ng		
10.5	Configu	ration		
10.6	Powerin	ng Down the ID HyWEAR compact		
10.7	Reset to	Default		
	10.7.1	Controller Reset		
	10.7.2	Complete Parameter Reset		
11	Configu	uration Parameters	24	
11.1	Device \$	Settings	24	
	11.1.1	Device ID	24	
	11.1.2	Auto-Power-Off	24	
	11.1.3	Response Timeout		
11.2	RFID Settings			
	11.2.1	Regulation		
	11.2.2	RF Power		
	11.2.3	RSSI Filter		
	11.2.4	TR-Response-Time		
11.3	Scan Se	ettings		



	11.3.1	Scan-Time RFID	. 27
	11.3.2	Scan-Time Barcode	. 27
	11.3.3	Scan Engine	. 27
	11.3.4	Scan Interface	. 27
	11.3.5	IDD	. 28
	11.3.6	Input Events	. 28
	11.3.7	Scanner ID	. 28
11.4	Bluetooth	n Settings	. 29
	11.4.1	Bluetooth Destination Address	. 29
	11.4.2	Bluetooth PIN	. 29
	11.4.3	Bluetooth Device Name	. 29
11.5	WiFi Sett	ings	. 30
	11.5.1	Frequency Band	. 30
	11.5.2	DHCP	. 30
	11.5.3	IP Address	. 30
	11.5.4	Port Number	. 30
	11.5.5	Subnet Mask	. 31
	11.5.6	Gateway Address	. 31
	11.5.7	DNS1	. 31
	11.5.8	DNS2	. 31
	11.5.9	SSID	. 31
	11.5.10	WPA2 Key	. 32
	11.5.11	EAP Method	. 32
	11.5.12	EAP Inner Method	. 32
	11.5.13	EAP User ID	. 32
	11.5.14	EAP Password	. 33
	11.5.15	EAP Opportunistic Key Caching (OKC)	. 33
	11.5.16	Host Connection Mode	. 33
	11.5.17	Host IP Address	. 33
	11.5.18	Hostname	. 34
	11.5.19	Host Port Number	. 34
11.6	Indicator	Settings	. 34
	11.6.1	Buzzer Signalization	. 34



	11.6.2	Vibration Feedback Signalization	34		
11.7	Button Settings				
	11.7.1	Unlock Trigger Button	35		
	11.7.2	Left Button Power-Off	35		
	11.7.3	Right Button Power-Off	35		
	11.7.4	Left Button Function	35		
	11.7.5	Right Button Function			
12	Trouble	shooting	37		
13	Mainter	nance and Cleaning	38		
13.1	Cleaning the Lense				
13.2	2 Contacts				
13.3	Fingerless Glove and Battery				
14					
••	Decom	missioning	39		
15	Decom Dispos	missioning al	39 40		



1 Safety Instructions

- Please read this user guide carefully and follow the given instructions and safety instructions before using the device.
- ► The device may only be used for the intended purpose designed by the manufacturer.
- ► This user guide should be conveniently kept available at all times for each user.
- Unauthorized changes and the use of spare parts and additional devices which have not been sold or recommended by the manufacturer may cause fire, electric shocks or injuries. Such unauthorized measures shall exclude any liability by the manufacturer.
- ► The liability-prescriptions of the manufacturer in the issue valid at the time of purchase are valid for the device. The manufacturer shall not be held legally responsible for inaccuracies, errors, or omissions in the manual or automatically set parameters for a device or for an incorrect application of a device.
- ► Repairs may only be executed by the manufacturer.
- ► Installation, operation and maintenance procedures should only be carried out by qualified personnel.
- Use of the device and its installation must be in accordance with national legal requirements and local electrical codes.
- ► When working on devices the valid safety regulations must be observed.
- Use of controls or adjustments or performance of procedures other than those specified herein may result in exposure to hazardous visible laser light. The laser scanner utilizes a low-power laser diode. Although staring directly at the laser beam momentarily causes no known biological damage, avoid staring into the beam as one would with any very strong light source, such as sunlight. Avoid that the laser beam hits the eye of an observer, even through reflective surfaces like mirrors, etc.



$P \le 1 \text{ mW}$ $\lambda = 663 \text{ nm}$

- Do not crush, puncture, short circuit or place the LiPo battery in fire or water. To reduce the risk of fire or burns, do not attempt to open, disassemble, or service the battery pack. Do not expose the unit to temperatures above 60 °C (140 °F). Only charge the battery with the battery charger intended by the manufacturer. Do not deep discharge the battery. Do not use damaged batteries.
- Switch off your wireless device whenever you are instructed to do so by airport or airline staff. Consult airline staff and ask for the device's use in-flight.
- Wireless devices may affect medical electrical equipment. Therefore they should be switched off wherever you are requested to do so in hospitals or healthcare facilities to prevent interference with sensitive medical equipment.
- ► It is recommended by pacemaker manufacturers to maintain a minimum of 15 cm (6") between a handheld wireless device and a pacemaker to avoid potential interference. Therefore persons with pacemakers should not carry the device in a breast pocket. These recommendations are consistent with independent research and recommendations by Wireless Technology Research. If you have any reason to suspect that interference is taking place, turn off your device.
- ► Do not take note or use the device while driving. When driving a vehicle, driving is your first responsibility, therefore give full attention to driving.
- RF signals may affect improperly installed or inadequately shielded electronic systems in motor vehicles.
 You should consult the manufacturer of any equipment that has been added to your vehicle.
- ► Do not place the device in the area over the air bag or in the air bag deployment area. Improperly installed wireless equipment could result in serious injury when the air bag inflates.
- Observe restrictions on the use of radio devices in fuel depots, chemical plants and areas where the air contains chemicals or particles such as grain, dust or metal powder as well as any other area where you are advised to turn off your vehicle engine.



2 Revision History of Documentation

Revision	Date	Description	
2	20.09.2019	Approval for Canada (IC) removed	
1	04.09.2019	FCC and IC approval notice supplemented	
		Illustration added to "Intended Use"	
0	08.02.2019	Initial version	



3 Introduction

3.1 The ID HyWEAR compact

The ID HyWEAR compact is the combination of a small RFID- and barcode scanner and a comfortable, ergonomic fingerless glove that allows fingers, hand and arm to move freely. The ID HyWEAR compact is easy to use with and without gloves and the exchangeable high-capacity rechargeable battery allows long use. It is equipped with the latest wireless technology (Bluetooth, WiFi 2.4G/5G with roaming function), clearly visible LEDs, buzzer, vibration function and a robust housing.

The ID HyWEAR compact is developed and manufactured in Germany.

3.2 Applications

With hands-free use and wireless connection to the host system, the ID HyWEAR compact is ideal for use in baggage handling, warehouse logistics, manufacturing and a variety of other applications. Its small size allows work to be carried out even on narrow parts and machines.



4 Scope of Delivery

The scope of delivery includes following components:



After unboxing please make sure, that all listed parts have been delivered properly and in good condition.



5 Product Description

5.1 **Product Illustration**



Fig. 1: Product illustration - scanner unit



Fig. 2: Product illustration - fingerless glove



5.2 Intended Use

The ID HyWEAR compact is designed to read 1D and 2D barcodes as well as RFID tags in the frequency bands 865 MHz to 868 MHz (EU version) and 902 MHz to 928 MHz (FCC version).



Fig. 3: Intended use of the ID HyWEAR compact



5.3 Approvals

5.3.1 Europe (CE)

This equipment is intended to be commercialized in all the countries of the European Union and there is no commercialization or operational restrictions in any of the countries.

Hereby, FEIG ELECTRONIC GmbH declares that this Bluetooth, Wi-Fi barcode scanner is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

CE

Performance Classification according to ETSI EN 301 489: Class 2

5.3.2 USA (FCC)

Product name:	ID HyWEAR compact		
FCC ID:	PJMHYWCMPCT		
Notice for USA	This device complies with Part 15 of the FCC Rules.		
	Operation is subject to the following two conditions.		
	(1) this device may not cause harmful interference, and		
	(2) this device must accept any interference received,		
	including interference that may cause undesired operation.		
	Unauthorized modifications may void the authority granted under Federal communications Commission Rules permitting the operation of this device.		
	This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.		
	This equipment complies with FCC RF exposure limits set forth for an uncontrolled environment. The equipment must not be co-located or operating in conjunction with any other antenna or transmitter.		
	The wireless device should be used in accordance with the instructions in the User Guide.		

(i) NOTE:

Changes or modifications made to this equipment not expressly approved by FEIG ELECTRONIC GmbH may void the FCC authorization to operate this equipment.



6 Technical Data

Mechanical Data			
Housing	Robust ABS		
Dimension (W x H x D)	60 mm x 50 mm x 23 mm (2.36" x 1.97" x 0.91")		
Weight	70 g		
Protection Class	IP 54		
Color	black (translucent), red		
Electrical Data			
Operating Frequency			
EU Version	865 MHz to 868 MHz		
FCC Version	902 MHz to 928 MHz		
Supported Transponders	EPC Class 1 Gen 2		
Barcode	1D: EAN-8, EAN-13, UPC-A, UPC-E Code 128, Code 39, Code 93, Interleaved 2of5, Codabar, Codablock_F 2D: DataMatrix, QR Code, PDF417		
Interfaces			
• WiFi	2.4 GHz / 5 GHz (IEEE 802.11 a/b/g/n/h),WPA2-PSK, WPA2 Enterprise		
Bluetooth	5.0, SPP		
Battery	1000 mAh Lithium Polymer, 3.7 V		
Indicators	High power feedback LEDs (green/red) Status LEDs (blue/yellow) Buzzer Vibration feedback		
Environmental Conditions			
Temperature Range			
Operation	0 °C up to 55 °C		
Storage	-25 °C up to 85 °C		
Humidity	5 % up to 95 % (non-condensing)		
Drop	1.5 m drop to concrete		
Standard Compliance			
Radio Approval			
• Europe	EN 302 208, EN 300 328		
• USA	FCC 47 CFR Part 15		
EMC	EN 301 489		
Safety			
Low Voltage	EN 62368		
Human Exposure EN 50364			
Laser (Class 2)	EN 60825		
Others	RoHS, WEEE		



7 Components

7.1 Electrical

7.1.1 Battery

The rechargeable battery for the ID HyWEAR compact is a LiPo battery.

WARNING:

To reduce the risk of fire, explosion and burns:

- Do not crush, puncture, short circuit the battery or place it in fire or water!
- Do not attempt to open, disassemble or service the battery!
- Only charge the battery with the ID HyWEAR Charging Station!
- Do not deep discharge the battery!
- Do not use damaged batteries!
- Do not expose the battery to temperatures above 60 °C (140 °F)!
- Do not charge the battery below 0 °C (32 °F)!

7.1.2 Scanner Unit

The electronics of the scanner unit are protected by the housing and must not be disassembled.

7.2 Mechanical

7.2.1 Fingerless Glove

The fingerless glove is made of textile and therefore is durable but still comfortable to wear. The fingerless glove can be adjusted using the Velcro strips on the wrist and index finger. The scanner unit is slid into the provided pocket and fixed by means of a Velcro strip. Ensure that the contacts are connected propery.

7.2.2 Housing

The housing is made of robust ABS and is IP54 classified.

7.3 Optical

7.3.1 Laser

The installed laser for reading 1D and 2D barcodes is a class 2 laser. The laser has a power of \leq 1 mW. The wavelength is 663 nm.

WARNING:

To prevent damage through laser light:

- Do not attempt to open, disassemble or service the laser or the housing!
- Do not stare directly into the laser beam!
- Avoid that the laser hits the eye of an observer, even through reflective surfaces like mirrors, etc.



8 Assembly

1. Slide the battery into the fixture on the underside of the scanner unit until it is fixed by the clip.



2. Slide the scanner unit into the designated pocket on the top of the fingerless glove and connect the electronics using the two snaps. Ensure that the scanner unit is firmly attached to the glove.

3. Close the lug with the Velcro strip to secure the scanner unit in place.





9 Operating Elements

9.1 LEDs

The ID HyWEAR compact is equipped with five LEDs (see chapter 5.1 Product Illustration on page 12.). The charging status LED indicates if the ID HyWEAR compact is charged via a USB connection.

No USB Connection (Default)

LED	green	yellow	red	blue
ction	0,5 s tag/barcode read	on until tag/barcode is read or timeout <i>scanning</i>	0,5 s no tag/barcode read	1 Hz connection establishment
Ā			4 Hz for 4 s timeout server	every 3 s for 0,2 s connection OK

9.2 Buzzer

By default, the buzzer is deactivated. You can configure the buzzer via "HyWEAR Config Tool".

For an overview of the configuration possibilities, see chapter 11 Configuration Parameters on page 24.

9.3 Vibration Feedback

By default, the vibration feedback is deactivated. You can configure the vibration feedback via "HyWEAR Config Tool".

For an overview of the configuration possibilities, see chapter 11 Configuration Parameters on page 24.

9.4 Trigger Button

Pushing the trigger button on the fingerless glove activates the scanner for a limited, configurable time (SCAN-TIME; default 3 s).

9.5 Left Button

By default, the left button has no function. You can configure the button via "HyWEAR Config Tool". For an overview of the configuration possibilities, see chapter 11 Configuration Parameters on page 24.

9.6 Right Button

By default, the right button has no function. You can configure the button via "HyWEAR Config Tool". For an overview of the configuration possibilities, see chapter 11 Configuration Parameters on page 24.



10 Operation

The instructions given in this user guide are based on the settings defined ex works. It is possible to configure own settings, therefore see chapter 10.5 Configuration on page 23.

10.1 Charging the Battery

Before initial operation, the battery should be fully charged. This can be done either via the supplied USB-C cable or via the ID HyWEAR Charging Station. As long as the battery is charging via USB-C, the charging status LED lights up yellow. If the ID HyWEAR compact is charged when switched off, the blue LED starts flashing simultaneously to signal the connection establishment. If the battery is fully charged, the charging status LED goes out. If the battery is completely discharged, the yellow LED flashes every 3 seconds for 0.2 seconds.

(i) NOTE:

The battery temperature must not exceed 45 °C (113 °F). Therefore, charge batteries only in the temperature range from 0 °C to 40 °C (32 °F to 104 °F).

10.1.1 Charging via ID HyWEAR Charging Station

The high quality ID HyWEAR Charging Station is part of the accessories of the ID HyWEAR compact and is supplied with it. Up to four batteries can be charged simultaneously. The charging status is indicated by a status LED. The blue LED indicates that the ID HyWEAR Charging Station is supplied with power. Thanks to the latest technology, overcharging of the batteries is impossible. Due to the rubberized underside of the charging station, it can also be placed on smooth surfaces without slipping. It is also possible to mount the charging station on a wall.

To charge the battery:

- 1. Press the clip on the lower side of the ID HyWEAR compact to release the battery.
- 2. Carefully slide the battery out of the guide rail.
- 3. Place the battery in the charging slot with the contacts facing down.
- 4. Ensure the battery is placed properly.
- 5. Ensure the ID HyWEAR Charging Station is plugged in. To connect the power plug to the ID HyWEAR Charging Station, it is necessary to bend the cable slightly (do not kink!).
- 6. To remove the battery, pull the battery release clip.

Complete charging takes approx. 2 hours. Use only the charging station provided by FEIG ELECTRONIC.







The ID HyWEAR Charging Station has a power LED and a charging LED for each slot that indicates the charging state of the inserted battery. For the different statuses of the LED, see the table below.

State	Description	
Power LED off	The charging station is not supplied with power.	
Power LED blue The charging station is supplied with power.		
Charging LED off	No battery inserted in the battery charging slot.	
Charging LED red The inserted battery is charging.		
Charging LED green	green The inserted battery is fully charged.	

Table 1: LED states



10.1.2 Charging via USB-C

To charge the ID HyWEAR compact via USB-C, connect it to a PC or laptop using the supplied USB-C cable. With a suitable adapter, you can also charge the device via a power outlet using the USB-C cable.



Fig. 5: Charging via USB-C

10.2 Powering Up the ID HyWEAR compact

To power up the ID HyWEAR compact, press and hold one of the three buttons for 2 seconds. As soon as you switch on the ID HyWEAR compact, the blue status LED starts flashing, indicating the attempt to establish a connection.



10.3 Connecting to Host

The flashing blue LED after power-up means that the ID HyWEAR compact is seeking a connection. As long as no connection to the host has been established, scanning is not possible.

10.3.1 Establishing a WiFi Connection

To connect the ID HyWEAR compact to a host via WiFi an access point is needed. Make sure that both devices, ID HyWEAR compact and the WiFi access point, have the same settings. For more information refer to see chapter 11.5 WiFi Settings on page 30.

The following figure explains how to connect the ID HyWEAR compact via WiFi.



Fig. 6: Establishing a WiFi connection

For detailed information, please refer to the Application Note in the FEIG download area, using the following link and login data:

https://www.feig.de/en/login

Username: hywear-compact Password: hywear



10.3.2 Establishing a Bluetooth Connection

Before attempting to connect the ID HyWEAR compact to a host, e.g. a tablet or smartphone, via Bluetooth make sure that both devices have the same settings. For more information refer to see chapter 11.4 Bluetooth Settings on page 29.

The following figure illustrates how to connect the ID HyWEAR compact via Bluetooth.



Fig. 7: Establishing a Bluetooth connection

For detailed information, please refer to the Application Note in the FEIG download area, using the following link and login data:

https://www.feig.de/en/login

Username: hywear-compact Password: hywear





10.4 Scanning

To scan a barcode or an RFID tag, aim at the target and press the trigger button. You can configure the scan engine via "HyWEAR Config Tool".

After pressing the trigger button, the ID HyWEAR compact tries to read a barcode or an RFID tag for 3 seconds. During this time, the yellow LED is lighting up constantly. If the scan was successful, the green LED lights up. In case of an unsuccessful scan, the red LED lights up.

10.5 Configuration

To configure the ID HyWEAR compact the software "HyWEAR Config Tool" is required, which can be obtained from the FEIG ELECTRONIC download area. Please use the login data, which you can find in the manual. For the different configuration parameters, see chapter 11 Configuration Parameters on page 24.

10.6 Powering Down the ID HyWEAR compact

The ID HyWEAR compact automatically powers down after the parameter AUTO-POWER-OFF (default setting: 600 s) has been lapsed and no button was pressed or if a connection could not be made within 60 s.

To manually power down the device, press either the left or the right button for 5 seconds and wait until all 4 LEDs light up, then release the button. The LEDs go out after 4 seconds and you hear a beep, indicating that the ID HyWEAR compact powers down.

10.7 Reset to Default

10.7.1 Controller Reset

To perform a controller reset, press and hold the left button and the right button for 5 seconds. Fast repeated flashing of the 4 LEDs and a beep at the end signal the start of the controller reset.

10.7.2 Complete Parameter Reset

To perform a complete parameter reset, press and hold the trigger button, left button and right button for 5 seconds within the first 30 seconds after powering up the ID HyWEAR compact. The start of the complete parameter reset is signaled by the flashing of the 4 LEDs in the sequence blue-red-yellow-green (twice) and a beep at the end.

(i) NOTE:

After a complete parameter reset all user configured parameters will be lost.



11 Configuration Parameters

Via the configuration parameters, various settings can be made, e.g. assigning a device ID, selecting different scan settings or options for the connection to the host. To configure the ID HyWEAR compact the software "HyWEAR Config Tool" is required, which can be obtained from the FEIG ELECTRONIC download area. Please use the login data, which you can find in the manual.

11.1 Device Settings

11.1.1 Device ID

Logical Name					
Device.Identifier.ScannerID					
Description Unique ID that can be assigned by the user. The printable ASCII characters: !"#\$%&'()*+,/0123456789:;<=>? @ABCDEFGHIJKLMNOPQRSTUVWXYZ[\]^_ `abcdefghijkImnopqrstuvwxyz{ }~	e ID can have a maximu	m length of 29 bytes and	d may only consist of		
Possible Values	Default Value	Unit -	Reset Required		

11.1.2 Auto-Power-Off

Logical Name PowerManagement.AutoPowerOff					
Description Defines the timespan after which the reader automatically switches off. The timespan is always re-triggered when the trigger button is pressed and a new scan process is started. In Continuous Read Mode the timespan is re-triggered every time a tag or barcode is read. If the parameter is set to "65535", the reader will stay on.					
Possible Values 165535	Default Value 600	Unit S	Reset Required Hard		

11.1.3 Response Timeout

Logical Name OperatingMode.ScanMode.Transmission.Timeout						
Description Defines the timeout for a response from the host.						
Possible ValuesDefault ValueUnitReset Required12553SHard						



11.2 RFID Settings

11.2.1 Regulation

Logical Name

AirInterface.Region.UHF.Regulation

Description

Defines the region specific behavior according to the RF regulations. For a detailed description of the individual countries' affiliation to the regions and their frequency bands.

The region is set up ex factory. Changing the region from EU to FCC and vice versa is only possible with an activation code.

If region = EU, only EU frequencies can be set. If region = FCC, only FCC frequencies can be set.

Possible Values	Default Value	Unit	Reset Required
0x04: FCC: America	0x06 (EU)	-	Hard
0x14: FCC: China	0x04 (FCC)		
0x24: FCC: Australia/New Zealand			
0x34: FCC: Brazil			
0x44: FCC: Israel			
0x54: FCC: Japan			
0x64: FCC: Malaysia			
0x06: EU: Europe			
0x16: EU: Asia/Arabia			
0x26: EU: Russia			
0x36: EU: Africa			
0x46: EU: India			
0x56: EU: Morocco			

11.2.2 RF Power

Logical Name AirInterface.Antenna.UHF.No1.OutputPower				
Description Defines the RF output power.				
Possible Values 0x00: Low 0x01: Middle 0x02: High	Default Value 0x02	Unit -	Reset Required Hard	

11.2.3 RSSI Filter

Logical Name AirInterface.Antenna.UHF.No1.RSSIFilter				
Description Defines the RSSI (Received Signal Strength Ind the RSSI filter value, the more weak transponde Typical values: 30 to 70 dBm.	dicator) filter level. A high er signals are rejected.	ner value increases the s	ensitivity. The lower	
Possible Values 0255	Default Value 0 (= disabled)	Unit -dBm	Reset Required	



11.2.4 TR-Response-Time

Logical Name AirInterface.TimeLimit			
Description Defines the maximum duration for the transpond At the latest after the TR-RESPONSE-TIME has commands between reader and transponder are Error" will appear.	der command. It starts at s elapsed the reader will e aborted. If the time is to	fter the reader has receiv send an answer protoco oo short the status "0x83	ved a new command. II. In this case, current B RF Communication
Possible Values 165535	Default Value 10	^{Unit} * 100 ms	Reset Required



11.3 Scan Settings

11.3.1 Scan-Time RFID

Logical Name AirInterface.ScanTime				
Description Defines the timespan the reader scans for an RFID tag.				
Possible Values 165535	Default Value 5	^{Unit} * 10 ms	Reset Required Soft	

11.3.2 Scan-Time Barcode

Logical Name Barcode.ScanTime				
Description Defines the timespan the reader scans for a barcode.				
Possible Values 1255	Default Value 30	^{Unit} * 100 ms	Reset Required Soft	

11.3.3 Scan Engine

Logical Name OperatingMode.ScanMode.DataSource.Engine				
Description Defines the engine from which data is to be read. If two engines are selected, the second engine is used only when the first engine timed out. The default value depends on the version of the reader.				
Possible Values 0x0001: RFID first, Barcode second 0x00FF: RFID only 0x01FF: Barcode only	Default Value 0x0001	Unit -	Reset Required Hard	

11.3.4 Scan Interface

Logical Name OperatingMode.ScanMode.Interface				
Description Defines the interface, which is used to send the scanned data to the host. The demo mode is for demonstration purposes only. It allows scanning without an active Bluetooth or WiFi connection. The status of a scan is indicated by the outputs (vibrator/buzzer/LED).				
Possible Values 0x00: Demo 0x01: Bluetooth SPP 0x02: Bluetooth HID 0x11:WiFi	Default Value 0x02	Unit -	Reset Required Hard	



11.3.5 IDD

Logical Name OperatingMode.ScanMode.DataSelector.IDD				
Description This configuration flag defines if RFID or barcode data will be part of the scan event data. The max. length for barcode is limited to 200 bytes by the buffer.				
Possible Values b0: IDD disabled b1: IDD enabled	Default Value b1	Unit -	Reset Required Soft	

11.3.6 Input Events

Logical Name OperatingMode.ScanMode.DataSelector.InputEvents				
Description This configuration flag defines if input states (button and trigger states) will be part of the scan event data.				
Possible Values b0: Input states disabled b1: Input states enabled	Default Value b0	Unit -	Reset Required Soft	

11.3.7 Scanner ID

Logical Name OperatingMode.ScanMode.DataSelector.ScannerID				
Description This configuration flag defines if the Scanner ID will be part of the scan event data.				
Possible Values Default Value Unit Reset Required b0: Scanner ID disabled b0 - Soft				



11.4 Bluetooth Settings

11.4.1 Bluetooth Destination Address

Logical Name HostInterface.Bluetooth.DestinationAddress				
Description Defines the Bluetooth destination address to which the connection is to be established. The Bluetooth destination address may only consist of the following hexadecimal characters: 0-9, A-F Example: 12:34:56:78:9A:BC				
Possible Values	Default Value	Unit -	Reset Required Hard	

11.4.2 Bluetooth PIN

Logical Name HostInterface.Bluetooth.PIN				
Description Defines the Bluetooth PIN for pairing. The PIN of printable ASCII characters: !"#\$%&'()*+,/0123456789:;<=>? @ABCDEFGHIJKLMNOPQRSTUVWXYZ[\]^_ `abcdefghijkImnopqrstuvwxyz{ }~	can have a length of up t	o 15 characters and may	/ only consist of	
Possible Values	Default Value 1234	Unit -	Reset Required Hard	

11.4.3 Bluetooth Device Name

Logical Name HostInterface.Bluetooth.DeviceName				
Description Defines the name of the Bluetooth device. The printable ASCII characters: !"#\$%&'()*+,/0123456789:;<=>? @ABCDEFGHIJKLMNOPQRSTUVWXYZ[\]^_ `abcdefghijkImnopqrstuvwxyz{ }~ The DID is the unique device identifier as decim	name can have a maxim nal digit.	um length of 31 bytes ar	nd may only consist of	
Possible Values	Default Value HyWEAR_+SNR	Unit -	Reset Required Hard	



11.5 WiFi Settings

11.5.1 Frequency Band

Logical Name HostInterface.WLAN.FrequencyBand				
Description Defines the frequency band used.				
Possible Values	Default Value	Unit	Reset Required	
0x00: 2.4 GHz	0x00	-	Hard	
0x01: 5 GHz				
0x02: 2.4 and 5 GHz (Dual Band)				

11.5.2 DHCP

Logical Name HostInterface.WLAN.IPv4.Enable_DHCP				
Description Enables or disables DHCP for WiFi connection. If DHCP is disabled, a static IP address is used.				
Possible Values Default Value Unit Reset Required b0: Disabled b1 - Hard b1: Enabled - - -				

11.5.3 IP Address

Logical Name HostInterface.WLAN.IPv4.IPAddress				
Description Defines the IP address for WiFi connection.				
Possible Values	Default Value 0.0.0.0	Unit -	Reset Required Hard	

11.5.4 Port Number

Logical Name HostInterface.WLAN.IPv4.PortNumber				
Description Defines the port number for WiFi connection.				
Possible Values 065553	Default Value 10002	Unit -	Reset Required Hard	



11.5.5 Subnet Mask

Logical Name HostInterface.WLAN.IPv4.SubnetMask			
Description Defines the subnet mask for WiFi connection.			
Possible Values	Default Value 255.255.255.0	Unit -	Reset Required Hard

11.5.6 Gateway Address

Logical Name HostInterface.WLAN.IPv4.GatewayAddress				
Description Defines the gateway address for WiFi connection.				
Possible Values	Default Value 0.0.0.0	Unit -	Reset Required Hard	

11.5.7 DNS1

Logical Name HostInterface.WLAN.IPv4.DNS1				
Description Defines the IP address of the 1st name server.				
Possible Values	Default Value 0.0.0.0	Unit -	Reset Required Hard	

11.5.8 DNS2

Logical Name HostInterface.WLAN.IPv4.DNS2				
Description Defines the IP address of the 2nd name server.				
Possible Values	Default Value 0.0.0.0	Unit -	Reset Required Hard	

11.5.9 SSID

Logical Name HostInterface.WLAN.Security.ServiceSetIdentifier.SSID					
Description Defines the name of the network. The name can have a maximum length of 32 bytes and may only consist of printable ASCII characters: !"#\$%&'()*+,/0123456789:;<=>? @ABCDEFGHIJKLMNOPQRSTUVWXYZ[\]^_ `abcdefghiikImnopgrstuvwxyz{ }~					
Possible Values	Default Value	Unit -	Reset Required Hard		
PANMOBIL portable solutions by FEIG ELECTRONIC			Page 31 of 41		

11.5.10 WPA2 Key

Logical Name HostInterface.WLAN.Security.WPA2.Key			
Description Defines the pre-shared key for WPA2. The key printable ASCII characters: !"#\$%&'()*+,/0123456789:;<=>? @ABCDEFGHIJKLMNOPQRSTUVWXYZ[\]^_ `abcdefghijkImnopqrstuvwxyz{ }~	can have a maximum ler	ngth of 61 bytes and ma	y only consist of
Possible Values	Default Value	Unit -	Reset Required Hard

11.5.11 EAP Method

Logical Name HostInterface.WLAN.Security.EAP.Method						
Description Defines the outer EAP (Extensible Authentication Protocol) method, meaning the process of creating a secure channel. If EAP is enabled, the parameter WIFI-WPA2 is irrelevant.						
Possible Values 0x00: EAP disabled 0x01: TLS 0x02: TTLS 0x03: FAST 0x04: PEAP	Possible Values Default Value Unit Reset Required 0x00: EAP disabled 0x00 (EAP disabled) - Hard 0x01: TLS 0x02: TTLS 0x03: FAST 0x04: PEAP					

11.5.12 EAP Inner Method

Logical Name HostInterface.WLAN.Security.EAP.InnerMethod				
Description Defines the inner EAP (Extensible Authentication Protocol) method, meaning the actual authentication process.				
Possible Values 0x00: MSCHAP 0x01: MSCHAPV2	Default Value 0x01 (MSCHAPV2)	Unit -	Reset Required Hard	

11.5.13 EAP User ID

Logical Name HostInterface.WLAN.Security.EAP.UserID			
Description Defines the user ID for EAP (Extensible Authen and may only consist of printable ASCII charact !"#\$%&'()*+,/0123456789:;<=>? @ABCDEFGHIJKLMNOPQRSTUVWXYZ[\]^_ `abcdefghijkImnopqrstuvwxyz{ }~	tication Protocol). The us ers:	ser ID can have a maxim	num length of 16 bytes
Possible Values	Default Value	Unit -	Reset Required Hard



11.5.14 EAP Password

Logical Name HostInterface.WLAN.Security.EAP.UserPassword				
Description Defines the user password for EAP (Extensible 16 bytes and may only consist of printable ASC !"#\$%&'()*+,/0123456789:;<=>? @ABCDEFGHIJKLMNOPQRSTUVWXYZ[\]^_ `abcdefghijklmnopqrstuvwxyz{ }~	Authentication Protocol) II characters:	. The password can hav	e a maximum length of	
Possible Values	Default Value	Unit -	Reset Required Hard	

11.5.15 EAP Opportunistic Key Caching (OKC)

Logical Name HostInterface.WLAN.Security.EAP.Enable_OKC					
Description Enables or disables opportunistic key caching (OKC), which decreases the time needed for authentication.					
Possible Values Default Value Unit Reset Required					
b0: Disabled	b0	-	Hard		
b1: Enabled					

11.5.16 Host Connection Mode

Logical Name OperatingMode.ScanMode.Transmission.Destination.Mode				
Description Defines the mode for the connection to the host.				
Possible Values Default Value Unit Reset Required 0x00: Connect by IP address 0x00 - Hard 0x01: Connect by hostname - - -				

11.5.17 Host IP Address

Logical Name OperatingMode.ScanMode.Transmission.Destination.IPv4.IPAddress				
Description Defines the destination address of the host by IP address.				
Possible Values	Default Value 0.0.0.0	Unit -	Reset Required Hard	



11.5.18 Hostname

Logical Name OperatingMode.ScanMode.Transmission.Destination.IPv4.Hostname				
Description Defines the destination address of the host by r only consist of the following printable ASCII cha -0123456789 ABCDEFGHIJKLMNOPQRSTUVWXYZ abcdefghijklmnopqrstuvwxyz	name. The hostname car racters:	n have a maximum lengtl	h of 52 bytes and may	
Possible Values	Default Value	Unit -	Reset Required Hard	

11.5.19 Host Port Number

Logical Name OperatingMode.ScanMode.Transmission.Destination.PortNumber				
Description Defines the destination port of the host.				
Possible Values Default Value Unit Reset Required 065535 0 - Hard				

11.6 Indicator Settings

11.6.1 Buzzer Signalization

Logical Name DigitalIO.Signaler.Buzzer.ActivationSources				
Description Defines the actions which trigger the buzzer. Multiple selections are possible.				
Possible Values	Default Value	Unit	Reset Required	
Bit 0: Tag/Barcode is read	0x01 (Tag/Barcode is	-	None	
Bit 1: Trigger is pressed	read)			
Bit 2: Response timeout in server				
communication				

11.6.2 Vibration Feedback Signalization

Logical Name DigitalIO.Signaler.Vibrator.ActivationSources			
Description Defines the actions which trigger the vibrator. Multiple selections are possible.			
Possible Values	Default Value	Unit	Reset Required
Bit 0: Tag/Barcode is read	0x02 (Trigger is	-	None
Bit 1: Trigger is pressed	pressed)		
Bit 2: Response timeout in server			
communication			



11.7 Button Settings

11.7.1 Unlock Trigger Button

Logical Name DigitalIO.Button.Trigger.Enable_UnlockTrigger				
Description Defines if the scan function can be unlocked by pressing the trigger button. After unlocking, a new scan can be started. NOTE: The scan function can be locked by the host after a scan event.				
Possible Values Default Value Unit Reset Required b0: Trigger button cannot unlock the scan function b0 - None b1: Trigger button can unlock the scan function - - -				

11.7.2 Left Button Power-Off

Logical Name DigitalIO.Button.Left.Enable_PowerOff			
Description The device will be switched off when the left button is pressed for at least 5 seconds.			
Possible Values b0: Switch-off function disabled b1: Switch-off function enabled	Default Value b1	Unit -	Reset Required None

11.7.3 Right Button Power-Off

Logical Name DigitalIO.Button.Right.Enable_PowerOff			
Description The device will be switched off when the right button is pressed for at least 5 seconds.			
Possible Values b0: Switch-off function disabled b1: Switch-off function enabled	Default Value b1	Unit -	Reset Required

11.7.4 Left Button Function

Logical Name DigitalIO.Button.Left.Function			
Description Defines the function assignment for the left button. 0x00: The button has no function. 0x01: Unlocks the scan function 0x04: Starts a new scan. In Continuous Read Mode it also stops a scan. 0x20: Toggles the trigger mode between Single Read Mode and Continuous Read Mode.			
Possible Values 0x00: No function 0x01: Unlock scan function 0x04: Start/Stop scan 0x20: Switch trigger mode	Default Value 0x04	Unit -	Reset Required



11.7.5 Right Button Function

Logical Name DigitalIO.Button.Right.Function			
Description Defines the function assignment for the right button. 0x00: The button has no function. 0x01: Unlocks the scan function 0x04: Starts a new scan. In Continuous Read Mode it also stops a scan. 0x20: Toggles the trigger mode between Single Read Mode and Continuous Read Mode.			
Possible Values 0x00: No function 0x01: Unlock scan function 0x04: Start/Stop scan 0x20: Switch trigger mode	Default Value 0x00	Unit -	Reset Required None



12 Troubleshooting

Problem	Solution
I cannot connect the device via USB.	 Ensure that the connection cable is plugged in properly.
	 Ensure that the correct driver for the USB controller is installed.
The red LED flashes after successful reading of a barcode or an RFID tag.	• The connection between the device and the host has timed out. Check the connection.
The red LED lights up after trying to read a barcode or an RFID tag.	 The SCAN-TIME, the time the device is searching for a barcode or RFID tag, has expired without a barcode or RFID tag having been read. Press the trigger button and aim at a barcode or an RFID tag.
I cannot connect the device via WiFi.	Ensure that the host supports WiFi.
	Check WiFi settings.



13 Maintenance and Cleaning

13.1 Cleaning the Lense

To clean the lense use a clean and dry cleaning cloth. Do not use chemical cleaners, lyes or similar.

13.2 Contacts

To clean the contacts use a clean and dry cleaning cloth. Do not use chemical cleaners, lyes or similar.

13.3 Fingerless Glove and Battery

The fingerless glove and the battery are consumables and therefore wear parts. To clean the battery use clean and dry cleaning cloth. Do not use chemical cleaners, lyes or similar. Do not reuse a damaged battery!

The fingerless glove is hand washable.



14 Decommissioning

For prolonged decommissioning, disconnect the scanner unit from the fingerless glove and slide the scanner unit out of the pocket. Then remove the battery. Make sure to store the device dry and clean. The storage temperature should be between -25 °C and 85 °C.



15 Disposal



Never dispose of LiPo batteries in household waste! LiPo batteries can be disposed of at special collection points. Before disposal, make sure that the LiPo battery is completely discharged.

How to dispose of the electronics and the fingerless glove?



16 Warranty

FEIG ELECTRONIC warrants that the product will be free of defects in material and workmanship for 12 months from the date of shipment when used as intended. Battery and fingerless glove are not covered. FEIG ELECTRONIC will, at its option, either repair or replace the defective products. Such repair or replacement shall be buyer's sole remedy in the event of manufacturer's breach of his limited warranty. Repaired or replaced parts or products may include new, reconditioned or remanufactured parts and equipment at manufacturer's option. All costs associated with shipment to FEIG ELECTRONIC for warranty service, including but not limited to freight, duties, insurance and custom fees, are buyer's responsibility. FEIG ELECTRONIC will pay the freight costs (duties, insurance, customs and any other fees) associated with the return shipment to the buyer. The method of shipment will be at the manufacturer's discretion. Repair or replacement of any parts or equipment does not extend the period of warranty provided for herein.

THIS LIMITED WARRANTY IS THE MANUFACTURER'S ONLY WARRANTY. FEIG ELECTRONIC DOES NOT GIVE WARRANTIES OF MERCHANTABILITY OR WARRANTIES OF FITNESS FOR A PARTICULAR PURPOSE.

To take advantage of this warranty, the buyer should contact the seller not the manufacturer. The warranty set forth herein does not cover and FEIG ELECTRONIC will have no obligations hereunder if any nonconformance is cause in whole or in part by accident, transportation, neglect, misuse, alteration, modification, or enhancement of the product or incorporation, interfacing, attachment of any feature, program, or device to the product by a person or entity other than the manufacturer, failure to provide a suitable installation environment, use of the product for other than the specific purpose for which the product is designed or any use of the product not in accordance with the User Guide or other misuse or abuse of the product. The warranty does not cover problems linked to batteries.

In case the product was bought directly from FEIG ELECTRONIC the buyer should refer to www.panmobil.com/rma.

Shipment Address:

FEIG ELECTRONIC GmbH Hansestrasse 91 D-51149 Cologne

