Correspondence Reference Number: 24018

731 Confirmation Number: EA691994

Revised Labels for Pat Motion Alert, with USA removed between FCC ID and QJRMA FCC QJRMA Ted Graef **Intuitive Control Systems** 10/1/02

PAT Motion Alert

Control Unit, Part Number 4000060

Input Voltage: 9-30 VDC
To place Control Unit into teach mode or change address: Press and hold mode and alarm buttons for 5 sec until alarm led starts flashing. Unit now in teach mode. Press mode button to change address, if desired. Press alarm button or wait 2 min to

automatically return to operating mode.

<u>To teach Beacon Control Unit address:</u> With Control Unit in teach mode, open signal unit and press learn button for 2 sec. 1 beep indicates learn mode, 3 beeps indicates address learned. 5 beeps indicate an error - repeat process.

FCC ID QJRMA

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.



PAT America, Inc. 1665 Orchard Dr Chambersburg, PA 17201 (717) 263-7655

PAT Motion Alert

Control Unit, Part Number 4000065

Input Voltage: 9 VDC, (Duracell MN 1604 or equiv.)
To place Control Unit into teach mode or change address: Press

and hold mode and alarm buttons for 5 sec until alarm led starts flashing. Unit now in teach mode. Press mode button to change address, if desired. Press alarm button or wait 2 min to automatically return to operating mode.

To teach Beacon Control Unit address: With Control Unit in teach

mode, open signal unit and press learn button for 2 sec. 1 beep indicates learn mode, 3 beeps indicates address learned. 5 beeps indicate an error - repeat process.

FCC ID QJRMA

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.



PAT America, Inc. 1665 Orchard Dr Chambersburg, PA 17201 (717) 263-7655

