

SI398 “Treat and Train” Operation Manual

Functional Description

1. To turn on the device, first apply the battery or AC adaptor to the unit, and then switch the On/Off switch to the ‘On’ side. To turn off the device, switch the On/Off switch to ‘Off’ side will turn off the unit.
2. When the power is on, the power led will turn on with green light and it will show red color when in low battery.
3. There are two modes of operation in this unit, which are Manual and Auto mode operation. Press the Dispense button on the remote control will start manual operation; the device will dispense a kibble and make a beep sound.
4. Press and hold the Dispense button will continuously dispense the kibble until you release the button.
5. Press the Session button on the remote control trigger auto operation. During auto operation, the session Led will be turned on. Press the Session button again will stop the auto operation.
6. There are three options in the Auto operation. They are Single treat; Multiple treat and Cue dispense. The slide switch next to the On/Off button can select these options. For single treat and multiple treat option, The machine will dispense treats at a regular or variable interval ranging from 3 seconds to 5 minutes. Single treat will dispense one kibble at a time and Multiple treats will dispense several kibbles at a time. For cue dispense option, it will only prompt to remind user to dispense kibble manually.
7. You can control the time interval for each treat by using a 12 positions dial. The table 1 shows all the timing for all setting. You can also choose between fix time interval or variable time interval by setting the slide switch on the bottom of the panel. When fixed interval is selected, the auto operation will last from one minute to five minutes. And if variable interval is selected, it will remain in auto operation until user press the session button to force it to stop.
8. There is a Infra red sensor to detect if the dog is in front of the machine, the dog sensor led will be on if a dog is detected and it will turn off if it is out of range. When this function is enable during auto operation, and the dog is out of range for several seconds, The auto operation will stop.
9. The volume slide switch allows you to change the volume.

- 10.** If the unit left idle for 30 minutes, it will go to Standby mode. The power led will be flashing. Press any button in the remote control will wake up the unit and start the corresponding function immediately.

Table 1: Time interval Settings

Setting	Fix interval (n)	Variable Lower Limit	Variable Upper Limit (2n-3)
1	3 sec	3 sec	3 sec
2	5 sec	3 sec	7 sec
3	7 sec	3 sec	11 sec
4	10 sec	3 sec	17 sec
5	15 sec	3 sec	27 sec
6	20 sec	3 sec	37 sec
7	25 sec	3 sec	47 sec
8	30 sec	3 sec	57 sec
9	45 sec	3 sec	87 sec
10	60 sec	3 sec	1 min 57 sec
11	2 min	3 sec	3 min 57 sec
12	5 min	3 sec	9 min 57 sec