

11. NUMBER OF HOPPING FREQUENCY

11.1. MEASUREMENT PROCEDURE

The EUT shall have its hopping function enabled. Use the following spectrum analyzer settings:

- 1. Span: The frequency band of operation. Depending on the number of channels the device supports, it may be necessary to divide the frequency range of operation across multiple spans, to allow the individual channels to be clearly seen.
- 2. RBW: To identify clearly the individual channels, set the RBW to less than 30% of the channel spacing or the 20 dB bandwidth, whichever is smaller.
- 3. VBW > RBW. Sweep: Auto. Detector function: Peak. Trace: Max hold.
- 4. Allow the trace to stabilize.

11.2. TEST SETUP (BLOCK DIAGRAM OF CONFIGURATION)

Same as described in section 8.2


11.3. MEASUREMENT EQUIPMENT USED

The same as described in section 6

11.4. LIMITS AND MEASUREMENT RESULT

TOTAL NO. OF	LIMIT (NO. OF CH)	MEASUREMENT (NO. OF CH)	RESULT
HOPPING CHANNEL	>=15	23	PASS

TEST PLOT FOR NO. OF TOTAL CHANNELS



The results spound this jest report refer only to the sample(s) tested unless otherwise stated and the sample(s) are retained for 30 days only. The document is issued by XCC, this document cannot be reproduced except in full with our prior written permission. The more details and the authenticity of the report will be confirmed at attp://www.ago.go.tt.com.

Attestation of Global Compliance

GC



Report No.: AGC00008180503FE03

Page 39 of 68

12. TIME OF OCCUPANCY (DWELL TIME)

12.1. MEASUREMENT PROCEDURE

The EUT shall have its hopping function enabled. Use the following spectrum analyzer settings:

- 1. Span: Zero span, centered on a hopping channel.
- 2. RBW shall be ≤channel spacing and where possible RBW should be set >> 1 / T, where T is the expected dwell time per channel.
- 3. Sweep: As necessary to capture the entire dwell time per hopping channel; where possible use a video trigger and trigger delay so that the transmitted signal starts a little to the right of the start of the plot. The trigger level might need slight adjustment to prevent triggering when the system hops on an adjacent channel; a second plot might be needed with a longer sweep time to show two successive hops on a channel.
- 4. Detector function: Peak. Trace: Max hold.
- 5. Use the marker-delta function to determine the transmit time per hop.
- 6. Repeat the measurement using a longer sweep time to determine the number of hops over the period specified in the requirements. The sweep time shall be equal to, or less than, the period specified in the requirements. Determine the number of hops over the sweep time and calculate the total number of hops in the period specified in the requirements, using the following equation:

(Number of hops in the period specified in the requirements) = (number of hops on spectrum analyzer) x (period specified in the requirements / analyzer sweep time)

7. The average time of occupancy is calculated from the transmit time per hop multiplied by the number of hops in the period specified in the requirements.

12.2. TEST SETUP (BLOCK DIAGRAM OF CONFIGURATION)

Same as described in section 8.2

12.3. MEASUREMENT EQUIPMENT USED

The same as described in section 6


12.4. LIMITS AND MEASUREMENT RESULT


Channel	Time of Pulse for DH5 (ms)	Number of hops in the period specified in the requirements	Sweep Time (ms)	Limit (ms)
Low	3.230	82.8	267.444	400
Middle	3.230	73.6	237.728	400
High	3.230	82.8	267.444	400

The results shown this jest report refer only to the sample(s) tested unless otherwise stated and the sample(s) are retained for 30 days only. The document is issued by KGC, this document cannot be reproduced except in full with our prior written permission. The more details and the authenticity of the report will be confirmed at Attp://www.agc-cett.com.



TEST PLOT OF LOW CHANNEL







The results spoured this jest report refer only to the sample(s) tested unless otherwise stated and the sample(s) are retained for 30 days only. The document is issued by XOC, this document cannot be reproduced except in full with our prior written permission. The more details and the authenticity of the report will be confirmed at attp://www.ago.go.tt.com.

Attestation of Global Compliance



TEST PLOT OF MIDDLE CHANNEL






The results spound this jest report refer only to the sample(s) tested unless otherwise stated and the sample(s) are retained for 30 days only. The document is issued by XCC, this document cannot be reproduced except in full with our prior written permission. The more details and the authenticity of the report will be confirmed at a true www.ago.gent.com.

Attestation of Global Compliance



TEST PLOT OF HIGH CHANNEL





The results spound this jest report refer only to the sample(s) tested unless otherwise stated and the sample(s) are retained for 30 days only. The document is issued by XCC, this document cannot be reproduced except in full with our prior written permission. The more details and the authenticity of the report will be confirmed at a true www.ago.gent.com.



13. FREQUENCY SEPARATION

13.1. MEASUREMENT PROCEDURE

The EUT shall have its hopping function enabled. Use the following spectrum analyzer settings:

- 1. Span: Wide enough to capture the peaks of two adjacent channels.
- 2. RBW: Start with the RBW set to approximately 30% of the channel spacing; adjust as necessary to best identify the center of each individual channel.
- 3. Video (or average) bandwidth (VBW) ≥ RBW.
- 4. Sweep: Auto. e) Detector function: Peak. f) Trace: Max hold. g) Allow the trace to stabilize.

Use the marker-delta function to determine the separation between the peaks of the adjacent channels.

13.2. TEST SETUP (BLOCK DIAGRAM OF CONFIGURATION)

Same as described in section 6.2

13.3. MEASUREMENT EQUIPMENT USED

The same as described in section 6.3

13.4. LIMITS AND MEASUREMENT RESULT

CHANNEL	CHANNEL SEPARATION	LIMIT	RESULT			
	KHz	KHz	Page 1			
CH09-CH10	2988	>=25 KHz or 2/3 20 dB BW	Pass			


TEST PLOT FOR FREQUENCY SEPARATION



The results spowford this jest report refer only to the sample(s) tested unless otherwise stated and the sample(s) are retained for 30 days only. The document is issued by AGC, this document cannot be reproduced except in full with our prior written permission. The more details and the authenticity of the report will be confirmed at attp://www.agc.gent.com.

Attestation of Global Compliance

GC





14. FCC LINE CONDUCTED EMISSION TEST


14.1. LIMITS OF LINE CONDUCTED EMISSION TEST

F	Maximum RF	Line Voltage
Frequency	Q.P.(dBuV)	Average(dBuV)
150kHz~500kHz	66-56	56-46
500kHz~5MHz	56	46
5MHz~30MHz	060	50

Note:

- 1. The lower limit shall apply at the transition frequency.
- 2. The limit decreases linearly with the logarithm of the frequency in the range 0.15 MHz to 0.50 MHz.

14.2. BLOCK DIAGRAM OF LINE CONDUCTED EMISSION TEST



The results spound this jest report refer only to the sample(s) tested unless otherwise stated and the sample(s) are retained for 30 days only. The document is issued by XCC, this document cannot be reproduced except in full with our prior written permission. The more details and the authenticity of the report will be confirmed at attp://www.ago.go.tt.com.



Report No.: AGC00008180503FE03 Page 45 of 68

14.3. PRELIMINARY PROCEDURE OF LINE CONDUCTED EMISSION TEST

- 1. The equipment was set up as per the test configuration to simulate typical actual usage per the user's manual. When the EUT is a tabletop system, a wooden table with a height of 0.8 meters is used and is placed on the ground plane as per ANSI C63.10 (see Test Facility for the dimensions of the ground plane used). When the EUT is a floor-standing equipment, it is placed on the ground plane which has a 3-12 mm non-conductive covering to insulate the EUT from the ground plane.
- 2. Support equipment, if needed, was placed as per ANSI C63.10.
- 3. All I/O cables were positioned to simulate typical actual usage as per ANSI C63.10.
- 4. All support equipments received AC120V/60Hz power from a LISN, if any.
- 5. The EUT received DC charging voltage by adapter which received 120V/60Hzpower by a LISN.
- 6. The test program was started. Emissions were measured on each current carrying line of the EUT using a spectrum Analyzer / Receiver connected to the LISN powering the EUT. The LISN has two monitoring points: Line 1 (Hot Side) and Line 2 (Neutral Side). Two scans were taken: one with Line 1 connected to Analyzer / Receiver and Line 2 connected to a 50 ohm load; the second scan had Line 1 connected to a 50 ohm load and Line 2 connected to the Analyzer / Receiver.
- 7. Analyzer / Receiver scanned from 150 kHz to 30MHz for emissions in each of the test modes.
- 8. During the above scans, the emissions were maximized by cable manipulation.
- 9. The test mode(s) were scanned during the preliminary test.

Then, the EUT configuration and cable configuration of the above highest emission level were recorded for reference of final testing.

14.4. FINAL PROCEDURE OF LINE CONDUCTED EMISSION TEST


- EUT and support equipment was set up on the test bench as per step 2 of the preliminary test.
- 2. A scan was taken on both power lines, Line 1 and Line 2, recording at least the six highest emissions. Emission frequency and amplitude were recorded into a computer in which correction factors were used to calculate the emission level and compare reading to the applicable limit. If EUT emission level was less –2dB to the A.V. limit in Peak mode, then the emission signal was re-checked using Q.P and Average detector.
- 3. The test data of the worst case condition(s) was reported on the Summary Data page.

The results spound this jest report refer only to the sample(s) tested unless otherwise stated and the sample(s) are retained for 30 days only. The document is issued by XCC, this document cannot be reproduced except in full with our prior written permission. The more details and the authenticity of the report will be confirmed at a true www.ago-gent.com.



14.5. TEST RESULT OF LINE CONDUCTED EMISSION TEST

The mode name of adapter-KT05W050100USU
Line Conducted Emission Test Line 1-L




No.	Freq.	Reading_Level (dBuV)			Correct Factor	Measurement (dBuV)			Limit (dBuV)		Margin (dB)		P/F	Comment
	(MHz)	Peak	QP	AVG	dB	Peak	QP	AVG	QP	AVG	QP	AVG		
1	0.2460	37.53		22.12	10.27	47.80		32.39	61.89	51.89	-14.09	-19.50	Р	
2	0.3740	34.67		24.74	10.32	44.99		35.06	58.41	48.41	-13.42	-13.35	Р	
3	0.4940	31.56		13.51	10.40	41.96		23.91	56.10	46.10	-14.14	-22.19	Р	
4	1.5020	32.04		17.54	10.38	42.42		27.92	56.00	46.00	-13.58	-18.08	Р	
5	2.3340	30.75		12.06	10.36	41.11		22.42	56.00	46.00	-14.89	-23.58	Р	
6	4.2380	28.51		10.45	10.33	38.84		20.78	56.00	46.00	-17.16	-25.22	Р	

The results spowford this jest report refer only to the sample(s) tested unless otherwise stated and the sample(s) are retained for 30 days only. The document is issued by XOC, this document cannot be reproduced except in full with our prior written permission. The more details and the authenticity of the report will be confirmed at attp://www.ago.go.tt.com.



Line Conducted Emission Test Line 2-N




No.	Freq.	Reading_Level (dBuV)			Correct Factor	Measurement (dBuV)			Limit (dBuV)		Margin (dB)		P/F	Comment
	(MHz)	Peak	QP	AVG	dB	Peak	QP	AVG	QP	AVG	QP	AVG		
1	0.2580	39.96		22.24	10.27	50.23		32.51	61.49	51.49	-11.26	-18.98	Р	
2	0.3780	38.09		23.49	10.32	48.41		33.81	58.32	48.32	-9.91	-14.51	Р	
3	0.7300	36.96		19.98	10.33	47.29		30.31	56.00	46.00	-8.71	-15.69	Р	
4	0.8500	35.68		17.81	10.34	46.02		28.15	56.00	46.00	-9.98	-17.85	Р	
5	1.4819	35.08		18.03	10.38	45.46		28.41	56.00	46.00	-10.54	-17.59	Р	
6	4.0420	31.93		12.29	10.41	42.34		22.70	56.00	46.00	-13.66	-23.30	Р	

The results showed the sample (s) tested unless otherwise stated and the sample (s) are retained for 30 days only. The document is issued by (SC, this document cannot be reproduced except in full with our prior written permission. The more details and the authenticity of the report will be confirmed at attp://www.ago-gent.com.



The mode name of adapter-HA-19050100UU Line Conducted Emission Test Line 1-L




No.	Freq.	Reading_Level (dBuV)			Correct Factor	Measurement (dBuV)			Limit (dBuV)		Margin (dB)		P/F	Comment
	(MHz)	Peak	QP	AVG	dB	Peak	QP	AVG	QP	AVG	QP	AVG		
1	0.3738	35.27		25.20	10.32	45.59		35.52	58.41	48.41	-12.82	-12.89	Р	
2	0.6179	33.92		17.44	10.32	44.24		27.76	56.00	46.00	-11.76	-18.24	Р	
3	0.7419	31.57		20.60	10.32	41.89		30.92	56.00	46.00	-14.11	-15.08	Р	
4	1.4738	31.20		19.88	10.38	41.58		30.26	56.00	46.00	-14.42	-15.74	Р	
5	2.2099	29.44		16.48	10.31	39.75		26.79	56.00	46.00	-16.25	-19.21	Р	
6	3.8940	28.78		15.14	10.45	39.23		25.59	56.00	46.00	-16.77	-20.41	Р	

The results spowth this jest report refer only to the sample(s) tested unless otherwise stated and the sample(s) are retained for 30 days only. The document is issued by AGC, this document cannot be reproduced except in full with our prior written permission. The more details and the authenticity of the report will be confirmed at attp://www.agc.gott.com.



Line Conducted Emission Test Line 2-N




No.	No. Freq.		Reading_Level (dBuV)			Measurement (dBuV)			Limit (dBuV)		Margin (dB)		P/F	Comment
	(MHz)	Peak	QP	AVG	dB	Peak	QP	AVG	QP	AVG	QP	AVG		
1	0.3780	40.06		22.82	10.32	50.38		33.14	58.32	48.32	-7.94	-15.18	Р	
2	0.7380	35.95		20.36	10.32	46.27		30.68	56.00	46.00	-9.73	-15.32	Р	
3	0.8460	36.44		18.79	10.34	46.78		29.13	56.00	46.00	-9.22	-16.87	Р	
4	1.4900	36.49		17.84	10.38	46.87		28.22	56.00	46.00	-9.13	-17.78	Р	
5	2.0660	33.61		16.55	10.25	43.86		26.80	56.00	46.00	-12.14	-19.20	Р	
6	3.8980	31.09		13.06	10.45	41.54		23.51	56.00	46.00	-14.46	-22.49	Р	

The results showed the sample (s) tested unless otherwise stated and the sample (s) are retained for 30 days only. The document is issued by (SC, this document cannot be reproduced except in full with our prior written permission. The more details and the authenticity of the report will be confirmed at attp://www.ago-gent.com.



The mode name of adapter-D31-05050100 Line Conducted Emission Test Line 1-L




No.	lo. Freq.		Reading_Level (dBuV)			Measurement (dBuV)			Limit (dBuV)		Margin (dB)		P/F	Comment
	(MHz)	Peak	QP	AVG	dB	Peak	QP	AVG	QP	AVG	QP	AVG		
1	0.3740	35.00		24.02	10.32	45.32		34.34	58.41	48.41	-13.09	-14.07	Р	
2	0.6180	33.65		18.27	10.32	43.97		28.59	56.00	46.00	-12.03	-17.41	Р	
3	0.7340	31.79		20.20	10.33	42.12		30.53	56.00	46.00	-13.88	-15.47	Р	
4	1.4620	31.32		20.59	10.38	41.70		30.97	56.00	46.00	-14.30	-15.03	Р	
5	3.7780	28.75		14.62	10.47	39.22		25.09	56.00	46.00	-16.78	-20.91	Р	
6	4.1900	26.37		10.61	10.35	36.72		20.96	56.00	46.00	-19.28	-25.04	Р	

The results spowth this jest report refer only to the sample(s) tested unless otherwise stated and the sample(s) are retained for 30 days only. The document is issued by AGC, this document cannot be reproduced except in full with our prior written permission. The more details and the authenticity of the report will be confirmed at attp://www.agc.gott.com.



Line Conducted Emission Test Line 2-N



No.	Freq.	Reading_Level (dBuV)			Correct Factor	Measurement (dBuV)			Limit (dBuV)		Margin (dB)		P/F	Comment
	(MHz)	Peak	QP	AVG	dB	Peak	QP	AVG	QP	AVG	QP	AVG		
1	0.2580	39.96		22.24	10.27	50.23		32.51	61.49	51.49	-11.26	-18.98	Р	
2	0.3780	38.09		23.49	10.32	48.41		33.81	58.32	48.32	-9.91	-14.51	Р	
3	0.7300	36.96		19.98	10.33	47.29		30.31	56.00	46.00	-8.71	-15.69	Р	
4	0.8500	35.68		17.81	10.34	46.02		28.15	56.00	46.00	-9.98	-17.85	Р	
5	1.4819	35.08		18.03	10.38	45.46		28.41	56.00	46.00	-10.54	-17.59	Р	
6	4.0420	31.93		12.29	10.41	42.34		22.70	56.00	46.00	-13.66	-23.30	Р	

RESULT: PASS

Note: All the test modes had been tested, the mode 1 was the worst case. Only the data of the worst case would be record in this test report.

The results spowford this jest report refer only to the sample(s) tested unless otherwise stated and the sample(s) are retained for 30 days only. The document is issued by AGC, this document cannot be reproduced except in full with our prior written permission. The more details and the authenticity of the report will be confirmed at attp://www.agc.gent.com.




APPENDIX A: PHOTOGRAPHS OF TEST SETUP

FCC LINE CONDUCTED EMISSION TEST SETUP



RADIATED EMISSION TEST SETUP BELOW 1GHZ




The results showed this jest report refer only to the sample(s) tested unless otherwise stated and the sample(s) are retained for 30 days only. The document is issued by AGC, this document cannot be reproduced except in full with our prior written permission. The more details and the authenticity of the report will be confirmed at attp://www.agc.go.tt.com.

Attestation of Global Compliance



RADIATED EMISSION TEST SETUP ABOVE 1GHZ




The results shown this jest report refer only to the sample(s) tested unless otherwise stated and the sample(s) are retained for 30 days only. The document is issued by (60°, this document cannot be reproduced except in full with our prior written permission. The more details and the authenticity of the report will be confirmed at http://www.agc.gett.com.

Attestation of Global Compliance



APPENDIX B: PHOTO GRAPHS OF EUT

All VIEW OF EUT



ADAPTER OF KT05W050100USU




The results shown this jest report refer only to the sample(s) tested unless otherwise stated and the sample(s) are retained for 30 days only. The document is issued by AGC, this document cannot be reproduced except in full with our prior written permission. The more details and the authenticity of the report will be confirmed at attp://www.agc.gett.com.


Attestation of Global Compliance



ADAPTER OF HA-19050100UU



ADAPTER OF D31-05050100



The results shown this jest report refer only to the sample(s) tested unless otherwise stated and the sample(s) are retained for 30 days only. The document is issued by AGC, this document cannot be reproduced except in full with our prior written permission. The more details and the authenticity of the report will be confirmed at attp://www.agc.com.

Attestation of Global Compliance



TOP VIEW OF EUT



BOTTOM VIEW OF EUT



The results showed this jest report refer only to the sample(s) tested unless otherwise stated and the sample(s) are retained for 30 days only. The document is issued by AGE, this document cannot be reproduced except in full with our prior written permission. The more details and the authenticity of the report will be confirmed at attp://www.agc.gett.com.

Attestation of Global Compliance



FRONT VIEW OF EUT



BACK VIEW OF EUT




The results showed this jest report refer only to the sample(s) tested unless otherwise stated and the sample(s) are retained for 30 days only. The document is issued by AGC, this document cannot be reproduced except in full with our prior written permission. The more details and the authenticity of the report will be confirmed at attr://www.agc.gett.com.


Attestation of Global Compliance



LEFT VIEW OF EUT



RIGHT VIEW OF EUT




The results showed this jest report refer only to the sample(s) tested unless otherwise stated and the sample(s) are retained for 30 days only. The document is issued by AGC, this document cannot be reproduced except in full with our prior written permission. The more details and the authenticity of the report will be confirmed at attp://www.agc.gett.com.

Attestation of Global Compliance


AGC 8



OPEN VIEW OF EUT(FIGURE 1)



OPEN VIEW OF EUT(FIGURE 2)




The results spowd this jest report refer only to the sample(s) tested unless otherwise stated and the sample(s) are retained for 30 days only. The document is issued by AGC, this document cannot be reproduced except in full with our prior written permission. The more details and the authenticity of the report will be confirmed at attr://www.agc-gent.com.

Attestation of Global Compliance



INTERNAL VIEW OF EUT(FIGURE 1)



INTERNAL VIEW OF EUT(FIGURE 2)



The results showing this jest report refer only to the sample(s) tested unless otherwise stated and the sample(s) are retained for 30 days only. The document is issued by AGC, this document cannot be reproduced except in full with our prior written permission. The more details and the authenticity of the report will be confirmed at attp://www.agc.gent.com.

Attestation of Global Compliance



INTERNAL VIEW OF EUT(FIGURE 3)



INTERNAL VIEW OF EUT(FIGURE 4)




The results shown this jest report refer only to the sample(s) tested unless otherwise stated and the sample(s) are retained for 30 days only. The document is issued by AGC, this document cannot be reproduced except in full with our prior written permission. The more details and the authenticity of the report will be confirmed at attr://www.agc.got.com.

Attestation of Global Compliance



INTERNAL VIEW OF EUT(FIGURE 5)



INTERNAL VIEW OF EUT(FIGURE 6)



The results showing this jest report refer only to the sample(s) tested unless otherwise stated and the sample(s) are retained for 30 days only. The document is issued by KCE, this document cannot be reproduced except in full with our prior written permission. The more details and the authenticity of the report will be confirmed at attp://www.agc-cert.com. **IGC** 8

Attestation of Global Compliance

Tel: +86-755 2908 1955

E-mail: agc@agc-cert.com


6 400 089 2118



OPNE VIEW OF EUT (FIGURE 1)



OPNE VIEW OF EUT (FIGURE 2)




The results spowth this jest report refer only to the sample(s) tested unless otherwise stated and the sample(s) are retained for 30 days only. The document is issued by AGC, this document cannot be reproduced except in full with our prior written permission. The more details and the authenticity of the report will be confirmed at attp://www.agc.gott.com.


Attestation of Global Compliance



INTERNAL VIEW OF EUT(FIGURE 1)



INTERNAL VIEW OF EUT(FIGURE 2)




The results spoured this jest report refer only to the sample(s) tested unless otherwise stated and the sample(s) are retained for 30 days only. The document is issued by XOC, this document cannot be reproduced except in full with our prior written permission. The more details and the authenticity of the report will be confirmed at attp://www.ago.go.tt.com.


Attestation of Global Compliance



OPNE VIEW OF EUT (FIGURE 1)



OPNE VIEW OF EUT (FIGURE 2)




The results spowth this jest report refer only to the sample(s) tested unless otherwise stated and the sample(s) are retained for 30 days only. The document is issued by AGC, this document cannot be reproduced except in full with our prior written permission. The more details and the authenticity of the report will be confirmed at attr://www.agc.gett.com.


Attestation of Global Compliance



INTERNAL VIEW OF EUT(FIGURE 1)



INTERNAL VIEW OF EUT(FIGURE 2)



The results spound this jest report refer only to the sample(s) tested unless otherwise stated and the sample(s) are retained for 30 days only. The document is issued by (GC, this document cannot be reproduced except in full with our prior written permission. The more details and the authenticity of the report will be confirmed at a titp://www.agc.gatt.com.


Attestation of Global Compliance



OPNE VIEW OF EUT (FIGURE 1)



INTERNAL VIEW OF EUT(FIGURE 1)




The results spowth this jest report refer only to the sample(s) tested unless otherwise stated and the sample(s) are retained for 30 days only. The document is issued by AGC, this document cannot be reproduced except in full with our prior written permission. The more details and the authenticity of the report will be confirmed at attr://www.agc.gett.com.

Attestation of Global Compliance



INTERNAL VIEW OF EUT(FIGURE 2)



----END OF REPORT----

The results shown the streport refer only to the sample(s) tested unless otherwise stated and the sample(s) are retained for 30 days only. The document is issued by AGC, this document cannot be reproduced except in full with our prior written permission. The more details and the authenticity of the report will be confirmed at a true; //www.agc cont.com.

Attestation of Global Compliance