

Report No.: FA951106

FCC SAR Test Report

APPLICANT : Brightstar Corporation

EQUIPMENT: GSM 850/1900 Terminal Device

BRAND NAME : Motorola

MODEL NAME : B525V1

FCC ID : WVBW172A

MARKETING NAME W172

STANDARD : 47 CFR Part 2 (2.1093)

IEEE C95.1-1999 IEEE 1528-2003

OET Bulletin 65 Supplement C (Edition 01-01)

The product sample received on May 11, 2009 and completely tested on May 19, 2009. We, SPORTON INTERNATIONAL INC., would like to declare that the tested sample has been evaluated in accordance with the procedures and shown the compliance with the applicable technical standards.

The test results in this report apply exclusively to the tested model / sample. Without written approval of SPORTON INTERNATIONAL INC., the test report shall not be reproduced except in full.

Reviewed by:

Roy Wu / Manager

ilac-MRA

Testing Laboratory

SPORTON INTERNATIONAL INC.

No. 52, Hwa Ya 1st Rd., Hwa Ya Technology Park, Kwei-Shan Hsiang, Tao Yuan Hsien, Taiwan, R.O.C.

TEL: 886-3-327-3456 FAX: 886-3-328-4978 FCC ID: WVBW172A Page Number : 1 of 31
Report Issued Date : May 26, 2009

Table of Contents

Rev	ision H	listory	3
1.		nent of Compliance	
2.	Admin	istration Data	5
	2.1	Testing Laboratory	5
	2.2	Applicant	
	2.3	Manufacturer	
	2.4	Application Details	5
3.	Gener	al Information	6
	3.1	Description of Device Under Test (DUT)	.6
	3.2	Product Photos	
	3.3	Applied Standards	
	3.4	Device Category and SAR Limits	
	3.5	Test Conditions	
		3.5.1 Ambient Condition	
		3.5.2 Test Configuration	
4.	Specif	ic Absorption Rate (SAR)	
	4.1	Introduction	.8
	4.2	SAR Definition	
5.	SAR N	leasurement Setup	
	5.1	DASY4 E-Field Probe System	
		5.1.1 E-Field Probe Specification	
		5.1.2 E-Field Probe Calibration	11
	5.2	DATA Acquisition Electronics (DAE)	
	5.3	Robot	
	5.4	Measurement Server	
	5.5	SAM Twin Phantom	14
	5.6	Device Holder for SAM Twin Phantom	
	5.7	Data Storage and Evaluation	
		5.7.1 Data Storage	
		5.7.2 Data Evaluation	
	5.8	Test Equipment List	
		Simulating Liquids	
7.		tainty Assessment	
8.	SAR N	leasurement Evaluation	
	8.1	Purpose of System Performance check	23
	8.2	System Setup	
	8.3	Validation Results	
9.		ption for DUT Testing Position	
10.		rement Procedures	
	10.1	Spatial Peak SAR Evaluation	
	10.2	Scan Procedures	
	10.3	SAR Averaged Methods	
11.		est Results	
	11.1	Conducted Power	
	11.2	Test Records for Head SAR Test	
	11.3	Test Records for Body SAR Test	
		nces	31
App	endix	A - System Performance Check Data	
App	endix	B - SAR Measurement Data	
App	endix	C - Calibration Data	
App	endix	D - Product Photos	
App	endix	E - Test Setup Photos	

TEL: 886-3-327-3456 FAX: 886-3-328-4978 FCC ID: WVBW172A

Revision History

REPORT NO.	VERSION	DESCRIPTION	ISSUED DATE
FA951106	Rev. 01	Initial issue of report	May 26, 2009

TEL: 886-3-327-3456 FAX: 886-3-328-4978 FCC ID: WVBW172A Page Number : 3 of 31
Report Issued Date : May 26, 2009
Report Version : Rev. 01



1. Statement of Compliance

The Specific Absorption Rate (SAR) maximum results found during testing for the **Brightstar Corporation GSM 850/1900 Terminal Device Motorola B525V1** are as follows (with expanded uncertainty 21.9%):

Band	Position	SAR _{1g} (W/kg)
CCMOEO	Head	1.57
GSM850	Body	0.786
CSM4000	Head	1.09
GSM1900	Body	0.4

They are in compliance with Specific Absorption Rate (SAR) for general population/uncontrolled exposure limits specified in FCC 47 CFR part 2 (2.1093) and ANSI/IEEE C95.1-1999, and had been tested in accordance with the measurement methods and procedures specified in IEEE 1528-2003 and OET Bulletin 65 Supplement C (Edition 01-01).

SPORTON INTERNATIONAL INC.

TEL: 886-3-327-3456 FAX: 886-3-328-4978 FCC ID: WVBW172A Page Number : 4 of 31
Report Issued Date : May 26, 2009

Report No.: FA951106

2. Administration Data

2.1 Testing Laboratory

Test Site	SPORTON INTERNATIONAL INC.
Test Site Location	No. 52, Hwa Ya 1 st Rd., Hwa Ya Technology Park, Kwei-Shan Hsiang, Tao Yuan Hsien, Taiwan, R.O.C. TEL: +886-3-327-3456 FAX: +886-3-328-4978
Test Site No.	Sporton Site No. : SAR01-HY

2.2 Applicant

Company Name	Brightstar Corporation
Address	9725 NW 117th Avenue, #300 I Miami, FL 33178

2.3 Manufacturer

Company Name	CHENG UEI PRECISION INDUSTRY CO., LTD.	
Address	No. 49, Sec. 4, Jhongyang Rd., Tucheng City, Taipei 23675, Taiwan	

2.4 Application Details

Date of Receipt of Application	May 11, 2009
Date of Start during the Test	May 14, 2009
Date of End during the Test	May 19, 2009

SPORTON INTERNATIONAL INC.

TEL: 886-3-327-3456 FAX: 886-3-328-4978 FCC ID: WVBW172A Page Number : 5 of 31
Report Issued Date : May 26, 2009
Report Version : Rev. 01

3. General Information

3.1 Description of Device Under Test (DUT)

Product Feature & Specification		
DUT Type	GSM 850/1900 Terminal Device	
Trade Name	Motorola	
Model Name	B525V1	
FCC ID	WVBW172A	
Marketing Name	W172	
Ty Fraguency	GSM850 : 824 MHz ~ 849 MHz	
Tx Frequency	GSM1900 : 1850 MHz ~ 1910 MHz	
Rx Frequency	GSM850 : 869 MHz ~ 894 MHz	
RX Frequency	GSM1900 : 1930 MHz ~ 1990 MHz	
Maximum Output Power to Antenna	GSM850 : 32.26 dBm	
Maximum Output Fower to Antenna	GSM1900 : 29.53 dBm	
Antenna Type	Fixed Internal Antenna	
HW Version	B525V1-0J	
SW Version	B525CA.M2.00.133.00.27.00	
Type of Modulation	GMSK	
DUT Stage	Identical Prototype	

List of Accessory:

Specification of Accessory				
	`			
	Brand Name	Motorola		
	Model Name	5812 / SPN5405A		
AC Adapter	Power Rating	I/P:100-240Vac, 50-60Hz, 200mA;		
	rower Rating	O/P: 5Vdc, 550mA		
	AC Power Cord Type	1.9 meter non-shielded cable without ferrite core		
	Brand Name	Motorola		
Battery	Model Name	VB50		
Datter y	Power Rating	3.7Vdc, 750mAh, 2.8Wh		
	Туре	Li-ion		
	Brand Name	SUPER DUPER		
Earphone	Model Name	PHF-SDE-15S		
	Signal Line Type	1.3 meter non-shielded cable without ferrite core		
LCD Panel	Brand Name	Foxlink		
LCD Fallel	Model Name	FS144QSC03-A0(8290-0274-0090)		

Remark: The above DUT's information was declared by manufacturer. Please refer to the specifications or user's manual for more detailed description.

3.2 Product Photos

Refer to Appendix D.

SPORTON INTERNATIONAL INC.

TEL: 886-3-327-3456 FAX: 886-3-328-4978 FCC ID: WVBW172A Page Number : 6 of 31

Report Issued Date : May 26, 2009

Report Version : Rev. 01



3.3 Applied Standards

The Specific Absorption Rate (SAR) testing specification, method and procedure for this GSM 850/1900 Terminal Device is in accordance with the following standards:

- 47 CFR Part 2 (2.1093)
- IEEE C95.1-1999
- IEEE 1528-2003
- OET Bulletin 65 Supplement C (Edition 01-01)

3.4 Device Category and SAR Limits

This device belongs to portable device category because its radiating structure is allowed to be used within 20 centimeters of the body of the user. Limit for General Population/Uncontrolled exposure should be applied for this device, it is 1.6 W/kg as averaged over any 1 gram of tissue.

3.5 Test Conditions

3.5.1 Ambient Condition

Ambient Temperature	20-24℃
Humidity	<60%

3.5.2 Test Configuration

The device was controlled by using a base station emulator R&S CMU200. Communication between the device and the emulator was established by air link. The distance between the DUT and the antenna of the emulator is larger than 50 cm and the output power radiated from the emulator antenna is at least 30 dB smaller than the output power of DUT. The DUT was set from the emulator to radiate maximum output power during all tests.

For SAR testing, the DUT is in GSM link mode and its crest factor is 8.3.

SPORTON INTERNATIONAL INC.

TEL: 886-3-327-3456 FAX: 886-3-328-4978 FCC ID: WVBW172A Page Number : 7 of 31
Report Issued Date : May 26, 2009

Report No.: FA951106

4. Specific Absorption Rate (SAR)

4.1 Introduction

SAR is related to the rate at which energy is absorbed per unit mass in an object exposed to a radio field. The SAR distribution in a biological body is complicated and is usually carried out by experimental techniques or numerical modeling. The standard recommends limits for two tiers of groups, occupational/controlled and general population/uncontrolled, based on a person's awareness and ability to exercise control over his or her exposure. In general, occupational/controlled exposure limits are higher than the limits for general population/uncontrolled.

4.2 SAR Definition

The SAR definition is the time derivative (rate) of the incremental energy (dW) absorbed by (dissipated in) an incremental mass (dm) contained in a volume element (dv) of a given density.

 ρ). The equation description is as below:

$$SAR = \frac{d}{dt} \left(\frac{dW}{dm} \right) = \frac{d}{dt} \left(\frac{dW}{\rho dv} \right)$$

SAR is expressed in units of Watts per kilogram (W/kg)

SAR measurement can be either related to the temperature elevation in tissue by

$$SAR = C \frac{\delta T}{\delta t}$$

, where C is the specific head capacity, $\,^{\delta}$ T is the temperature rise and $\,^{\delta}$ t the exposure duration, or related to the electrical field in the tissue by

$$SAR = \frac{\sigma |E|^2}{\rho}$$

, where σ is the conductivity of the tissue, ρ is the mass density of the tissue and E is the rms electrical field strength.

However for evaluating SAR of low power transmitter, electrical field measurement is typically applied.

SPORTON INTERNATIONAL INC.

TEL: 886-3-327-3456 FAX: 886-3-328-4978 FCC ID: WVBW172A Page Number : 8 of 31 Report Issued Date : May 26, 2009

Report No.: FA951106



5. SAR Measurement Setup




Fig. 5.1 DASY4 System

The DASY4 system for performance compliance tests is illustrated above graphically. This system consists of the following items:

- > A standard high precision 6-axis robot with controller, a teach pendant and software
- A data acquisition electronic (DAE) attached to the robot arm extension
- > A dosimetric probe equipped with an optical surface detector system
- > The electro-optical converter (ECO) performs the conversion between optical and electrical signals
- A measurement server performs the time critical tasks such as signal filtering, control of the robot operation and fast movement interrupts.
- A probe alignment unit which improves the accuracy of the probe positioning
- A computer operating Windows XP
- DASY4 software
- Remove control with teach pendant and additional circuitry for robot safety such as warming lamps, etc.
- > The SAM twin phantom
- A device holder
- > Tissue simulating liquid
- Dipole for evaluating the proper functioning of the system

Some of the components are described in details in the following sub-sections.

SPORTON INTERNATIONAL INC.

TEL: 886-3-327-3456 FAX: 886-3-328-4978 FCC ID: WVBW172A Page Number : 9 of 31 Report Issued Date : May 26, 2009

Report No.: FA951106



5.1 DASY4 E-Field Probe System

The SAR measurement is conducted with the dosimetric probe (manufactured by SPEAG). The probe is specially designed and calibrated for use in liquid with high permittivity. The dosimetric probe has special calibration in liquid at different frequency. This probe has a built in optical surface detection system to prevent from collision with phantom.

5.1.1 E-Field Probe Specification <ET3DV6>

Construction	Symmetrical design with triangular co		
	Built-in optical fiber for surface detect		
	Built-in shielding against static charge	es	
	PEEK enclosure material (resistant to	o organic solvents)	
Frequency	10 MHz to 3 GHz		
Directivity	± 0.2 dB in brain tissue (rotation		
	around probe axis)		
	± 0.4 dB in brain tissue (rotation		
	perpendicular to probe axis)		
Dynamic Range	5μW/g to 100mW/g; Linearity:		
	±0.2dB		
Surface Detection	± 0.2 mm repeatability in air and	Same)	
	clear liquids on reflecting surface		
Dimensions	Overall length: 330mm	The state of the s	
	Tip length: 16mm		
	Body diameter: 12mm		
	Tip diameter: 6.8mm		
	Distance from probe tip to dipole		
	centers: 2.7mm	Fig 5.2 Probe Setup on Robot	
Application	General dosimetry up to 3GHz		
	Compliance tests for mobile phones and Wireless LAN		
	Fast automatic scanning in arbitrary phantoms		

<EX3DV3 Probe>

-LASDVS FIODE	0 (: 1.1 : ::11.1: 1		
Construction	Symmetrical design with triangular core		
	Built-in shielding against static charges		
	PEEK enclosure material (resistant to organic s	olvents)	
Frequency	10 MHz to 6 GHz; Linearity: ± 0.2 dB (30 MHz		
	to 3 GHz)		
Directivity	± 0.3 dB in HSL (rotation around probe axis)		
	± 0.5 dB in tissue material (rotation normal to		
	probe axis)		
Dynamic Range	10 μW/g to 100 mW/g; Linearity: ± 0.2 dB		
	(noise: typically < 1 μW/g)		
Dimensions	Overall length: 330 mm (Tip: 20 mm)		
	Tip diameter: 2.5 mm (Body: 12 mm)		
	Typical distance from probe tip to dipole		
	centers: 1 mm		
Application	High precision dosimetric measurements in any		
	exposure scenario (e.g., very strong gradient	Fig. 5.3 EX3DV3 E-field Probe	
	fields). Only probe which enables compliance	1 19. 0.0 2.02 10 2 11014 1 1000	
	testing for frequencies up to 6 GHz with		
	precision of better 30%.		

SPORTON INTERNATIONAL INC.

TEL: 886-3-327-3456 FAX: 886-3-328-4978 FCC ID: WVBW172A Page Number : 10 of 31
Report Issued Date : May 26, 2009
Report Version : Rev. 01



5.1.2 E-Field Probe Calibration

Each probe needs to be calibrated according to a dosimetric assessment procedure with accuracy better than \pm 10%. The spherical isotropy shall be evaluated and within \pm 0.25dB. The sensitivity parameters (NormX, NormY, and NormZ), the diode compression parameter (DCP) and the conversion factor (ConvF) of the probe are tested. The calibration data are as below:

ET3DV6 sn1788 (Cal: Sep. 23, 2008)							
Item	X axis	Y axis	Z axis				
Sensitivity (μV)	1.73	1.59	1.72				
Diode Compression Point (mV)	95	98	91				
	Frequency (MHz)	X,Y,Z	. axis				
Conversion Factor (Head / Body)	800~1000	6.55 / 6.34					
	1650~1850	5.59 / 4.87					
	1850~2050	5.13	4.73				
	2350~2550	4.68	/ 3.98				
	Frequency (MHz)	Alpha	Depth				
Boundary Effect	800~1000	0.44 / 0.50	2.65 / 2.48				
(Head / Body)	1650~1850	0.68 / 0.63	1.98 / 2.33				
	1850~2050	0.75 / 0.74	1.75 / 1.99				
	2350~2550	0.80 / 0.94	1.45 / 1.75				

SPORTON INTERNATIONAL INC.

TEL: 886-3-327-3456 FAX: 886-3-328-4978 FCC ID: WVBW172A Page Number : 11 of 31
Report Issued Date : May 26, 2009
Report Version : Rev. 01



EX3DV3 sn3514 (Cal: Jan. 21, 2009) Item X axis Y axis Z axis 0.70 Sensitivity (µV) 0.66 0.60 **Diode Compression Point (mV)** 91 94 95 **Frequency** X,Y,Z axis (MHz) 800~1000 9.31 / 9.41 1710~1910 8.16 / 8.18 2200~2400 7.78 / 7.60 **Conversion Factor** 2500~2700 7.34 / 7.20 (Head / Body) 3400~3600 6.89 / 6.40 4.78 / 4.29 5100~5300 5200~5400 4.40 / 3.94 5400~5600 4.22 / 3.88 5500~5700 4.13 / 3.89 5700~5900 4.13 / 3.85 **Frequency** Alpha **Depth** (MHz) 800~1000 0.45 / 0.42 0.76 / 0.76 1710~1910 0.60 / 0.85 0.63 / 0.56 2200~2400 0.63 / 4.17 0.53 / 0.182500~2700 0.16 / 0.34 2.19 / 1.14 **Boundary Effect** (Head / Body) 3400~3600 0.86 / 0.81 0.50 / 0.53 5100~5300 0.40 / 0.451.70 / 1.75 5200~5400 0.40 / 0.45 1.70 / 1.75 5400~5600 0.40 / 0.45 1.70 / 1.75 5500~5700 0.40 / 0.45 1.70 / 1.75

5700~5900

0.40 / 0.45

NOTE: The probe parameters have been calibrated by the SPEAG.

TEL: 886-3-327-3456 FAX: 886-3-328-4978 FCC ID: WVBW172A Page Number : 12 of 31
Report Issued Date : May 26, 2009
Report Version : Rev. 01

1.70 / 1.75



5.2 DATA Acquisition Electronics (DAE)

The data acquisition electronics (DAE) consists of a highly sensitive electrometer-grade preamplifier with auto-zeroing, a channel and gain-switching multiplexer, a fast 16 bit AD-converter and a command decoder and control logic unit. Transmission to the measurement server is accomplished through an optical downlink for data and status information as well as an optical uplink for commands and the clock.

The mechanical probe mounting device includes two different sensor systems for frontal and sideways probe contacts. They are used for mechanical surface detection and probe collision detection.

The input impedance of the DAE is 200M Ohm; the inputs are symmetrical and floating. Common mode rejection is above 80dB.

5.3 Robot

The DASY4 system uses the high precision robots RX90BL type out of the newer series from Stäubli SA (France). For the 6-axis controller DASY4 system, the CS7MB robot controller version from Stäubli is used. The RX robot series have many features that are important for our application:

- > High precision (repeatability 0.02 mm)
- High reliability (industrial design)
- Jerk-free straight movements
- > Low ELF interference (the closed metallic construction shields against motor control fields)
- ➢ 6-axis controller

5.4 Measurement Server

The DASY4 measurement server is based on a PC/104 CPU board with 166 MHz CPU 32 MB chipset and 64 MB RAM.

Communication with

the DAE electronic box

the 16-bit AD-converter system for optical detection and digital I/O interface.

The measurement server performs all the real-time data evaluation for field measurements and surface detection, controls robot movements and handles safety operations.

SPORTON INTERNATIONAL INC. TEL: 886-3-327-3456

FAX: 886-3-328-4978 FCC ID: WVBW172A Page Number : 13 of 31

Report Issued Date : May 26, 2009

Report No.: FA951106



5.5 SAM Twin Phantom

The SAM twin phantom is a fiberglass shell phantom with 2mm shell thickness (except the ear region where shell thickness increases to 6mm). It has three measurement areas:

- Left head
- Right head
- Flat phantom

The bottom plate contains three pair of bolts for locking the device holder. The device holder positions are adjusted to the standard measurement positions in the three sections. A white cover is provided to tap the phantom during off-periods to prevent water evaporation and changes in the liquid parameters. On the phantom top, three reference markers are provided to identify the phantom position with respect to the robot.

The phantom can be used with the following tissue simulating liquids:

- *Water-sugar based liquid
- *Glycol based liquids




Fig. 5.4 Top View of Twin Phantom



Fig. 5.5 Bottom View of Twin Phantom

SPORTON INTERNATIONAL INC.

TEL: 886-3-327-3456 FAX: 886-3-328-4978 FCC ID: WVBW172A Page Number : 14 of 31 Report Issued Date: May 26, 2009

Report No.: FA951106



5.6 <u>Device Holder for SAM Twin Phantom</u>

The SAR in the Phantom is approximately inversely proportional to the square of the distance between the source and the liquid surface. For a source in 5 mm distance, a positioning uncertainty of ±0.5mm would produce a SAR uncertainty of ± 20%. An accurate device position is therefore crucial for accurate and repeatable measurement. The position in which the devices must be measured, are defined by the standards.

The DASY4 device holder is designed to cope with different positions given in the standard. It has two scales for the device rotation (with respect to the body axis) and the device inclination (with respect to the line between the ear reference points). The rotation center for both scales is the ear reference point (EPR).

Thus the device needs no repositioning when changing the angles.

The DASY4 device holder has been made out of low-loss POM material having the following dielectric parameters: relative permittivity $\varepsilon r = 3$ and loss tangent $\delta = 0.02$. The amount of dielectric material has been reduced in the closest vicinity of the device, since measurements have suggested that the influence of the clamp on the test results could thus be lowered.



Fig. 5.6 Device Holder

SPORTON INTERNATIONAL INC.

TEL: 886-3-327-3456 FAX: 886-3-328-4978 FCC ID: WVBW172A Page Number : 15 of 31 Report Issued Date: May 26, 2009

Report No.: FA951106

5.7 Data Storage and Evaluation

5.7.1 Data Storage

The DASY4 software stores the assessed data from the data acquisition electronics as raw data (in microvolt readings from the probe sensors), together with all the necessary software parameters for the data evaluation (probe calibration data, liquid parameters and device frequency and modulation data) in measurement files with the extension. The post-processing software evaluates the desired unit and format for output each time the data is visualized or exported. This allows verification of the complete software setup even after the measurement and allows correction of erroneous parameter settings. For example, if a measurement has been performed with an incorrect crest factor parameter in the device setup, the parameter can be corrected afterwards and the data can be reevaluated.

The measured data can be visualized or exported in different units or formats, depending on the selected probe type (e.g., [V/m], [A/m], [mW/g]). Some of these units are not available in certain situations or give meaningless results, e.g., a SAR-output in a non-lose media, will always be zero. Raw data can also be exported to perform the evaluation with other software packages.

5.7.2 Data Evaluation

Media parameters:

The DASY4 post-processing software (SEMCAD) automatically executes the following procedures to calculate the field units from the microvolt readings at the probe connector. The parameters used in the evaluation are stored in the configuration modules of the software :

Probe parameters :	- Sensitivity	Norm _j , a _{,0,} a _{,1} , a _{,2}
--------------------	---------------	--

Conversion factor ConvF_i
 Diode compression point dcp_i

Device parameters: - Frequency f

- Crest factor cf - Conductivity σ

- Density ρ

These parameters must be set correctly in the software. They can be found in the component documents or they can be imported into the software from the configuration files issued for the DASY4 components. In the direct measuring mode of the multi-meter option, the parameters of the actual system setup are used. In the scan visualization and export modes, the parameters stored in the corresponding document files are used.

The first step of the evaluation is a linearization of the filtered input signal to account for the compression characteristics of the detector diode. The compensation depends on the input signal, the diode type and the DC-transmission factor from the diode to the evaluation electronics. If the exciting field is pulsed, the crest factor of the signal must be known to correctly compensate for peak power.

TEL: 886-3-327-3456 FAX: 886-3-328-4978 FCC ID: WVBW172A

The formula for each channel can be given as :

$$Vi = U_i + U_i^2 \cdot \frac{cf}{dcp_i}$$

with

 V_i = compensated signal of channel i (i = x, y, z)

 U_i = input signal of channel i (i = x, y, z)

cf = crest factor of exciting field (DASY parameter) dcp_i = diode compression point (DASY parameter)

From the compensated input signals, the primary field data for each channel can be evaluated:

E-field probes : $E_i = \sqrt{\frac{V_i}{Norm_i ConvF}}$

 $\text{H-field probes}: \quad \boldsymbol{H}_i \ = \ \sqrt{V_i} \, \frac{a_{i0+} a_{i1} f + a_{i2} f}{f}$

with

 V_i = compensated signal of channel i (i = x, y, z)

Norm_i = sensor sensitivity of channel i (i = x, y, z)

μV/(V/m)2 for E-field Probes

ConvF = sensitivity enhancement in solution

a, = sensor sensitivity factors for H-field probes

f = carrier frequency [GHz]

 E_i = electric field strength of channel i in V/m

 H_i = magnetic field strength of channel i in A/m

The RSS value of the field components gives the total field strength (Hermitian magnitude):

$$E_{tot} = \sqrt{E_x^2 + E_y^2 + E_z^2}$$

The primary field data are used to calculate the derived field units.

SAR =
$$E_{tot}^2 \cdot \frac{\sigma}{\rho \cdot 1000}$$

with

SAR = local specific absorption rate in mW/g

Etot = total field strength in V/m

 σ = conductivity in [mho/m] or [Siemens/m]

 ρ = equivalent tissue density in g/cm³

* Note that the density is set to 1, to account for actual head tissue density rather than the density of the tissue simulating liquid.

The power flow density is calculated assuming the excitation field to be a free space field.

$$P_{pwe} = \frac{E_{tot}^2}{3770}$$
 or $P_{pwe} = H_{tot}^2 \cdot 37.7$

with

Ppwe = equivalent power density of a plane wave in mW/cm²

Etot = total electric field strength in V/m

Htot = total magnetic field strength in A/m

SPORTON INTERNATIONAL INC.

TEL: 886-3-327-3456 FAX: 886-3-328-4978 FCC ID: WVBW172A Page Number : 17 of 31

Report Issued Date: May 26, 2009

Report No.: FA951106

: Rev. 01 Report Version

5.8 Test Equipment List

Manufacturer	Name of Familian and	Turne/Mandal	Carial Namehan	Calib	ration
Manufacturer	Name of Equipment	Type/Model	Serial Number	Last Cal.	Due Date
SPEAG	Dosimetric E-Filed Probe	ET3DV6	1787	Aug. 26, 2008	Aug. 25, 2009
SPEAG	Dosimetric E-Filed Probe	ET3DV6	1788	Sep. 23, 2008	Sep. 22, 2009
SPEAG	Dosimetric E-Filed Probe	EX3DV3	3514	Jan. 21, 2009	Jan. 20, 2010
SPEAG	835MHz System Validation Kit	D835V2	499	Mar. 17, 2008	Mar. 16, 2010
SPEAG	900MHz System Validation Kit	D900V2	190	Jul. 16, 2007	Jul. 15, 2009
SPEAG	1800MHz System Validation Kit	D1800V2	2d076	Jul. 10, 2007	Jul. 09, 2009
SPEAG	1900MHz System Validation Kit	D1900V2	5d041	Mar. 28, 2008	Mar. 27, 2010
SPEAG	2000MHz System Validation Kit	D2000V2	1010	Sep. 17, 2008	Sep. 16, 2010
SPEAG	2300MHz System Validation Kit	D2300V2	1006	Sep. 12, 2007	Sep. 11, 2009
SPEAG	2450MHz System Validation Kit	D2450V2	736	Jul. 12, 2007	Jul. 11, 2009
SPEAG	2600MHz System Validation Kit	D2600V2	1008	Sep. 12, 2007	Sep. 11, 2009
SPEAG	3500MHz System Validation Kit	D3500V2	1014	Sep. 19, 2007	Sep. 18, 2009
SPEAG	5GHz System Validation Kit	D5GHzV2	1006	Jan. 24, 2008	Jan. 23, 2010
SPEAG	Data Acquisition Electronics	DAE3	577	Nov. 12, 2008	Nov. 11, 2009
SPEAG	Data Acquisition Electronics	DAE3	393	Aug. 25, 2008	Aug. 24, 2009
SPEAG	Data Acquisition Electronics	DAE4	778	Sep. 22, 2008	Sep. 21, 2009
SPEAG	Device Holder	N/A	N/A	NCR	NCR
SPEAG	SAM Phantom	QD 000 P40 C	TP-1303	NCR	NCR
SPEAG	SAM Phantom	QD 000 P40 C	TP-1383	NCR	NCR
SPEAG	SAM Phantom	QD 000 P40 C	TP-1446	NCR	NCR
SPEAG	SAM Phantom	QD 000 P40 C	TP-1477	NCR	NCR
SPEAG	ELI4 Phantom	QD 0VA 001 BB	1026	NCR	NCR
SPEAG	ELI4 Phantom	QD 0VA 001 BA	1029	NCR	NCR
Agilent	PNA Series Network Analyzer	E8358A	US40260131	Apr. 17, 2009	Apr. 16, 2010
Agilent	Wireless Communication Test Set	E5515C	MY48360820	Dec. 15, 2008	Dec. 14, 2009
R&S	Universal Radio Communication Tester	CMU200	105934	Nov. 11, 2008	Nov. 10, 2009
Agilent	Dielectric Probe Kit	85070D	US01440205	NCR	NCR
Agilent	Dual Directional Coupler	778D	50422	NCR	NCR
AR	Power Amplifier	5S1G4M2	0328767	NCR	NCR
R&S	Power Meter	NRVD	101394	Oct. 20, 2008	Oct. 19, 2009
R&S	Power Sensor	NRV-Z1	100130	Oct. 20, 2008	Oct. 19, 2009

Table 5.1 Test Equipment List

SPORTON INTERNATIONAL INC.

TEL: 886-3-327-3456 FAX: 886-3-328-4978 FCC ID: WVBW172A Page Number : 18 of 31
Report Issued Date : May 26, 2009

Report No.: FA951106

6. <u>Tissue Simulating Liquids</u>

For the measurement of the field distribution inside the SAM phantom with DASY4, the phantom must be filled with around 25 liters of homogeneous tissue simulating liquid. The liquid height from the ear reference point (ERP) of the phantom to the liquid top surface is (head SAR)or from the flat phantom to the liquid top surface (body SAR) is 15.2cm.

Report No.: FA951106

The following ingredients for tissue simulating liquid are used:

- **Water:** deionized water (pure H20), resistivity \ge 16MΩ- as basis for the liquid
- > Sugar: refined sugar in crystals, as available in food shops to reduce relative permittivity
- Salt: pure NaCl to increase conductivity
- ➤ **Cellulose**: Hydroxyethyl-cellulose, medium viscosity (75-125 mPa.s, 2% in water, 20°C), CAS#54290-to increase viscosity and to keep sugar in solution.
- Preservative: Preventol D-7 Bayer AG, D-51368 Leverkusen, CAS#55965-84-9- to prevent the spread of bacteria and molds.
- ➤ DGMBE: Deithlenglycol-monobuthyl ether (DGMBE), Fluka Chemie GmbH, CAS#112-34-5 to reduce relative permittivity.

Table 6.1 gives the recipes for tissue simulating liquid.

Table 0.1 gives the recipes for tissue simulating liquid.								
Frequency	Water	Sugar	Cellulose	Salt	Preventol	DGBE	Conductivity	Permittivity
(MHz)	(%)	(%)	(%)	(%)	(%)	(%)	(σ)	(ε _r)
				For Head				
835	40.3	57.9	0.2	1.4	0.2	0	0.90	41.5
900	40.3	57.9	0.2	1.4	0.2	0	0.97	41.5
1800, 1900, 2000	55.2	0	0	0.3	0	44.5	1.40	40.0
2450	55.0	0	0	0	0	45.0	1.80	39.2
		_		For Body		_		
835	50.8	48.2	0	0.9	0.1	0	0.97	55.2
900	50.8	48.2	0	0.9	0.1	0	1.05	55.0
1800, 1900, 2000	70.2	0	0	0.4	0	29.4	1.52	53.3
2450	68.6	0	0	0	0	31.4	1.95	52.7

Table 6.1 Recipes of Tissue Simulating Liquid

 SPORTON INTERNATIONAL INC.
 Page Number
 : 19 of 31

 TEL: 886-3-327-3456
 Report Issued Date
 : May 26, 2009

 FAX: 886-3-328-4978
 Report Version
 : Rev. 01

FCC ID: WVBW172A

Report No. : FA951106

Table 6.2 gives the targets for tissue simulating liquid.

Frequency (MHz)	Liquid Type	Conductivity (σ)	±5% Range	Permittivity (ε _r)	±5% Range
835	Head	0.90	0.86 ~ 0.95	41.5	39.4 ~ 43.6
900	Head	0.97	0.92 ~ 1.02	41.5	39.4 ~ 43.6
1800, 1900, 2000	Head	1.40	1.33 ~ 1.47	40.0	38.0 ~ 42.0
2450	Head	1.80	1.71 ~ 1.89	39.2	37.2 ~ 41.2
835	Body	0.97	0.92 ~ 1.02	55.2	52.4 ~ 58.0
900	Body	1.05	1.00 ~ 1.10	55.0	52.3 ~ 57.8
1800, 1900, 2000	Body	1.52	1.44 ~ 1.60	53.3	50.6 ~ 56.0
2450	Body	1.95	1.85 ~ 2.05	52.7	50.1 ~ 55.3

Table 6.2 Targets of Tissue Simulating Liquid

The dielectric parameters of the liquids were verified prior to the SAR evaluation using an Agilent 85070D Dielectric Probe Kit and an Agilent Network Analyzer.

Table 6.3 shows the measuring results for simulating liquid.

Frequency (MHz)	Liquid Type	Temperature (°C)	Conductivity (σ)	Permittivity (ϵ_r)	Measurement Date
835	Head	21.4	0.896	41.3	May 14. 2009
1900	Head	21.5	1.43	39.0	May 14. 2009
835	Body	21.7	0.983	54.4	May 19. 2009
1900	Body	21.2	1.55	52.1	May 19. 2009

Table 6.3 Measuring Results for Simulating Liquid

SPORTON INTERNATIONAL INC. TEL: 886-3-327-3456

FAX : 886-3-328-4978 FCC ID : WVBW172A Page Number : 20 of 31
Report Issued Date : May 26, 2009
Report Version : Rev. 01

7. <u>Uncertainty Assessment</u>

The component of uncertainly may generally be categorized according to the methods used to evaluate them. The evaluation of uncertainly by the statistical analysis of a series of observations is termed a Type An evaluation of uncertainty. The evaluation of uncertainty by means other than the statistical analysis of a series of observation is termed a Type B evaluation of uncertainty. Each component of uncertainty, however evaluated, is represented by an estimated standard deviation, termed standard uncertainty, which is determined by the positive square root of the estimated variance.

A Type A evaluation of standard uncertainty may be based on any valid statistical method for treating data. This includes calculating the standard deviation of the mean of a series of independent observations; using the method of least squares to fit a curve to the data in order to estimate the parameter of the curve and their standard deviations; or carrying out an analysis of variance in order to identify and quantify random effects in certain kinds of measurement.

A type B evaluation of standard uncertainty is typically based on scientific judgment using all of the relevant information available. These may include previous measurement data, experience and knowledge of the behavior and properties of relevant materials and instruments, manufacture's specification, data provided in calibration reports and uncertainties assigned to reference data taken from handbooks. Broadly speaking, the uncertainty is either obtained from an outdoor source or obtained from an assumed distribution, such as the normal distribution, rectangular or triangular distributions indicated in Table 7.1

Uncertainty Distributions	Normal	Rectangular	Triangular	U-shape
Multiplying factor ^(a)	1/k ^(b)	1/√3	1/√6	1/√2

⁽a) standard uncertainty is determined as the product of the multiplying factor and the estimated range of variations in the measured quantity

(b) κ is the coverage factor

Table 7.1 Standard Uncertainty for Assumed Distribution

The combined standard uncertainty of the measurement result represents the estimated standard deviation of the result. It is obtained by combining the individual standard uncertainties of both Type A and Type B evaluation using the usual "root-sum-squares" (RSS) methods of combining standard deviations by taking the positive square root of the estimated variances.

Expanded uncertainty is a measure of uncertainty that defines an interval about the measurement result within which the measured value is confidently believed to lie. It is obtained by multiplying the combined standard uncertainty by a coverage factor. Typically, the coverage factor ranges from 2 to 3. Using a coverage factor allows the true value of a measured quantity to be specified with a defined probability within the specified uncertainty range. For purpose of this document, a coverage factor two is used, which corresponds to confidence interval of about 95 %. The DASY4 uncertainty Budget is showed in Table 7.2.

SPORTON INTERNATIONAL INC.

TEL: 886-3-327-3456 FAX: 886-3-328-4978 FCC ID: WVBW172A

Page Number : 21 of 31 Report Issued Date: May 26, 2009

Report No. : FA951106

: Rev. 01 Report Version

FCC SAR	Test Report
---------	-------------

Error Description	Uncertainty Value ± %	Probability Distribution	Divisor	Ci (1g)	Standard Unc. (1g)	vi or Veff
Measurement Equipment						
Probe Calibration	±5.9 %	Normal	1	1	±5.9 %	∞
Axial Isotropy	±4.7 %	Rectangular	√3	0.7	±1.9 %	∞
Hemispherical Isotropy	±9.6 %	Rectangular	√3	0.7	±3.9 %	8
Boundary Effects	±1.0 %	Rectangular	√3	1	±0.6 %	8
Linearity	±4.7 %	Rectangular	√3	1	±2.7 %	8
System Detection Limits	±1.0 %	Rectangular	√3	1	±0.6 %	8
Readout Electronics	±0.3 %	Normal	1	1	±0.3 %	8
Response Time	±0.8 %	Rectangular	√3	1	±0.5 %	8
Integration Time	±2.6 %	Rectangular	√3	1	±1.5 %	8
RF Ambient Noise	±3.0 %	Rectangular	√3	1	±1.7 %	8
RF Ambient Reflections	±3.0 %	Rectangular	√3	1	±1.7 %	8
Probe Positioner	±0.4 %	Rectangular	√3	1	±0.2 %	8
Probe Positioning	±2.9 %	Rectangular	√3	1	±1.7 %	8
Max. SAR Eval.	±1.0 %	Rectangular	√3	1	±0.6 %	8
Test Sample Related						
Device Positioning	±2.9 %	Normal	1	1	±2.9	145
Device Holder	±3.6 %	Normal	1	1	±3.6	5
Power Drift	±5.0 %	Rectangular	√3	1	±2.9	8
Phantom and Setup						
Phantom Uncertainty	±4.0 %	Rectangular	√3	1	±2.3	8
Liquid Conductivity (target)	±5.0 %	Rectangular	√3	0.64	±1.8	8
Liquid Conductivity (meas.)	±2.5 %	Normal	1	0.64	±1.6	8
Liquid Permittivity (target)	±5.0 %	Rectangular	√3	0.6	±1.7	8
Liquid Permittivity (meas.)	±2.5 %	Normal	1	0.6	±1.5	8
Combined Standard Uncertainty					±10.9	387
Coverage Factor for 95 %		K=2				
Expanded uncertainty (Coverage factor = 2)					±21.9	

Report No.: FA951106

Table 7.2 Uncertainty Budget of DASY4

 SPORTON INTERNATIONAL INC.
 Page Number
 : 22 of 31

 TEL: 886-3-327-3456
 Report Issued Date
 : May 26, 2009

 FAX: 886-3-328-4978
 Report Version
 : Rev. 01

FCC ID: WVBW172A



8. SAR Measurement Evaluation

Each DASY4 system is equipped with one or more system validation kits. These units, together with the predefined measurement procedures within the DASY4 software, enable the user to conduct the system performance check and system validation. System validation kit includes a dipole, tripod holder to fix it underneath the flat phantom and a corresponding distance holder.

8.1 Purpose of System Performance check

The system performance check verifies that the system operates within its specifications. System and operator errors can be detected and corrected. It is recommended that the system performance check be performed prior to any usage of the system in order to guarantee reproducible results. The system performance check uses normal SAR measurements in a simplified setup with a well characterized source. This setup was selected to give a high sensitivity to all parameters that might fail or vary over time. The system check does not intend to replace the calibration of the components, but indicates situations where the system uncertainty is exceeded due to drift or failure.

8.2 System Setup

In the simplified setup for system evaluation, the DUT is replaced by a calibrated dipole and the power source is replaced by a continuous wave which comes from a signal generator at frequency 835 MHz and 1900 MHz. The calibrated dipole must be placed beneath the flat phantom section of the SAM twin phantom with the correct distance holder. The distance holder should touch the phantom surface with a light pressure at the reference marking and be oriented parallel to the long side of the phantom. The equipment setup is shown below:




Fig. 8.1 System Setup for System Evaluation

SPORTON INTERNATIONAL INC.

TEL: 886-3-327-3456 FAX: 886-3-328-4978 FCC ID: WVBW172A Page Number : 23 of 31
Report Issued Date : May 26, 2009
Report Version : Rev. 01



- Signal Generator 1.
- 2. Amplifier
- 3. **Directional Coupler**
- 4. **Power Meter**
- 835 MHz or 1900 MHz Dipole 5.

The output power on dipole port must be calibrated to 20dBm (100mW) before dipole is connected.



Fig 8.2 Dipole Setup

TEL: 886-3-327-3456 FAX: 886-3-328-4978 FCC ID: WVBW172A

Page Number : 24 of 31 Report Issued Date: May 26, 2009

Report No.: FA951106

8.3 Validation Results

Comparing to the original SAR value provided by SPEAG, the validation data should be within its specification of 10 %. Table 8.1 shows the target SAR and measured SAR after normalized to 1W input power. The table below indicates the system performance check can meet the variation criterion.

Measurement Date	Frequency (MHz)	Targeted SAR _{1g} (W/kg)	Measured SAR _{1g} (W/kg)	Deviation (%)
May 14. 2009	835	9.16	8.82	-3.71
May 14. 2009	1900	39.50	40.20	1.77
May 19. 2009	835	9.52	9.48	-0.42
May 19. 2009	1900	40.10	40.50	1.00

Table 8.1 Target and Measurement SAR after Normalized

SPORTON INTERNATIONAL INC.
TEL: 886-3-327-3456

FAX: 886-3-328-4978 FCC ID: WVBW172A Page Number : 25 of 31
Report Issued Date : May 26, 2009
Report Version : Rev. 01

9. <u>Description for DUT Testing Position</u>

This DUT was tested in six different positions. They are right cheek, right tilted, left cheek, left tilted, face of the DUT with phantom 15 mm gap and bottom of the DUT with phantom 15 mm gap as illustrated below: (Please refer to Appendix E for the test setup photos.)

1) "Cheek Position"

- i) To position the device with the vertical center line of the body of the device and the horizontal line crossing the center piece in a plane parallel to the sagittal plane of the phantom. While maintaining the device in this plane, align the vertical center line with the reference plane containing the three ear and mouth reference point (M, RE and LE) and align the center of the ear piece with the line RE-LE.
- ii) To move the device towards the phantom with the ear piece aligned with the line LE-RE until the phone touched the ear. While maintaining the device in the reference plane and maintaining the phone contact with the ear, move the bottom of the phone until any point on the front side is in contact with the cheek of the phantom or until contact with the ear is lost (see Fig. 9.1).

2) "Tilted Position"

- i) To position the device in the "cheek" position described above
- ii) While maintaining the device the reference plane described above and pivoting against the ear, moves it outward away from the mouth by an angle of 15 degrees or until contact with the ear is lost (sees Fig. 9.2).

3) "Body Worn"

- i) To position the device parallel to the phantom surface with either keypad up or down.
- ii) To adjust the device parallel to the flat phantom.
- iii) To adjust the distance between the device surface and the flat phantom to 15 mm.

SPORTON INTERNATIONAL INC.

TEL: 886-3-327-3456 FAX: 886-3-328-4978 FCC ID: WVBW172A Page Number : 26 of 31
Report Issued Date : May 26, 2009
Report Version : Rev. 01




Fig. 9.1 Phone Position 1, "Cheek" or "Touch" Position. The reference points for the right ear (RE), left ear (LE) and mouth (M), which define the plane for phone positioning, are indicated.




Fig. 9.2 Phone Position 2, "Tilted Position". The reference point for the right ear (RE), left ear (LE) and mouth (M), which define the plane for phone positioning, are indicated.

TEL: 886-3-327-3456 FAX: 886-3-328-4978 FCC ID: WVBW172A Page Number : 27 of 31
Report Issued Date : May 26, 2009

Report No.: FA951106



10. Measurement Procedures

The measurement procedures are as follows:

- Linking DUT with base station emulator CMU200 in middle channel
- Setting CMU200 to allow DUT to radiate maximum output power
- Measuring output power through RF cable and power meter
- Placing the DUT in the positions described in the last section
- Setting scan area, grid size and other setting on the DASY4 software
- > Taking data for the middle channel on each testing position
- Finding out the largest SAR result on these testing positions of each band
- Measuring output power and SAR results for the lowest and highest channels in this worst case testing position

According to the OET Bulletin 65 Supplement C standard, the recommended procedure for assessing the peak spatial-average SAR value consists of the following steps:

- Power reference measurement
- Area scan
- Zoom scan
- Power reference measurement

10.1 Spatial Peak SAR Evaluation

The procedure for spatial peak SAR evaluation has been implemented according to the OET Bulletin 65 Supplement C standard. It can be conducted for 1g and 10g, as well as for user-specific masses. The DASY4 software includes all numerical procedures necessary to evaluate the spatial peak SAR value.

The base for the evaluation is a "cube" measurement. The measured volume must include the 1g and 10g cubes with the highest averaged SAR values. For that purpose, the center of the measured volume is aligned to the interpolated peak SAR value of a previously performed area scan.

SPORTON INTERNATIONAL INC.

TEL: 886-3-327-3456 FAX: 886-3-328-4978 FCC ID: WVBW172A Page Number : 28 of 31
Report Issued Date : May 26, 2009

Report No.: FA951106



The entire evaluation of the spatial peak values is performed within the post-processing engine (SEMCAD). The system always gives the maximum values for the 1g and 10g cubes. The algorithm to find the cube with highest averaged SAR is divided into the following stages:

- extraction of the measured data (grid and values) from the Zoom Scan
- calculation of the SAR value at every measurement point based on all stored data (A/D values and measurement parameters)
- generation of a high-resolution mesh within the measured volume
- interpolation of all measured values form the measurement grid to the high-resolution grid
- extrapolation of the entire 3-D field distribution to the phantom surface over the distance from sensor to surface
- calculation of the averaged SAR within masses of 1g and 10g

10.2 Scan Procedures

First Area Scan is used to locate the approximate location(s) of the local peak SAR value(s). The measurement grid within an Area Scan is defined by the grid extent, grid step size and grid offset. Next, in order to determine the EM field distribution in a three-dimensional spatial extension, Zoom Scan is required. The Zoom Scan measures 5x5x7 points with step size 8, 8 and 5 mm. The Zoom Scan is performed around the highest E-field value to determine the averaged SAR-distribution over 1 g.

10.3SAR Averaged Methods

In DASY4, the interpolation and extrapolation are both based on the modified Quadratic Shepard's method. The interpolation scheme combines a least-square fitted function method and a weighted average method which are the two basic types of computational interpolation and approximation.

Extrapolation routines are used to obtain SAR values between the lowest measurement points and the inner phantom surface. The extrapolation distance is determined by the surface detection distance and the probe sensor offset. The uncertainty increases with the extrapolation distance. To keep the uncertainty within 1% for the 1 g and 10 g cubes, the extrapolation distance should not be larger than 5 mm.

SPORTON INTERNATIONAL INC.

TEL: 886-3-327-3456 FAX: 886-3-328-4978 FCC ID: WVBW172A

Page Number : 29 of 31 Report Issued Date: May 26, 2009

Report No.: FA951106



11. SAR Test Results

11.1 Conducted Power

Conducted Power							
Band	GSM850			GSM1900			
Channel	128	189	251	512	661	810	
Frequency	824.2	836.4	848.8	1850.2	1880	1909.8	
GSM	32.26	32.17	31.54	29.53	29.29	29.47	

(*Unit: dBm)

Report No.: FA951106

11.2 Test Records for Head SAR Test

Plot No.	Position	Band	Chan.	Freq. (MHz)	Measured 1g SAR (W/kg)	Limit (W/kg)	Result
#01	Right Cheek	GSM850	189	836.4	1.53	1.6	Pass
#02	Right Tilted	GSM850	189	836.4	0.733	1.6	Pass
#03	Left Cheek	GSM850	189	836.4	1.47	1.6	Pass
#04	Left Tilted	GSM850	189	836.4	0.684	1.6	Pass
#05	Right Cheek	GSM850	128	824.2	1.24	1.6	Pass
#06	Right Cheek	GSM850	251	848.8	1.57	1.6	Pass
#07	Left Cheek	GSM850	128	824.2	1.24	1.6	Pass
#08	Left Cheek	GSM850	251	848.8	1.52	1.6	Pass
#09	Right Cheek	GSM1900	661	1880.0	0.855	1.6	Pass
#10	Right Tilted	GSM1900	661	1880.0	0.231	1.6	Pass
#11	Left Cheek	GSM1900	661	1880.0	0.96	1.6	Pass
#12	Left Tilted	GSM1900	661	1880.0	0.204	1.6	Pass
#13	Right Cheek	GSM1900	512	1850.2	0.72	1.6	Pass
#14	Right Cheek	GSM1900	810	1909.8	1.02	1.6	Pass
#15	Left Cheek	GSM1900	512	1850.2	0.806	1.6	Pass
#16	Left Cheek	GSM1900	810	1909.8	1.09	1.6	Pass

11.3 Test Records for Body SAR Test

Test Necolds for Body SAN Test							
Plot No.	Position	Band	Chan.	Freq. (MHz)	Measured 1g SAR (W/kg)	Limit (W/kg)	Result
#21	Bottom with 15mm Gap	GSM850	189	836.4	0.751	1.6	Pass
#22	Face with 15mm Gap	GSM850	189	836.4	0.664	1.6	Pass
#23	Bottom with 15mm Gap	GSM850	128	824.2	0.540	1.6	Pass
#24	Bottom with 15mm Gap	GSM850	251	848.8	0.786	1.6	Pass
#17	Bottom with 15mm Gap	GSM1900	661	1880.0	0.310	1.6	Pass
#18	Face with 15mm Gap	GSM1900	661	1880.0	0.367	1.6	Pass
#19	Face with 15mm Gap	GSM1900	512	1850.2	0.317	1.6	Pass
#20	Face with 15mm Gap	GSM1900	810	1909.8	0.4	1.6	Pass

Test Engineer: Jason Wang

SPORTON INTERNATIONAL INC.

TEL: 886-3-327-3456 FAX: 886-3-328-4978 FCC ID: WVBW172A

Page Number : 30 of 31 Report Issued Date: May 26, 2009



12. References

[1] FCC 47 CFR Part 2 "Frequency Allocations and Radio Treaty Matters; General Rules and Regulations"

Report No.: FA951106

- [2] IEEE Std. 1528-2003, "Recommended Practice for Determining the Peak Spatial-Average Specific Absorption Rate (SAR) in the Human Head from Wireless Communications Devices: Measurement Techniques"
- [3] Supplement C (Edition 01-01) to OET Bulletin 65 (Edition 97-01), "Additional Information for Evaluating Compliance of Mobile and Portable Devices with FCC Limits for Human Exposure to RF Emissions", June 2001
- [4] IEEE Std. C95.1-1999, "IEEE Standard for Safety Levels with Respect to Human Exposure to Radio Frequency Electromagnetic Fields, 3 kHz to 300 GHz", 1999
- [5] DASY4 System Handbook

 SPORTON INTERNATIONAL INC.
 Page Number
 : 31 of 31

 TEL: 886-3-327-3456
 Report Issued Date
 : May 26, 2009

 FAX: 886-3-328-4978
 Report Version
 : Rev. 01

FCC ID: WVBW172A



Appendix A - System Performance Check Data

Please refer to the system performance check data as below.

SPORTON INTERNATIONAL INC.

TEL: 886-3-327-3456 FAX: 886-3-328-4978 FCC ID: WVBW172A Report Issued Date: May 26, 2009

Report No.: FA951106



Appendix B - SAR Measurement Data

Please refer to the SAR measurement data as below.

SPORTON INTERNATIONAL INC.

TEL: 886-3-327-3456 FAX: 886-3-328-4978 FCC ID: WVBW172A Report Issued Date: May 26, 2009

Report No.: FA951106



Appendix C - Calibration Data

Please refer to the calibration certificates of DASY as below.

SPORTON INTERNATIONAL INC.

TEL: 886-3-327-3456 FAX: 886-3-328-4978 FCC ID: WVBW172A Report Issued Date : May 26, 2009
Report Version : Rev. 01