LORD QUICK START GUIDE

G-Link®-200-OEM High-Speed Triaxial Accelerometer Node

The G-Link-200-OEM wireless accelerometer node features an on-board triaxial accelerometer that allows high-resolution data acquisition at noise levels as low as 25 or 80 µg \sqrt{Hz} . The G-Link-200-OEM can output continuous waveform data, or one of four derived channels, including Velocity (IPS_{rms}), Amplitude (G_{rms} and G_{pk-pk}) and Crest Factor, allowing long-term monitoring of key performance indicators while maximizing battery life. To acquire sensor data, the G-Link-200-OEM is used with a LORD Sensing WSDA gateway, and comes with the following configuration options.



	Configuration Option	Antenna Gain
	Integrated chip antenna	1.5 dBi
	MMCX interface:IP67 rated whip antenna, 1 m cable	2.0 dBi
G-Link-200 OEM PCB	MMCX interface: Indoor rated whip antenna, 12" cable	2.5 dBi
	U.FL interface:Flag antenna, 4" cable	2.5 dBi
	U.FL interface: Stub antenna, 2" cable	-0.9 dBi
	Calibration Certificate	

Table 1 - G-Link-200-OEMConfiguration Options

Part	Description	
Power Interface Kit Power connector and mating cable		
Mounting Kit	Mounting board, 4 screws	

Table 2 - G-Link-200-OEM Parts





Indicator	Behavior	Node Status	
	OFF	Node is OFF	
	Rapid green flashing on start-up	Node is booting up	
Device	1 (slow) green pulse per second	Node is idle and waiting for a command	
indicator	1 green blink every 2 seconds	Node is sampling	
	Blue LED during sampling	Node is resynchronizing	
	Red LED	Built-in test error	

Table 3 - Indicator Behaviors



SYSTEM OPERATION

Sensor nodes have three operational modes: *active*, *sleep*, and *idle*. When the node is sampling, it is in active mode. When sampling stops, the node is switched into idle mode, which is used for configuring node settings, and allows toggling between sampling and sleeping modes. The node will automatically go into the ultra low-power sleep mode after a user-determined period of inactivity. The node will not go into sleep mode while sampling.



Figure 2 - Node Operational Modes

1. Install Software

Install the **SensorConnect** software on the host computer before connecting any hardware. Access the free software download on the LORD Sensing website at:



http://www.microstrain.com/software

2. Establish Gateway Communication

Drivers for the USB gateways are included the SensorConnect software installation. With the software installed, the USB gateway will be detected automatically whenever the gateway is plugged in.

- 1. Power is applied to the gateway through the USB connection. Verify the gateway status indicator is illuminated, showing the gateway is connected and powered on.
- 2. Open the SensorConnect[™] software.
- 3. The gateway should appear in the Controller window automatically with a communication port assignment. If the gateway is not automatically discovered, verify the port is active on the host computer, and then remove and re-insert the USB connector.

Home Devices	Data		
~ 므 local		Base Sta	ition 47215
✓ ♥ Base Station 47215	2	Frequency	24
		Serial	6307-1040-47215
		Firmware	3.31
		Connection	Serial, COM5, 921600

Figure 3 - USB Gateway Communication



3. Connect to Nodes

Several methods can be used in SensorConnect to establish communication with the nodes: the automatic node discovery on the same frequency, automatic node discovery on a different frequency, and add node manually.

A. Automatic Node Discovery on Same Frequency

If the base and node are on the same operating frequency, the node will populate below the Base Station listing when powering on the G-Link-200- $\mbox{OEM}.$



B. Automatic Node Discovery on Different Frequency

If a red circle with a number appears next to the Base Station, the node is operating on a separate radio channel. Select the Base Station and then select the Nodes on Other Frequencies tile.

Home Devices Data		
~ 므 local	Base Sta	tion 00001
 Base Station 00001 	Frequency	18
🕫 Node 197	Serial	6307-0200-00001
Node 32235	Firmware	4.37110
C HOUC SEESS	Connection	Serial, COM7, 3000000
		≡ ∔ Nodes on Other Frequencies

Highlight the new node being added and select Move Node to Frequency (#).

Select a Node to move to this BaseStation's frequency.				
Node 🛝	Frequency 1	Last Heard		
61506	13	6 minutes ago		
62884	11	8 minutes ago		

C Refresh

Move Node to Frequency 24



C. Manually Add Node

Adding a node manually requires entering the node address and its current frequency setting.

From the Base Station, select the Manual Add Node tile, enter the Node Address, last known Frequency (factory default is 15), and select Add Node.

Node Addre	255
197	4
Frequency	

If the node failed to be added, a failure message will appear. This means the node did not respond to the base station which could indicate the node is not in idle mode or it may be on another frequency. If "Add Node Anyway" is selected, it will associate that node with the channel entered but it is likely there will be a communication error. If the node was not in idle, move the base station to the frequency of the node and issue a "Set to Idle" command.

Failed to Find Node 9 ×
Unable to communicate with Node 9 on frequency 20. The Node may be out of range, sampling, or in a low power sleep state. Do you want to add it to frequency 20 anyway?
Add Node Anyway Cancel

If the node was successfully added, two confirmation messages will appear and it will be listed under the Base Station.





4. Configure Node

Node settings are stored to non-volatile memory and may be configured using SensorConnect. To access the node configuration menu, under Devices select the node and then the Configure tile.

Home	Devices	Data		
~ 므 local			Base Sta	tion 47215
~ 📦 Bas	e Station 4721	5	Frequency	24
ON N	ode 8000	•	Serial	6307-1040-47215
			Firmware	3.31
			Connection	Serial, COM5, 921600
Setu	Configure	;	S Cycle Power	Range Test

The configuration menus show the channels and configuration options available for the type of node being used.

Wireless Node Configuration					
Hardware	Calibra	ation	Sampling	Power	
Input Range					
	Channel(s)	Input Range			
	1, 2, 3	±2 G's (accelera	ation) 🔻		
Low Pass Filter					
	Channel(s)	Filter Cutoff			
	1, 2, 3	26 Hz	¥		
High Pass Filter					
	Channel(s)	Setting			
	1, 2, 3	Disabled	*		

Figure 4 - Node Configuration

5. Configure Sampling Setting and Start Data Acquisition

- 1. Left click on the Base Station > Sampling, and indicate the nodes to be sampled by checking the box to the left of each node.
- 2. Under 3 Channels, select Raw Channels, ch1, ch2 and ch3 from the drop down menu.
- 3. Under Sampling, select Sample Rate from the drop down menu, select Continuously to sample indefinitely.



Figure 5 - Sampling Setting

- 4. Select Apply and Start Network.
- 5. Select Create Quick View Dashboard in the pop up window immediately to create a dashboard of the new data.



G-Link®-200-OEM Wireless Accelerometer Node Quick Start Guide



Figure 6 - Quick View Dashboard



Radio Specifications

The G-Link-200-OEM employs a 2.4GHz IEEE 802.15.4- compliant radio transceiver for wireless communication. The radio is a direct-sequence spread spectrum radio and can be configured to operate on 16 separate frequencies ranging from 2.405 GHz to 2.480 GHz. Following the 802.15.4 standard, these frequencies are aliased as channels 11 through 26. For all newly manufactured nodes, the default setting is 2.425 GHz (channel 15).

G-Link-200-OEM

FCC ID: XJQMSLINK0010

IC ID: 8505A-MSLINK0010

This device complies with Part 15 of the United States FCC Rules, and Industry Canada's license-exempt RSSs. Operation is subject to the following two conditions: 1) This device may not cause interference, and 2) This device must accept any interference, including interference that may cause undesired operation of the device. Changes or modifications, including antenna changes not expressly approved by LORD Corporation could void the user's authority to operate the equipment.

Cet appareil est conforme à la Partie 15 des Règles de la FCC des États-Unis et aux RSSS exempts de licence d'Industrie Canada. Le fonctionnement est soumis aux deux conditions suivantes: 1) Cet appareil ne doit pas causer d'interférences et 2) Cet appareil doit accepter toute interférence, y compris les interférences pouvant entraîner un fonctionnement indésirable de l'appareil. Les changements ou modifications, y compris les changements d'antenne non expressément approuvés par LORD Corporation, pourraient annuler l'autorisation de l'utilisateur d'utiliser l'équipement.

ESD Sensitivity

The G-Link-200-OEM is intended to be integrated in to an application appropriate housing to protect it from environmental elements, impact, and electrostatic discharge (ESD), which can disrupt operation or damage the PCB.



The G-Link-200-OEM is susceptible to damage and/or disruption of normal operation from Electrostatic Discharge (ESD). ESD may cause the device to reset, which may require user intervention to continue data acquisition.

LORD Corporation MicroStrain[®] Sensing Systems 459 Hurricane Lane, Suite 102 Williston, VT 05495 USA

ph: 802-862-6629 sensing_sales@LORD.com sensing_support@LORD.com

