

PERIDUO-605

•User Manual •Bedienungsanleitung •Manual de Instrucciones
 •Mode D'Emploi •Manualdo Utilizador •取扱説明書
 •产品说明书 •使用手册

VALUE CREATOR

PERIXX

Periox's warranty obligations are limited to the terms set forth below. Periox warrants this hardware product against defects in materials and workmanship for a period of two (2) years from the date of original invoice.

If you discover a defect, Periox will, at its option, repair or replace the product at no charge to you, provided you return it during the warranty period with shipping charges pre-paid to Periox. You must contact Periox for a Return Merchandise Authorization number (RMA) prior to returning any product. For each product returned for warranty service, please include your name, shipping address (to P.O. Box), telephone number, a copy of the bill of sale as proof of purchase and make sure that the package is clearly marked with your RMA number.

THE WARRANTY AND REMEDIES SET FORTH ABOVE ARE EXCLUSIVE AND IN LIEU OF ALL OTHERS, WHETHER WRITTEN, ORAL, EXPRESS OR IMPLIED. PERIOX SPECIALLY DISCLAIMS ANY AND ALL IMPLIED WARRANTIES, INCLUDING AND WITHOUT LIMITATION, WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, NO DEFECT DESIGN, AGENT OR EMPLOYEE IS AUTHORIZED TO MAKE ANY MODIFICATION, EXTENSION OR ADDITION TO THIS WARRANTY.

PERIOX IS NOT RESPONSIBLE FOR SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM ANY BREACH OF WARRANTY OR UNDER ANY LEGAL THEORY INCLUDING BUT NOT LIMITED TO LOST PROFITS, DOWNTIME, GOODWILL, DAMAGE TO OR REPLACEMENT OF EQUIPMENT OR PROPERTY AND ANY COST OF RECOVERING, REPROGRAMMING OR REPRODUCING ANY PROGRAM OR DATA STORED IN OR USED WITH PERIOX PRODUCTS. PERIOX'S MAXIMUM LIABILITY FOR ANY AND ALL DAMAGES ARISING OUT OF USE OF THE PRODUCT SHALL BE LIMITED TO THE AMOUNTS PAID BY PURCHASER FOR SUCH PRODUCT.

PERIXX

Caution

- The manufacturer and re-sellers are not responsible for any malfunctions, damages, or personal injury incurred by:
 - A misuse of the product
 - Any attempt to dismantle, change or modify the product in any manner
 - You are cautioned that changes or modifications not expressly approved by the party responsible for the compliance could void your authority to operate the equipment.
 - Mandatory repair charges are required for the following conditions, within the guarantee period:
 - Malfunction or damage is due to misuse or improper alteration or repair.
 - Malfunction or damage caused by the falling after the purchase.
 - Malfunction or damage is caused by fire, salt, gas, earthquake, lightning, wind, water, or other natural calamities, or abnormal voltage.
 - Malfunction or damage is caused by other devices connected to the keyboard.
 - All brand names, trademarks and logos are the properties of their respective owners.

Please Note: Long-term repetitive use of any keyboard could cause injury to user. Periox recommends users avoid excessive use of this or any keyboard.

PERIXX

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates use and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to the radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

PERIXX

Product Illustration

① LED Indicators (Num Lock, Caps Lock and Scroll Lock) ② Scroll Wheel/Middle Click
 ③ Keyboard Stand ④ Position 1: For Removable Magnet Foot & Keyboard Stand
 ⑤ Position 2: For Removable Magnet Foot ⑥ Battery ⑦ On/Off switch ⑧ Connect Button

PERIXX

Product Illustration

① Left Click Button ② Right Click Button ③ Scroll Wheel/Middle Click
 ④ DPI Switch: 20PI Levels: 100/2/1000
 ⑤ Forward/Backward ⑥ Backward/Forward
 ⑦ Sensor ⑧ Battery ⑨ On/Off switch ⑩ Receiver/Storage

PERIXX

Product Specification

Color	Black or White
Interface	Wireless 2.4G
Size	Keyboard: 463x277x66mm (with stand) Keyboard: 463x277x49mm (without stand) Mouse: 120x75x63mm
Weight	Keyboard: 845g Mouse: 102g
Function key	17
Operation Temperature	0°C to 45°C
Storage Temperature	-15°C to 60°C
Electrical Rating	3V
Operation voltage	≤ 5mA
Material	ABS
OS requirement	Windows XP and above

PERIXX

Installation Process

Step 1

Step 2

PERIXX

Step 3

PERIXX

Power Saving Mode & Battery Consumption

Power Saving mode helps to consume minimum power (when kept on) by turning off signal connection when the mouse is in Idle Mode and increases the battery life.

When the mouse is in power saving mode, click on any mouse button to reconnect. 2pcs of brand-new AAA battery (1100mAh) provides up to 80 days of use when you use about two hours a day.

Keyboard

	Active Mode	Static Mode	Sleeping Mode (LED off)
Stop Working Time	-	2 Sec	After 5 Minutes
Current Consumption	≤8.7mA	≤1.8mA	≤1.8mA

Mouse

	Working Mode	Static Mode	Power Saving Mode (LED off)	Power Saving Mode II (LED flash slowly)	Deeply Sleeping Mode (LED off flash slowly)
Stop Working Time	-	2 Sec	10 Sec	6 Minutes	After 8 Minutes
Current Consumption	8.7mA	≤0.8mA	≤1.8mA	≤0.5mA	≤0.3mA

PERIXX

Table of Content

ENGLISH 13
 DEUTSCH 16
 ESPAÑOL
 FRANÇAIS
 ITALIANO
 日本語
 简体中文
 e-Manual via www.periox.com

PERIXX

English(UK/US)

Caution

- The manufacturer and re-sellers are not responsible for any technical malfunctions, damages, or personal injury incurred by:
 - Any attempt to dismantle, change or modify the product in any manner
 - Malfunction or damage due to misuse or improper alteration or repair.
 - Malfunction or damage caused by external influence such as falling.
 - Malfunction or damage is caused by fire, salt, gas, earthquake, lightning, wind, water, or other natural calamities, or abnormal voltage.
 - Malfunction or damage is caused by other devices connected to the products.
 - Malfunction or damage is caused by high temperature, humid, gross, dusty and hazardous environment.
- You are cautioned that changes or modifications not expressly approved by Periox Computer GmbH could void your authority to operate the equipment.
- All brand names, trademarks and logos are the properties of their respective owners.

Please Note: Long-term repetitive use of any keyboard and mouse could cause injury to user. Periox recommends users to avoid excessive use of this or any keyboard and mouse.

PERIXX

English(UK/US)

Thank you for purchasing a Periox product. PERIDUO-605 is a user friendly full-size keyboard. It is an ideal solution for the office or home working space. It is easy to install and use with plug and play feature. There is no need to install any driver or software. You can use it with various applications like All-in-one PC, Notebook, and your Desktop PC.

System Requirements

- Operating System: Microsoft Windows XP/7/2010
- 1 x Free USB Port

Installation Process

The following steps initiate a connection process of the PERIDUO-605 to your PC:

1. Turn On the PC
2. Insert Batteries
3. Plug the USB Receiver into a free USB Port
4. The device will be automatically detected by the PC, and it should be ready to work
5. If the device is still not working, please repeat the process from step 1.
6. If the device is still not working, try to reconnect the connection by unplugging your receiver from your port and plug it back in again. Then, press and hold the connect button for 5 seconds. Periox recommends users to avoid excessive use of this or any keyboard and mouse.

PERIXX

Hot Keys

Fn + M	Media Player	Fn + C	Ctrl+Z	Fn + A	Alt
Fn + V	Volume down	Fn + S	Ctrl+Y	Fn + H	Home Page
Fn + N	Volume up	Fn + W	Ctrl+W	Fn + L	Windows Lock
Fn + H	Mute	Fn + E	My Favorite	Fn + C	Calculator
Win + Tab	Alt	Win + U	Play / Pause		
Fn + Q	Whose				

PERIXX

Deutsch (DE)

Bitte beachten Sie:

- Der Hersteller übernimmt die Verantwortung für technische Defekte, Schäden oder mögliche Verletzungen verursacht durch:
 - Versuche, den Artikel zu demontieren oder zu modifizieren.
 - Zwischenmischung oder eigene Reparaturen
 - Fremdeinwirkung wie z.B. Sturz oder Schlag
 - Feuer, Gas, Erdbeben, Blitz, Wind, Wasser, Überspannung oder jede andere Form von Baller Gefahr
 - Andere mit der Tastatur verbundene Geräte
 - Zu hohe Temperaturen oder eine feuchte, staubige oder giftige Umgebung
- Der Benutzer wird darauf hingewiesen, dass Änderungen oder Modifikationen an der Gerätschaft, die von Periox Computer GmbH nicht ausdrücklich genehmigt sind, die Garantie des Herstellers zur Inbetriebnahme des Gerätes außer Kraft setzen könnte.
- Alle Markenmarken, Warenzeichen und Logos sind Eigentum von Periox.

Die übermäßige Langzeit-Nutzung jeder Tastatur und Maus kann zu Verletzungen führen. Periox empfiehlt Benutzern den übermäßigen Gebrauch von jeglicher Tastatur und Maus zu vermeiden.

PERIXX

Deutsch (DE)

Vielen Dank für Ihren Kauf dieses Periox Produkts. Das PERIDUO-605 zeichnet sich durch seine praktische Größe und seinem suggestivem Design aus, welches sich in jede Arbeitsumgebung einpasst. Es bietet somit die ideale Lösung für Büro-, Home- und Gaming-Bedürfnisse. Durch die Plug & Play Funktion ist es leicht zu verwenden, einfach anzuschließen, es benötigt keine weiteren Treiber- oder Softwareinstallationen.

System Voraussetzungen

- Betriebssystem: Microsoft Windows XP/7/2010
- 1 x freier USB Port

Tastatur Installation:

1. Schalten Sie Ihren PC ein.
2. Legen Sie die Batterien ein.
3. Stecken Sie den USB Receiver in einen freien USB-Anschluss.
4. Das Gerät sollte nun automatisch vom PC erkannt werden und funktionsbereit sein.
5. Sollte das Gerät nicht funktionieren, wiederholen Sie bitte die Installation mit Schritt 1.
6. Wenn Ihr Gerät immer noch nicht funktioniert, schließen Sie den Empfänger erneut an und drücken Sie die "Connect"-Taste für 5 Sekunden.

PERIXX

Hot Keys

Fn + M	Media Player	Fn + C	Ctrl+Z	Fn + A	Alt
Fn + V	Volume down	Fn + S	Ctrl+Y	Fn + H	Home Page
Fn + N	Volume up	Fn + W	Ctrl+W	Fn + L	Windows Lock
Fn + H	Mute	Fn + E	My Favorite	Fn + C	Calculator
Win + Tab	Alt	Win + U	Play / Pause		
Fn + Q	Whose				

PERIXX

Deutsch (DE)

Bitte beachten Sie:

- Der Hersteller übernimmt die Verantwortung für technische Defekte, Schäden oder mögliche Verletzungen verursacht durch:
 - Versuche, den Artikel zu demontieren oder zu modifizieren.
 - Zwischenmischung oder eigene Reparaturen
 - Fremdeinwirkung wie z.B. Sturz oder Schlag
 - Feuer, Gas, Erdbeben, Blitz, Wind, Wasser, Überspannung oder jede andere Form von Baller Gefahr
 - Andere mit der Tastatur verbundene Geräte
 - Zu hohe Temperaturen oder eine feuchte, staubige oder giftige Umgebung
- Der Benutzer wird darauf hingewiesen, dass Änderungen oder Modifikationen an der Gerätschaft, die von Periox Computer GmbH nicht ausdrücklich genehmigt sind, die Garantie des Herstellers zur Inbetriebnahme des Gerätes außer Kraft setzen könnte.
- Alle Markenmarken, Warenzeichen und Logos sind Eigentum von Periox.

Die übermäßige Langzeit-Nutzung jeder Tastatur und Maus kann zu Verletzungen führen. Periox empfiehlt Benutzern den übermäßigen Gebrauch von jeglicher Tastatur und Maus zu vermeiden.

PERIXX

Value Creator