




USER MANUAL SMART WATCH

Downloading the App

Scan the following QR code, download and install the App.


H band



Scan QR Code and Download

Charging and Active

Charging the device to active before the first time using;
To charge your device, plug the charging cable into the adapter or USB port on your computer.




Pairing



The MAC address on the "Setting"- "About" page could help you identify your device on the scanning list.

Use the Touch Screen



Phone Call

After connecting the smart Watch to the phone, you can use the watch to dial to control the phone for making calls and answering the phone calls. You can also view the call history of the watch. You need to keep the connection between the watch and the phone stable when using the Phone Call function.

Smart Watch Features

Heart Rate Test
The Smart Watch could record your heart rate all day. You also could tap on the page to start measuring heart rate.

Smart Watch Features

Blood pressure/Blood oxygen
Click on the blood pressure/blood pressure interface to measure the current blood pressure value/blood oxygen value. More detailed information analysis and data recording can view in the client.

Period reminder
Click on the menstrual period interface, through the management cycle calendar, intelligently predict victory cycles. On the period reminder page, It can show the period reminder measured data of the last times.

Smart Watch Features

Blood glucose
Click the blood glucose interface to measure the current blood glucose value. More details analysis and data records can view on the client.

ECG
ECG measurement, electrocardiogram monitoring, assessment of heart health. Raise your hand to measure your heart health status at any time. More detailed information analysis and data recording can View in the client.

Smart Watch Features

Pressure
Click on the pressure interface to measure the current pressure index. More detailed information analysis and data recording can View in the client.

Training
Tap the training icon on the menu to start a new training measure recording, Multiple sports modes to be chosen. The last training recording will be shown on the training page.

Smart Watch Features

Sleep
If you keep wearing Smart Watch When Sleeping , it can provide the hours slept and quality of sleep stats on both the screen and the APP. NOTE: Sleep stats reset to zero at 8:00 pm.

Player Shutter
After connecting the device,you can remote contral the music player on your phone.

Smart Watch Features

Remote Shutter
After connecting the device,you can remote control the camera on your phone.

Messages Reminder
The device can sync incoming notifications from Twitter, Facebook, Whatsapp, Instagram etc. Recently 5 messages can be stored. Note: You can switch on/off the incoming notification in the APP.

Smart Watch Features

Other Features
Other features include stopwatch, alarm, timer, brightness,mute on/off, theater mode,factory reset, power off and about.

Weather
It could show the weather info of current and tomorrow on the weather page. Weather info is synced after connecting with the APP, it will not be updated after a long disconnected.

Smart Watch Features

Remind to Move
The device will vibrate to remind you to make a relax after 1 hour sitting. Note: You can switch on/off the feature in the APP.

Sports
Smart Watch automatically tracks Steps taken on the screen. NOTE: Your movement stats reset to zero at midnight.

Getting to Know Your Device

1.Using in Wet Conditions
Your device is water-resistant, which means it is rain-proof and splash-proof and can stand up to even the sweatiest workout. NOTE: Do not swim with your Smart Bracelet. We also don't recommend showering with your wristband; though the water won't hurt the device, wearing it 24/7 does not give your skin a chance to breathe. Whenever you get your bracelet wet, dry it thoroughly before putting it back on.

2.Using Quick View
With Quick View you can check the time or the message form your phone on your Smart Bracelet without taping. Just turn your wrist towards you and the time screen will appear for a few seconds.

General Info & Specifications

1.Environmental Conditions
Operating temperature: 14°F to 122°F (-10°C to 50°C)
Non-operating temperature: -4°F to 140°F (-20°C to 60°C)

2.Size
Fits a wrist between 5.5 and 7.7 inches in circumference.

3.Disposal and Recycling
Please kindly be aware that it is the consumer's responsibility to properly dispose and recycle Smart Bracelet and accompanying components. Do not dispose of Smart Bracelet with common household waste, the Smart Bracelet unit is considered electronic waste and should be disposed of at your local electronic equipment collection facility. For more information, please contact your local electronic equipment waste management authority or the retailer where you bought the product.

FCC Caution :

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.