

# AMAZING C CellAllure®

## Instructions / Instrucciones English / Español



Welcome to use this smart phone

### Contents

1. SIM MicroSD method of use.....	01
2. Keyboard function .....	01
3. Manage your contacts.....	02
4. Make a phone call .....	02
5. Record the moment .....	02
6. Keep moving pieces.....	03
7. Appreciate the colorful pictures.....	03
8. Send an E-mail.....	04
9. Enjoy the wonderful music.....	04
10. Use the internet .....	04




**Warning**  
Do not use the phone while its charging in high voltage

### Know your mobile phone

Welcome you to experience the high quality of the smart hone, let us know first before use parts of the phone.

#### 1. SIM MicroSD method of use

Will screen printing graphic in SIM card according to the fuselage, inserted into the booth. Avoid registration failed, please in strict accordance with the graphic operation.



#### 2. Keyboard function

Under the arbitrary interface

- Return to the higher level interface or exit the program
- Return to the main screen
- Open the menu Settings list

Press the power key, closed or light up the screen.

At the same time hold down the power button and volume down key, capture screen.

01

#### 3. Manage your contacts

- Open the **【Contact】** .
- When using mobile phones for the first time, you can click on the contact interface **【Manage your contacts】** , contacts to other storage devices in the mobile phone. Click on the **【group】** The label. You can also contact for group classification, facilitate management.

#### 4. Make a phone call

- Open the **【Dial】** .
- You can dial telephone, or click on the seach person to make a phone call.

#### 5. Record the moment

- Open the **【Camera】**

With a back photo camera, high support intelligen, beautiful skin, HDR, special effects, such as a variety of photo mode, smiling face automatic identification function allows you to instantly captured the most satisfying smile support automatic or manual touch screen focus focus, press. Easy to obtain high quality photos.

02

#### 6. Keep moving pieces

- Open the **【Camera】** , switch to video mode

Full hd video, smooth quality ,will bring you an unprecedented video experience, press the at any time video important moments in your life.



#### 7. Appreciate the colorful pictures

- Open the **【Gallery】**

Browse pictures at any time, memories moved instantly. Choose a photo album **【Slideshow】** mobile phone to a digital photo frame, play photos for you.

Browse a picture, enter edit mode, you can cut to a photograph, color adjustment, increase the filter effects beautification operation.

03

#### 8. Send an E-mail

- Open the **【E-mail】**

Set the email account, you can through the mobile phone to send and receive E-mail, keep in touch with friends or customers anytime and anywhere.

#### 9. Enjoy the wonderful music

- Open the **【Music】**

Carrying "Sound effects+", can be attached by the ptimization of the double track earphone experience dolby surround sound, feel more natural more clear treble and bass. At the same time, the expressive force of speakers have been optimized, to bring you a higher quality of auditory enjoyment. Please use the attached with headphones.

#### 10. Use the internet

Open the starting page of the brower, users can enter into input URL, search, bookmarks, history and stored pages through the interfaces Press Menu button to open more menus: homepage, settings, clear records and exit brower homepage, and users can the homepage of ISP internet(set in advance or a when using the internet service, it is recommended that you use WIFI link network. If you use the SIM card network charge carriers.

04

**WARNING:**  
Factory Data Reset setting will delete ALL your data and system configuration as well as any downloaded apps. Please use this function carefully.

SPECIFICATIONS	
CPU/PCB solution:	SC7731E
Display:	6.8" HD+IPS Screen
SIM card support:	Dual SIM
Memory:	2GB
Storage:	16GB
GSM:	850/900/1800/1900MHz
WCDMA:	850/1700/1900MHz
Wi-Fi:	Yes
Front camera:	8MP
Rear camera:	13MP
Bluetooth:	Yes
GPS:	Yes
Fingerprint sensor:	yes
SD card support:	Up to 64GB
Charger:	Telephone 3.8V Input: 100-240V 50/60 Hz, 150mA Output: DC 5.0V 1A ca
USB:	Micro USB
Audio jack:	3.5mm jack
Battery capacity (mAh):	2800mAh Li-ion battery
Supplied accessories:	1 Handset, 1 True wireless mini BT earbuds, 1 Battery, 1 Charger, 2 User manuals, 1 Warranty card.
OS:	Android™ 8.1
Other:	FM radio, Flashlight.

Images used are for illustration purposes only and may differ from actual product. Restrictions Apply.

**Thank you for your purchase of the CellAllure® Amazing C Smartphone. We hope you enjoy your new device.**

Google, Android and other marks are trademarks of Google LLC.

05

# AMAZING C CellAllure®

www.cellallure.com



# AMAZING C CellAllure®

## Instructions / Instrucciones English / Español



Bienvenido. Aprenda a usar su teléfono

### Contenidos

1. Método de uso de la tarjeta SIM SD..... 01
2. Función del teclado ..... 01
3. Administra tus contactos..... 02
4. Realiza una llamada telefónica ..... 02
5. Captura el momento ..... 02
6. Continúa moviendo las piezas ..... 03
7. Aprecia coloridas fotos ..... 03
8. Envía un correo electrónico..... 04
9. Disfruta música maravillosa..... 04
10. Usa el internet ..... 04



### Advertencia


No use el teléfono mientras se esté cargando en alto voltaje

### Conoce tu teléfono celular

Bienvenido a la experiencia de alta calidad del CellAllure Amazing C. Conócelo antes de usarlo.

#### 1. Método de uso de la tarjeta SIM SD

Cada ranura tiene un texto indicando si es para la tarjeta SIM o SD. Para evitar daños, introduzca la tarjeta según corresponda de acuerdo a la indicación gráfica.



#### 2. Función del teclado

Debajo de la pantalla se muestran

- Regresar a la interfaz superior o salir de la aplicación
- Regresar a la pantalla principal
- Abrir la lista del menú de opciones

Presiona el botón de encendido para prender o apagar la pantalla.

Al mismo tiempo el botón de encendido y la tecla de bajar volumen para realizar una captura de pantalla.

01

### 3. Administra tus contactos

- Abre **【Contactos】**.
- Cuando uses el celular por primera vez, selecciona en la interfaz de contactos **【Administra tus contactos】**, para importar contactos de otros dispositivos. Toca la etiqueta **【Grupo】** Además puedes contactar por clasificación del grupo que facilita su administración.

#### 4. Realiza una llamada telefónica

- Abre **【Llamadas】**.
- Tu puedes marcar el teléfono o dar click en la búsqueda de personas para hacer una llamada.

#### 5. Captura el momento

Abre la **【Cámara】**


Con una cámara principal trasera, que incluye funciones como filtros de piel, HDR, efectos especiales así como una gran variedad de modos de fotografías, identificación automático de rostros te permite capturar tu sonrisa inmediatamente de manera automática o manual presionando. Facilitando la toma de increíbles fotografías.

02

### 6. Continúa moviendo las piezas

- Abre la **【Cámara】**, y cambia a modo Video.

Cuenta con video Full HD de alta calidad te ofrece una experiencia de video sin precedentes. Presiona en cualquier momento.



#### 7. Aprecia coloridas fotos

- Abre la **【Galería】**

Navega en las fotos en cualquier momento. Revive memorias instantáneamente. Selecciona en un álbum **【Diapositivas】** para transformar tu celular en un portarretratos digital y reproducir tus fotografías.

Selecciona una imagen, entra y al modo edición. Puedes cortar la fotografía, ajustar el color, incrementar los efectos del filtro.

03

### 8. Envía un correo electrónico

- Abre **【Correo electrónico】**

Configura la cuenta para recibir y enviar correos electrónicos desde el celular. Mantente en contacto con tus amigos o clientes en cualquier momento y desde cualquier lugar.

#### 9. Enjoy the wonderful music

- Abre **【Música】**

Con "Efectos de sonido+", puedes optimizar la experiencia de doble audífono con Dolby Surround. Siente unos graves y agudos más claros y naturales. Al mismo tiempo la con la fuerza optimizada de los altavoces te ofrece una mayor calidad. Por favor use la mejora con audífonos.

#### 10. Usa el internet

Abre la página de inicio del navegador. Los usuarios pueden introducir URL, búsqueda, marcadores, historial y páginas almacenadas a través de la interfaz. Presiona el botón de Menú para abrir más menús: Página de inicio, ajustes, limpiar registros y salir del explorador. Se recomienda el uso de una red WiFi. En caso de usar la red de la tarjeta SIM se pueden generar cargos adicionales.

04

#### ADVERTENCIA:

La configuración de restablecimiento de datos de fábrica eliminará TODOS los datos y la configuración del sistema, así como las aplicaciones descargadas. Utilice esta función con cuidado.

#### ESPECIFICACIONES

Procesador:	SC7731E
Pantalla:	Pantalla 6.8" HD+IPS
Tarjeta sin compatible:	Dual SIM
Memoria:	2GB
Almacenamiento:	16GB
GSM:	850/900/1800/1900MHz
WCDMA:	850/1700/1900MHz
Wi-Fi:	Sí
Cámara frontal:	8MP
Cámara trasera:	16MP
Bluetooth:	Sí
GPS:	Sí
Lector de huella:	Sí
Tarjeta SD compatible:	Hasta 64 GB
Cargador:	Teléfono 3.8V Input: 100-240V 50/60 Hz, 150mA Output: DC 5.0V 1A ca
USB:	Micro USB
Entrada de audio:	Entrada 3.5mm
Capacidad de batería (mAh):	Batería 2800mAh de Li-ion
Accesorios incluidos:	1 Teléfono, 1 audífonos inalámbricos, 1 Batería, 1 Cargador, 2 Manuales de usuarios, 1 Tarjeta de garantía.
OS:	Android™ 8.1
Otros:	Radio FM, Linterna.

Las imágenes utilizadas son solo para fines ilustrativos y pueden diferir del producto real. Se aplican restricciones.

Gracias por la compra del CellAllure® Amazing C Smartphone. Esperamos que disfrutes tu celular.

Google, Android y otras marcas son marcas comerciales de Google LLC.

05

# AMAZING C CellAllure®

www.cellallure.mx



### **FCC compliance statement**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**Important:** Changes or modifications to this product not authorized by GNJ Manufacturing Inc. could void the electromagnetic compatibility (EMC) and wireless compliance and negate your authority to operate the product.

This product has demonstrated EMC compliance under conditions that included the use of compliant peripheral devices and shielded cables between system components. It is important that you use compliant peripheral devices and shielded cables between system components to reduce the possibility of causing interference to radios, televisions, and other electronic devices.

### **SAR Statement:**

This Mobile Phone meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health.

FCC RF Exposure Information and Statement the SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types: Smart Temp (FCC ID: 2AAE9CAPHG65) has also been tested against this SAR limit. This device was tested for typical body-worn operations with the back of the handset kept 10mm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 10mm separation distance between the user's body and the back of the handset. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that

do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.

#### Body-worn Operation

This device was tested for typical body-worn operations. To comply with RF exposure requirements, a minimum separation distance of 10mm must be maintained between the user's body and the handset, including the antenna. Third-party belt-clips, holsters, and similar accessories used by this device should not contain any metallic components. Body-worn accessories that do not meet these requirements may not comply with RF exposure requirements and should be avoided. Use only the supplied or an approved antenna.