

Sound Crush Company Limited

HR-801 Twist Mini Wireless Speaker

HR-801 Twist Mini Wireless Speaker



What's Included:

- HR-801 Twist Mini Wireless Speaker
- Aux cable 3.5mm
- USB Charging Cable
- User's guide

Specifications

- Power Output: 3W
- Dimensions (HxWxD) 18x4.8x4.8cm
- Advanced Audio Distribution Profile (A2DP) for wireless music streaming
- Hands-free Audio (HFP) and Headset Profiles (HSP) for hands-free calling capability
- Range up to 10 meter
- Battery life 4 to 5 hours of playing time depending on volume settings

How to connect the HR-801 to your Bluetooth device.

1. Make sure your speaker is charged (follow charge instruction)
2. Press the power-mode button on top of the speaker for 3 seconds.
The led will turn flash blue-red indicating it is searching , then solid blue indicating it is in Bluetooth mode.

If at any time in the future you should need to dispose of this product please note that:
Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority or retailer for recycling advice. (Waste Electrical and Electronic Equipment Directive)



www.mitone.eu

3. Check the instruction manual of your smartphone or other blue tooth device and make sure the Bluetooth function is on. Make sure your device is in search or discover mode.
4. Your device will find u, connect, the led on the speaker will becomes solid blue.
5. You can now start playing your music.

How to connect the HR-801 without Bluetooth

1. Make sure your speaker is charged (follow charge instruction)
2. Turn the speaker on with the main On-Off switch at the back of the speaker.
3. Press the power-mode button on top of the speaker for 3 seconds.
4. The led will turn flash blue-red indicating it is searching , then solid blue indicating it is in Bluetooth mode. Press the power button once more (short) the led will turn solid green.
5. Connect the supplied aux cable to the aux input at the back of the speaker.
6. Connect the other end to the headphone output (3.5mm) of your smartphone or other device.



Hands free Calling

When your phone is connected to theHR-801you can use the speaker as a h nds-free device.

To accept a call, push the phone button on the speaker. You can also accept the call as you usually do on your phone.

Change Volume

Press the volume up or down to adjust to your desired volume. You can also change the volume on your audio device

Bluetooth button

Press the button to disconnect or reconnect your Bluetooth speaker.

Power LED indicator

The led indicator is located on the left side of USB charging port of the speaker.

When the LED is red the battery is charging.

When the LED is flashing the battery is low.

When the LED is off the battery is charged.

Pause your music

Push the play/pause button to play or pause your music.

Charge the Built-in Li-Ion Battery

Connect the mini USB cable at the back of the speaker. (USB charging)

Connect the other end of the cable to a USB port or to a USB AC adapter. (not included)

The red LED indicator will turn red when charging and will turn off when charging is finished.

Warning

Do not become distracted by this product while driving.

Do not leave the product exposed to a heat source or high temperatures

Do not remove or attempt to remove the Li-Ion battery

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.