


## Quick Start Guide

Dispho®

### First step: Bluetooth pairing

Touch-hold the camera key for 3 seconds till the blue light flashes to show that the Bluetooth is turned on; pair up with "Dispho" and the blue light will be on all the time if the pairing is successful. Touch-hold the camera key for another 3 seconds to shut Bluetooth down.




### Second step: open the phone holder

Set this product face up and turn the phone holder in the back downward for 90° to open it. Then rotate the holder 180° horizontally to face forward.




### Third Step: Fix the phone

Rotate the phone holder till you can pull open the holder handle and fix the phone securely on the holder.



### Fourth Step: Photograph

Set the volume button on your phone to act as the shutter button. Use the remote control to take a photo.



### Fifth Step: Use tripod

This product comes with a tripod. Open the selfie holder from the bottom and fix it on a steady horizontal plane, then you can start to enjoy your selfie shooting experience.



- Separated Bluetooth remote control is designed to be separable with a Bluetooth range of 10 meters.
- The bottom of the remote control is equipped with a charging port; please use it to charge this product.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.