

User Manual & Datasheet

Klikr user manual

Important Safety advice

Read this manual and all safety warnings carefully before you use or install this unit.

Clean-up instructions: don't use solvents. Clean regularly.

Do not try to repair and disassemble the unit by yourself. This may cause an electric shock. Please contact a qualified technician.

Keep away from naked flames (like candles).

Use in temperate areas.

A minimum space of 2 inches should be maintained around the unit for its ventilation.



We hereby declare that Klikr meets the essential requirements and other relevant provisions of European Directive 1999/5/EC.

FCC statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



Waste Electrical and Electronic Equipment Directive

According to Directive 2002/96/EC on Waste Electrical and Electronic Equipment, household electrical appliances cannot be dispersed in the conventional waste stream. Used electrical and electronic equipments must be collected.

Technical specifications

Size: 32 x 32 x 9.5mm

Battery: 1 CR2032

Bluetooth 4.0

Syncing range: > 10 meters

Operating temperature: 0°C to 50°C

Syncing to mobile devices requires Bluetooth 4.0 wireless technology, iPhone 4S and later, and leading Android phones.



Klikr V0.0.1

Model: KL001

Thank you for buying Klikr. You should find on the packing:

- 1 Klikr
- 1 battery
- 1 sticky pad
- User manual

Open the battery door.



Put the battery and close the battery door



Put the sticky pad on the bottom of Klikr



Find the IR sensor of your device and stick the Klikr with the lens towards the IR sensor.



Download the Klikr app on Apple Store or Google Play to control your Klikr.

Klikr V0.0.1

Model: KL001