



Exercise data
Click the data icon to check the corresponding date for the day, including steps, distance, and calories.

Message
After the watch is connected to the mobile APP, the newly pop-up information on the mobile phone will be pushed to the watch side synchronously. The watch can store multiple pieces of information.

Weather
After the watch is connected to the mobile app, the weather will be automatically synchronized to the watch.

08



Heart rate monitoring
The measurement starts after the green indicator light at the bottom is on, and is completed after the vibration occurs in about 30-60s. The measurements are based on PPG technology.

Blood oxygen monitoring
The measurement starts after the red indicator light at the bottom is on, and is completed after the vibration occurs in about 30-60s. The measurements are based on PPG technology.

Sleep monitoring
It records and shows your sleep status that day. The data is updated every day and synchronized to the APP in the same time.

09



Sport mode
Get active your way by choosing your favorite workout modes, including hiking, running, climbing, cycling, basketball, yoga and elliptical machine.

Breath training
Select the corresponding time, and follow the prompts on the watch until it is completed.

Menu style
Adjust the Menu style selection in the watch settings. The menu supports list mode and smart mode.

10



Women's health
Set your gender to female in the app and add information about the menstrual period. You can set up a period reminder with OnWear App.

Stopwatch
Click the triangle icon to start and click again to pause (the left icon means resetting).

Timer
Count down from a specified time with the timer, and it ends with the vibration reminder.

11



Music
After connecting your smart watch with app, open music player to control the playback of the music.

Dial switch
Watch face can be switched by long pressing the dial. Multiple dials are built in the watch. You can also download more Watch faces through our App.

Power on/off
Long press button for 3s to power on. The watch will automatically power on when it is charging. Click the "OFF" icon to shutdown.

12



System Info
View the Bluetooth name, Mac address, firmware version number and other information of the watch.

Reset
All persona data will be removed if you confirm to restore factory settings.

This manual is for reference, the specific functions and interface may be different from the actual product. Please refer to the actual product.

13



Scan the QR code to get multilingual user manual.



Packing list

Specifications

Product model: C1
Waterproof rating: 5ATM
Sensor: 3-axis G-sensor
Battery capacity: 260mAh
Synchronization method: Bluetooth
Resolution: 240x280
Display screen: 1.69 inch TFT
Working time: about 10-25 days
Working temperature: -10°C-50°C
Compatible system: IOS 10.0 or above, Android 5.0 or above

EN

02

Please read the instructions before use

- The waterproof rating of the watch is 5ATM. You can use it normally in daily life situations such as washing your hands, raining, etc. Please do not put the watch in hot water, do not perform operations such as underwater pressing or deep diving. It is not recommended to wear it in the shower.
- The waterproof function is not permanently effective, and the protective performance may be reduced due to daily wear and tear.
- Do not disassemble the product or replace the battery without authorization. If the product fails, please contact the after-sales service department.
- Avoid touching the screen surface with sharp or sticky objects to avoid damage. Avoid dropping the product on the ground or being strongly impacted by other objects. Avoid exposing the watch to corrosive liquids to avoid damage to the watch.
- Charge the batteries for two hours before use. Please avoid overcharging at 100% for an extended time. Place the magnetic charging cable on the back of your smart watch and the end of the charging cable magnetically sticks to the back of your Watch and aligns it properly.
- Please use the input voltage: 5V/1A or 5V/2A charger, with the original charging cable provided by the manufacturer.
- The data of this product is for health management reference only, please do not use it as medical data. If abnormal physical data is found, the hospital's inspection shall prevail.
- The company reserves the right to change or modify all the information in the document without notice. Due to software upgrades, the functions may vary in specific software versions.

03

APP download & login



OnWear App download

- Get the OnWear app in the App Store on your iPhone.
 - Get the OnWear app in Google Play on your Android phone.
 - Scan the QR code in your watch to download OnWear app (compatible with IOS10.0 or above / Android5.0 or above).
- After installing the app, please register or log in with the interface prompts. Turn on your phone Bluetooth, and select the Bluetooth name "XINJI-C1" for binding. Connect your smart watch with your phone in OnWear App. The watch can be used normally now.

04

Method of operation

- From the watch face, swipe down from the top of the screen to enter the shortcut interface.
- From the watch face, swipe up from the bottom of the screen to enter the information list interface.
- From the watch face, swipe right from the left of the screen to enter the menu style interface.
- From the watch face, swipe left from the right of the screen to enter interfaces including step counting, heart rate, and sleep.

05

Warranty card

Customer information		Seller information	
Name		Name	
Add		Add	
E-mail		Purchase Date	
P.C.		Product model	
Tel		Invoice number	
Date	Malfunction	Process result	

06

FCC Statement
1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference.
(2) This device must accept any interference received, including interference that may cause undesired operation.
2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE:
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.
This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
Consult the dealer or an experienced radio/TV technician for help.

07