


Hatch

Meet your Hatch Rest.

(2nd Gen)

Get started.


- 1. Plug it in.** Connect the custom power cable to Rest then plug it into your power outlet.
- 2. Download the app.** Download the Hatch Sleep app to your phone or tablet from the Apple App or Google Play store.
- 3. Connect your Rest.** Follow the steps in the app to connect your Rest (2nd Gen). Setup will take about 10 minutes.



Get to know your Hatch Rest.

Brightness Control
Press to increase or decrease brightness.

Nightlight Button
Press to turn on a soft white light.



Dimmable Clock
Illuminate the clock using your Hatch Sleep app.

Volume Control
Press to increase or decrease volume.

Power Cable Port
Connect your device here.

Touch Ring
Tap the touch ring to turn on your Rest. Tap the touch ring again to cycle through light and sound favorites. Touch and hold the touch ring to turn off your Rest.

Things to try.

- Cycle through favorites.** Tap the touch ring to cycle through light and sound favorites created to help aid sleep — yellow to red hues are recommended by experts designed to help promote sleep.
- Customize a routine.** Personalize a routine to fit your child's schedule, choosing from the range of colors and sounds in the Hatch Sleep app. Try the Time-to-Rise routine to let your child know when it's time to get up.
- Try Hatch Sleep Membership.*** Make bedtime simple and fast with content designed to help kids wind down and dream. Try calming lullabies for babies, snoozy singalongs for little kids, and sleepy stories to help big kids fall asleep fast.

*Activate Hatch Sleep Membership in app.

Recommended Routines.

These are favorite routines shared by real Hatch parents. The Hatch Sleep app will provide personalized sleep routines for your child.

For Babies
White noise can mimic the sounds of the womb and block out unwanted noise.

Yellow Light + White Noise

For Little Kids
Little kids do well with visual and sound cues. Try pink for nap time and green for playtime.

Pink Light + Soft Thunder + Green Light + Dinosaurs

For Big Kids
Big kids love to get up early, so set a time-to-rise routine when you're ready for their day to begin.

Orange Light + Mindfulness + Green Light + Birds

INTRODUCING

Hatch Sleep Membership

An ever-growing library of 100s of bedtime stories, songs, and lullabies to help babies and kids fall asleep fast.

Baby Calming lullabies and sleep singalongs to relax to at bedtime.	Little Kid Sleepy stories, calming lullabies, and snoozy singalongs help toddlers fall asleep fast.	Big Kid Gentle music, mini meditations, and bedtime yoga helps big kids relax and wind down.
---	---	--

Care and safety.

Care Instructions
Unplug Rest before cleaning. Clean the surface with a damp cloth, avoiding the power cable port.

CAUTION: Rest may be damaged if the power cable port comes into contact with liquid.

For Your Safety & Your Child's Safety
Always keep Rest at least three feet away from children as the cord can pose a strangulation hazard. Do not use near or place in water.

Need help? Hatch support is a dream.

Avez-vous besoin d'aide ? Le soutien à Hatch est un rêve.

Contact us at support@hatch.co.
Contactez-nous à support@hatch.co.

Follow [@hatchforsleep](https://twitter.com/hatchforsleep) and see what dreams are made of.
Suivez [@hatchforsleep](https://twitter.com/hatchforsleep) et voyez de quoi sont faits les rêves.


Hatch

Apprenez à connaître votre Rest

(2ème génération)

Les premiers pas.


- 1. Brancher.** Connectez le câble d'alimentation fourni à Rest, et puis branchez-le à une prise de courant.
- 2. Téléchargez l'appli.** Téléchargez l'appli Hatch Sleep sur le magasin Apple App ou Google Play sur votre téléphone ou votre tablette.
- 3. Relevez votre Rest.** Suivez les étapes de l'appli pour relier votre Rest (2ème génération). La configuration prendra environ 10 minutes.



Connaître Hatch Rest.

Contrôle de la luminosité
Appuyez pour augmenter ou diminuer la luminosité.

Bouton d'éclairage nocturne
Appuyez pour allumer une lumière blanche douce.



Horloge
Illuminez l'horloge en utilisant votre appli Hatch Sleep.

Contrôle du volume
Appuyez pour augmenter ou diminuer le volume.

Port du Câble d'Alimentation
Maintenez votre Rest branché pour une utilisation normale.

Anneau tactile
Touchez l'anneau tactile pour allumer votre Rest. Tapez à nouveau l'anneau tactile pour alterner entre les lumières et les sons favoris. Appuyez sur l'anneau tactile et maintenez-le enfoncé pour éteindre l'appareil.

Choses à essayer.

- Passer en revue les favoris.** Commencez une meilleure nuit de sommeil pour votre bébé, votre tout-petit ou votre grand enfant avec des teintes, des lumières et des sons personnalisés. Sauvegardez-les comme vos favoris en un clic.
- Personnalisez une routine.** Personnalisez une routine pour l'adapter aux horaires de votre enfant, en choisissant parmi la gamme de couleurs et de sons de l'appli Hatch Sleep. Essayez la routine "Time-to-Rise" pour faire savoir à votre enfant quand il est temps de se lever.
- Essayez l'Abonnement au Hatch Sleep*** Rendez l'heure du coucher simple et rapide avec des contenus conçus pour aider les enfants à se calmer et à rêver. Essayez les berceuses apaisantes pour les bébés, les chants somnolents pour les petits enfants et les histoires endormies pour aider les grands enfants à s'endormir rapidement.

*Activez l'abonnement à Hatch Sleep sur l'appli.

Routines recommandées.

Voici quelques routines favoris partagés par de parents réels Hatch.

Pour les bébés
Les bébés dorment mieux avec un bruit blanc, donc maintenez ceci comme votre son de prédilection.

Lumière jaune + Bruit blanc

Pour les tout-petits
Réglez une couleur particulière lorsque c'est l'heure de la sieste et une autre couleur lorsqu'il est acceptable pour votre tout-petit de terminer sa sieste.

Lumière rose + Tonnerre doux + Lumière verte + Dinosaures

Pour les grands enfants
Si votre grand enfant commence à avoir peur du noir, utilisez une lumière rouge, rose ou orange à l'heure du coucher pour favoriser un meilleur sommeil.

Lumière orange + Pleine conscience + Lumière verte + Oiseaux

PRÉSENTATION DE

L'Abonnement à Hatch Sleep

Une bibliothèque toujours croissante de centaines d'histoires avant d'aller au lit, de chansons et de berceuses pour aider les bébés et les enfants à s'endormir rapidement.

Bébé Des berceuses apaisantes et des chansons pour se détendre au moment du coucher.	Petit enfant Des histoires pour s'endormir, des berceuses apaisantes et des chants somnolents pour aider les tout-petits à s'endormir rapidement.	Grand enfant De la musique douce, des mini-méditations et du yoga au coucher pour aider les grands enfants à se détendre et à se calmer.
--	---	--

Soins et sécurité.

Instructions d'Entretien
Débranchez le Rest avant de le nettoyer. Nettoyez la surface avec un chiffon humide, en évitant le port du câble d'alimentation.

ATTENTION: Le Rest pourrait être endommagé si le port du câble d'alimentation entre en contact avec un liquide.

Pour votre sécurité et celle de votre enfant
Maintenez toujours le Rest à au moins un mètre (environ trois pieds) des enfants car le cordon peut présenter un risque d'étranglement. Ne pas utiliser près de feu ou dans l'eau.

FCC Caution: Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

IMPORTANT NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
—Reorient or relocate the receiving antenna.
—Increase the separation between the equipment and receiver.
—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
—Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement: This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. The equipment should be installed and operated with minimum distance 20cm between the radiator & your body. (ISED Warning: This device complies with Innovation, Science, and Economic Development Canada's radio-quiet standards.) Operation is subject to the following two conditions:
(1) This device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'opérateur est autorisé aux deux conditions suivantes:
(1) l'appareil radio ne produit de brouillage et
(2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi même si le brouillage est susceptible d'en compromettre le fonctionnement.

The device is compliance with RF exposure guidelines users can obtain Canadian information on RF exposure and compliance. The minimum distance from body to use the device is 20cm.
Le présent appareil est conforme, après examen de ce matériel, aux conditions ou aux limites d'intensité de champ RF. Les utilisateurs peuvent se renseigner sur les exigences en matière de conformité et compléter d'acquies les informations correspondantes. La distance minimale du corps à utiliser le dispositif est de 20cm.

FCC ID: 2AFVZ-HBRE87 / IC:23920-HBRE87