ClearClick® Present+Share (USB-C Edition)

Wireless Presentation & Video Broadcasting System



User's Manual & Quick Start Guide

2-Year Warranty & USA-Based Tech Support

For tech support, email us at: support@clearclick.com

Extend your warranty to 3 years for free by registering at: www.ClearClick.com/Register/



FCC STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCR Miss. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment penerates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no quarantee that interference with not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Regrient or relocate the receiving antenna.

Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.

SAR statement (TX)

This device complies with FCC SAR requirements. The highestreported 1g-SAR for body is 0.287 W / Kg.

For body-worn operation, this device has been tested and meets the FCC RF exposure guidelines for use with an accessory that contains no metal and positions the device a minimum of 0mm from the body. RF exposure compliance with any body-worn accessory that contains metal was not tested and certified. And use of such body-worn accessory should be avoided. Accessory available in market and must be used to keep use distance 0mm from EUT to body-worn operation.

RF Exposure Statement (RX)

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance of 20cm the radiator your body. This device

and its antenna(s) must not be co-located or operation in conjunction with any other

Additional Transmitters Available

This system supports up to 8 transmitters. To purchase additional transmitters, please visit:

www.ClearClick.com

Extend Your Warranty for FREE!

Extend your warranty by one year for free simply by registering your product at: www.ClearClick.com

Safety Precautions - Important, Please Read:

- Do not disassemble the units.
- 2. Do not permit children to use or play with this device.
- Please note that the devices may become very warm during use.
- Do not operate the unit around water or rain. Do not operate the unit around any unnecessary machines or appliances.
- Unplug the units when not in use.
- Use only the included accessories with the device.

2-Year Warranty

Your purchase comes with a **2-year warranty**. This means that if anything goes wrong with the unit (other than accidental damage) within the first 2 years of ownership, we will replace the unit for free, 100% at our cost. Contact us at support@clearclick.com with any issues.

What's In The Box?



2 USB-C Transmitters (TX)



1 HDMI Receiver (RX)



1 USB-C Power Cable (For RX/Receiver)

Recommended System Requirements

PC/Mac/Phone/Netbook/Tablet with USB-C port that supports USB-C video output (DisplayPort Alt Mode).

Recommended minimum 2018 model year. Phones/Tablets must have USB-C port. (Lightning port & micro USB not supported.)

Quick Start Guide

- Plug in the receiver (RX) to your TV, monitor, or projector via HDMI.
- Connect the USB-C port of the receiver (RX) to a USB port or power supply for power (required).
- 3. Connect a transmitter (TX) to your PC/Mac/Netbook/Phone/Tablet's USB-C port. (See System Requirements on previous page.)
- 4.Press the button on the transmitter (TX) to start transmitting to the receiver (RX) attached to your TV, monitor, or projector.
- 5. Within a few seconds, your TV/monitor/projector will show the video signal that it is receiving from your device.

6.IMPORTANT NOTE - HOW TO USE THE SECOND TRANSMITTER (TX):

If the first transmitter (TX) is transmitting/in use, you must first "unlink" it by pressing the button on

the first transmitter (TX) again (or unplugging it entirely). This will "unlink" the first transmitter and allow you to transmit from the second transmitter (TX).

Technical Specifications

Transmitter (TX) Interface: USB-C

Receiver (RX) Interface: HDMI

Network: Wi-Fi

Max Resolution: 1920x1080/60 FPS

Latency: 90~120ms Range: Up to 49 feet For product support or to purchase additional transmitters (TX), please visit:



© 2023 ClearClick Software LLC. All rights reserved.