

旧白

 2) Press the device button (or trigger the door magnet / the infrared sensor), the receiver will produces sound "Du" to indicate the pairing sensors, the receiver will adarm. 2) Press the device button (or trigger the door magnet / the infrared sensor), the receiver will adarm. 3.5 Environment operating temperature: Receiver: -20~70 C Dorbell button: -40~70 C 3.6 Environment operating humidity: Receiver: -20~70 C Dorbell button: -40~70 C 3.7 Storage temperature: Signal. 3.7 Storage temperature: Receiver: -20~70 C Dorbell button: -40~70 C 3.6 Environment operating humidity: Receiver: -20~70 C Dorbell button: -40~70 C 3.7 Storage temperature: Receiver: -20~70 C Dorbell button: -40~70 C 3.6 Environment operating nethod. 3.7 Storage temperature: Receiver: -20~70 C Dorbell button: -40~70 C 3.6 Environment operating humidity: Receiver: -20~70 C Dorbell button: -40~70 C 3.7 Storage temperature: Receiver: -20~70 C Dorbell button: -40~70 C 3.6 Environment operating humidity: Receiver: -20~70 C Dorbell button: -40~70 C 3.7 Storage temperature: Receiver: -20~70 C Dorbell button: -40~70 C 3.6 Environment operating humidity: Receiver: -20~70 C Dorbell button: -40~70 C 3.7 Storage temperature: Receiver: -20~70 C Dorbell button: -40~70 C 3.6 Environment operating humidity: Receiver: -20~70 C Dorbell button: -40~70 C 3.7 Storage temperature: Receiver: -20~70 C Dorbell button: -40~70 C 3.6 Environment operating humidity: Receiver: -20~70 C Dorbell button: -40~70 C 3.7 Storage temperature: Receiver: -20~70 C Dorbell button: -40~70 C 3.8 Receiver: -20~70 C Dorbell button: -40~70 C 3.9 Receiver: -20~70 C Dorbell button: -40~70 C 3.6 Receiver: -20~70 C Dorbell button: -40~70 C 3.7 Storage temperature: Receiver: -20~70 C Dorbell button: -40~70 C 3.8 Receiver: -20~70 C Dorbell button: -40~70 C 3.9 Recei	 a magnet / the infrared sensor), the receiver will a magnet / the infrared sensor), the receiver will produces sound "Du" to indicate the pairing is successful. Private Door Pairing Method: Set the private doorbell button and choose a "special ringtone" to remind the owner if use in a private door for go in and out. The pairing method is as follows: 1.) Press [Δ] ringtone selection key of the receiver to choose a "special ringtone". 2.) Press and hold [Δ] ringtone selection key 	
---	--	--

反面