

BLUETOOTH connected ACTIVE NOISE CANCELLING HEADSET

Ref.: 9047

- MANUAL -

BUTTON OPERATING INTRUCTIONS

1. ANC : Long press 2 seconds this button to turn ON/OFF de-noising.

The LED indicator is in green when in noise cancelling state.

2. MI : Long press 3 seconds to power ON/OFF. Short press for play/pause.

When call comes, short press to answer, Long press to reject, double click to redial.

- 3. P- : Short press for volume down . Long press for previous song
- 4. + Short press for volume up. Long press for next song.
- 5. Type-C USB /DC 5V for USB charge
- 6. 3.5mm AUX-IN input

BLUETOOTH MODE

- 1. Power on the headset. The red/blue light flashes fast, go to Bluetooth pairing state.
- Open the Bluetooth function of your Bluetooth advice and choose the preparing name of "SoundPlay ANC" to connect. The blue light flashed slowly after paired successfully.
- 3. When call come in, press the **PLAY/PAUSE** button to answer call or end call.

AUX-IN MODE

- Insert the 3.5mm AUX cable into the 3.5mm slot, you can use it as wired headphone.
- Can use line in function without power on. Support MP3/IPOD/SMARTPHONE/PC etc.

NOISE CANCELLING

In Bluetooth mode or AUX-IN mode, short press **ANC** button to turn on/off de-noising. The LED indicator will be in green when in noise cancelling state. *Note: Turn on ANC function, the music sound will suddenly increase.*

CHARGE BATTERY

Insert one end of USB cable (included) to DC5V slot on the device, and connect another end to PC or adapter which is 5V output.

PRECAUTIONS

- 1) The headset is not waterproof, note that waterproof and moisture in order to ensure the system can used normally
- 2) It can't to place long-term, need to charge and discharge one time weekly in order to extend battery life.
- 3) It is major of support computer USB to charge, to change or connect to other internal power to charge.

PRECISE DETAILS AND PRECAUTIONS OF THE LISTENING OF THE DEVICE WITH AN EARPHONES OR AUDIO HELMET

- In order to prevent hearing damage, please do not expose too long your ears to high noise levels. Exposition to an 80dB (A) noise level should not exceed forty hours per week, and five hours per week for an 89dB (A) noise level.

- Have regular listening breaks.
- Hearing at a too high sound volume can impair your hearing.
- You risk a permanent hearing impairment.
- Limit the volume: always adjust the volume so as to listen to a clear and safe quality of sound.

FCC Caution

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.