T890 Sport Bluetooth Headset User Manual Thark you for choosing our Blactric please read this to before usage.	Support IFP; HSP, A2DP and AVRCP Connect with two Bluetooth devices simultaneously Operating Range: Up to 33 feet (10 90mAh rechargeable batteries Tak imma: Bhours Music Play time: 7 hours Standby time: 20 hours Charging time: 2 hours Uetooth IPhone battery indication	Note: Low battery alarm: red LED flash several lines with a prompt "Battery Low". Charges Charges Charges Charges Charges Charges Charges Charges Contained Charges Contained	consultiver lank or any default will be consultive the end LED will be consult with the earlyhout is end LED be consult we earlyhout has been Maly charged. Note release charge the earlyhout for 2 box enderson is the early the early phone is damp and wet places where is can trave dramget. Barring and connection with a device: Step 1: Long press MFB built the LED barring mode. Step 2: Turn on the Blackshoth on your device and can be earlyhout end the earlyhout is the earlyhout end connection with the earlyhout. Step 2: Turn on the Blackshoth on your connection with the earlyhout. Step 2: Turn on the Blackshoth or your connection with the earlyhout.	 the approval and the approval. the Viet of Viet State Number of the approxame of the state Number of Viet State Number of Viet State Number of Viet State Number of Viet Number	password '0000': Important: If the paining carril be com- paring mode activated, which hears the paining the activated, which hears the paining is activated, which hears the paining is activated, which hears the model phone again. Comparing the model phone again. Compar	back to the previous song. View Constraints of the second with a prompt press MFB 1 second with a prompt being the second with a prompt which preverse ensary our mobile phone which preverse ensary our mobile phone the phone ensary our mobile phone which preverse and the second end of the phone ensary our mobile phone the phone ensary our mobile phone the phone ensary our mobile phone the phone ensary our mobile the phone ensary our mobile	Press MF3 token to making the second definition to the second definition of definition that all on the second definition of definition to go back and from the 2 calls, quickly togother and the second definition of the second definition of the second second second second calls of second second second second second calls of second second second second second definition of the second second second second definition of the second second second second second definition second second second second second definition of the second second second second second second definition second second second second second second definition second second second second second second second definition second second second second second second second definition second	pinet will be its occe applied of the Last Number Recalling finite. Note: depending on your phone type, the actual operation may be different. (Proced Battery Indicator) For Procues, there will be a Battery field indicator of the approve that will appear on the upper right screen. (Accessories) Micro USE Charping Cable Ear Tree (6 pinces: 2amail, 2medium, 2 large)	EVERCENT CARE Warrently Period, 12 months from the data of purchase. Fore Barrice: During the warrently period, If there is any barry provide the second of the second warrang local and purchasing invoke to any provide the second of the second of the Fore mainten work to go an under the 1-The dranged due to water or does and the matchinery calcaded by fundam. 2. The dranged caused by fundam due emainteners and by fundam due to the fore mainteners and the damage caused by the Force majorum.	Customer Name Guidomer Photos Product Notes Product Notes Product Notes Comparison and Comparison Dealer
である て まのの スポーツブルートゥース・ヘッドセ ットのユーザーマニュアル の の で ちょっと た の た の に の の の の の の の の の の の の の		ヘッドフォン内部に取り外し可能を電話がな レインストールされている heartar gable 電 他を使用します。いない夜さんまたは変更に 電池を使用します。いない夜さんまたは変更に 電池を引き起こす書を行うください。不正な 友ざんやそうするすべての場面の回転電話だを引 いませんか。 オーキャンの個くため語言の回答電話に少く イヤホン、携帯電話を実電話(中の実電器)に少く イマホン、携帯電話を実電話(中の実電器)に少く	新になります、イヤホンが交会に充電される 方に変わります。 日本、約々ズ泡(下くれた)、24,5% 日本、約々ズ泡(下くれた)、24,5% 日本、約々ズ泡(下)、24,5% 日本、14,5% <p日本、14,5%< p=""> <p日本、14,5%< p=""> <p日本、14,5%< p=""> <p日本、14,5%< <="" th=""><th>イヤホンの12D が青色にしょっちゅう点紙 のみ。 31 g 電気にイホンキペワシングするには、 干燥 をなす、単品のデバイズの18moxの4 アプリケーション。 ステップシュ港目のデバイズの17メントス に不開、12度1012、 ステップを単語のペマのデバイズに 18moxの4 アプリケーション。 ステップを単語のペマのデバイズに 18moxの4 アプリケーション。 メモルマントス オールン・ ステップを使用のペマのデバイズに 18moxの5 キャント オールン・ ステップシューム・ ステップシューム・ オールン・ ステップシューム・ オールン・ ステップシューム・ オールン・ スティント オールン・ スティント オールン・ スティント オールン・ スティント オールン・ スティント オールン・ スティント オールン・ スティント オールン・ スティント スティント オールン・ スティント スト スティント スティント スト スティント スティント スト スティント スト スティント スティント スト スティント ス スティント スティント スティント スティント スティント スティント スティント スティント スティント スティント スティント スティント スティント スティント スティント スティント スティント スティント ス ス ス ス ス ス ス ス ス ス ス ス ス ス ス ス ス ス ス</th><th>住 志なたの現明電話は、パージョン21以 注 、 、 、 、 、 、 、 、 、 、 、 、 、</th><th>長い間音楽を整まなた方用し、トラックま で着二声シン1は、前の部に設つます。 ・ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・</th><th>2番目の町で用しをす着目のブイイスから 気軽ものでを入意使します。これによう ためのでを入意使します。これによう ためのでを入意の意識のので加し、 という、これになったの意識のので加し、 を用いたすべた。これに必要すること、 時にありてのためを思すること、 のである、これに必要する。 のである、これに必要する。 これになったり、これになった。 これになったり、これになった。 これになったり、これになった。 これになったり、これになった。 これになったり、これになった。 これになったり、これになった。 これになったり、これになった。 これになったり、これになった。 これになったり、これになった。 これて、 これになった。 これになった。 これになった。 これになった。 これになった。 これになった。 これで、 これで、 これて、 これで、 これで、 これて、 これて、 これて、 これて、 これて、 これて、 これて、 これて</th><th>「最悪物」ダイヤム、プロングでまでう、 同胞学ーを抑えます。これは、単行的に のは、学校が入れてたまたのであり、ダイヤを抱から作り、タイヤ などの考慮していたます。 最後の書のいたれたまたの情報であり、 のであれたまたまた。ペアにされた 低低の のであれたまたまた。ペアにされた しつきれたまたまた。ペアにされた のであれたまたまた。ペアにされた のであれたの言語の時期によっては実際の後 作が良める、同たものできた。 「日本のこのであり、これでいたまです。 それたのできたいできた。 「日本のこのであり、これでいたまです。 それたのできたいできた。 では、またで、 「日本のこのであり、これでいたまで、 なくたちのます。 「日本のこのであり、 「日本のこのであります。」 「日本のこのであります。」 「日本のこのであります。」 「日本のこのであります。」</th><th>住住的で 使用の 使用の 使用の 使用の 使用の 使用の 使用の 使用の 使用の 使用の</th><th>1000 € 1000 € 1000 €</th></p日本、14,5%<></p日本、14,5%<></p日本、14,5%<></p日本、14,5%<>	イヤホンの12D が青色にしょっちゅう点紙 のみ。 31 g 電気にイホンキペワシングするには、 干燥 をなす、単品のデバイズの18moxの4 アプリケーション。 ステップシュ港目のデバイズの17メントス に不開、12度1012、 ステップを単語のペマのデバイズに 18moxの4 アプリケーション。 ステップを単語のペマのデバイズに 18moxの4 アプリケーション。 メモルマントス オールン・ ステップを使用のペマのデバイズに 18moxの5 キャント オールン・ ステップシューム・ ステップシューム・ オールン・ ステップシューム・ オールン・ ステップシューム・ オールン・ スティント オールン・ スティント オールン・ スティント オールン・ スティント オールン・ スティント オールン・ スティント オールン・ スティント オールン・ スティント スティント オールン・ スティント スト スティント スティント スト スティント スティント スト スティント スト スティント スティント スト スティント ス スティント スティント スティント スティント スティント スティント スティント スティント スティント スティント スティント スティント スティント スティント スティント スティント スティント スティント ス ス ス ス ス ス ス ス ス ス ス ス ス ス ス ス ス ス ス	住 志なたの現明電話は、パージョン21以 注 、 、 、 、 、 、 、 、 、 、 、 、 、	長い間音楽を整まなた方用し、トラックま で着二声シン1は、前の部に設つます。 ・ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・	2番目の町で用しをす着目のブイイスから 気軽ものでを入意使します。これによう ためのでを入意使します。これによう ためのでを入意の意識のので加し、 という、これになったの意識のので加し、 を用いたすべた。これに必要すること、 時にありてのためを思すること、 のである、これに必要する。 のである、これに必要する。 これになったり、これになった。 これになったり、これになった。 これになったり、これになった。 これになったり、これになった。 これになったり、これになった。 これになったり、これになった。 これになったり、これになった。 これになったり、これになった。 これになったり、これになった。 これて、 これになった。 これになった。 これになった。 これになった。 これになった。 これになった。 これで、 これで、 これて、 これで、 これで、 これて、 これて、 これて、 これて、 これて、 これて、 これて、 これて	「最悪物」ダイヤム、プロングでまでう、 同胞学ーを抑えます。これは、単行的に のは、学校が入れてたまたのであり、ダイヤを抱から作り、タイヤ などの考慮していたます。 最後の書のいたれたまたの情報であり、 のであれたまたまた。ペアにされた 低低の のであれたまたまた。ペアにされた しつきれたまたまた。ペアにされた のであれたまたまた。ペアにされた のであれたの言語の時期によっては実際の後 作が良める、同たものできた。 「日本のこのであり、これでいたまです。 それたのできたいできた。 「日本のこのであり、これでいたまです。 それたのできたいできた。 では、またで、 「日本のこのであり、これでいたまで、 なくたちのます。 「日本のこのであり、 「日本のこのであります。」 「日本のこのであります。」 「日本のこのであります。」 「日本のこのであります。」	住住的で 使用の	1000 € 1000 € 1000 €